

## Bush Home WC31831

# Bush Home Cabot 60W Desk Hutch User Manual

Model: WC31831 | Brand: Bush Home

## 1. INTRODUCTION

Thank you for choosing the Bush Home Cabot 60W Desk Hutch. This hutch is designed to provide additional storage and organization for your home office, complementing a coordinating 60W computer desk (sold separately). It features a transitional style, offering practical storage solutions and display space for various items.

This manual contains important information regarding the assembly, safe operation, and maintenance of your new hutch. Please read it thoroughly before beginning assembly and retain it for future reference.

## 2. SAFETY INFORMATION

- **Wall Attachment:** For enhanced stability and safety, especially in homes with children, wall attachment hardware is included. It is highly recommended to secure the hutch to a wall using the provided hardware to prevent tipping.
- **Weight Distribution:** Distribute weight evenly across shelves and compartments. Avoid placing excessively heavy items on upper shelves.
- **Assembly:** Follow all assembly instructions carefully. Incorrect assembly can lead to instability and potential injury. A second pair of hands is recommended for assembly.
- **Monitor Clearance:** The hutch design accommodates monitors up to 18 inches high in the open desk area. Ensure your monitor fits within this clearance.

### 3. PACKAGE CONTENTS

Your package should contain the following components:

- 60W Hutch components (engineered wood panels, shelves, back panel)
- Fluted glass door with flip-up hinge mechanism
- Assembly hardware (screws, dowels, cam locks, etc.)
- Wall attachment hardware
- Assembly Instructions booklet

Inspect all parts before assembly. If any components are missing or damaged, please contact customer support.

### 4. ASSEMBLY INSTRUCTIONS

Detailed assembly instructions are provided in the booklet included with your product. Please refer to this booklet for step-by-step guidance. The following points highlight key aspects of the assembly process:

- **Preparation:** Clear a spacious area for assembly. Lay out all parts and hardware.
- **Panel Identification:** Carefully identify each panel using the labels or diagrams in the instruction booklet.
- **Hardware:** Use the correct hardware for each step. Avoid overtightening screws, which can damage the engineered wood.
- **Back Panel:** The back panel is crucial for structural integrity. Ensure it is properly aligned and secured.
- **Fluted Glass Door:** Pay close attention to the installation of the flip-up door and its hinge mechanism. Ensure the hinges are correctly oriented and secured to allow smooth operation.
- **Wall Anchor:** Install the wall attachment hardware as directed in the manual to secure the hutch to a wall.



Fluted glass door that  
flips up to open

Anti-Tip Restraint  
Wall Anchor included

Hutch door  
remains open for  
your convenience

Work-in-progress  
compartments

Figure 4.1: Overview of hutch features including fluted glass door, wall anchor, and work-in-progress compartments.



Figure 4.2: Detail of the flip-up door mechanism, designed for smooth opening and closing.



Figure 4.3: Cable management grommet for organizing wires and cords.

## 5. OPERATION

The Cabot 60W Desk Hutch is designed for straightforward use:

- **Fluted Glass Door:** The center cabinet features a fluted glass door that flips up to open. Gently lift the door to access the enclosed storage compartment. The hinge mechanism is designed to hold the door open for convenience.
- **Open Shelves:** The open shelves to the left and right of the center cabinet are suitable for displaying decorative items, small plants, or organizing books.

- **Bottom Cubbies:** Three open cubbies at the bottom provide easy access to frequently used materials or work-in-progress documents.
- **Cable Management:** Utilize the designated space at the bottom of the hutch to route and manage cords and cables from your electronic devices, maintaining a tidy workspace.

Your browser does not support the video tag.

Video 5.1: An overview of the Bush Home Cabot Collection, demonstrating various furniture pieces and their functionality, including the hutch.

## 6. MAINTENANCE

To maintain the appearance and longevity of your hutch:

- **Cleaning:** Wipe surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Promptly clean any spills to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically check all assembly hardware and wall anchor connections to ensure they remain tight. Tighten as necessary.

## 7. TROUBLESHOOTING

- **Difficulty with Door Installation:** If the fluted glass door is difficult to install or does not operate smoothly, re-check the hinge orientation and mounting. Ensure the hinges are correctly positioned over their mounts as per the assembly instructions. Do not force components.
- **Hutch Instability:** If the hutch feels unstable, verify that all assembly hardware is tightened and that the wall attachment hardware is securely installed. Ensure the hutch is placed on a level surface.
- **Missing/Damaged Parts:** If you encounter missing or damaged parts during assembly, do not proceed. Contact customer support for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Bush Home
Model Number	WC31831
Product Dimensions (D x W x H)	11.46"D x 59.45"W x 36.3"H (29.1 cm D x 151.0 cm W x 92.2 cm H)

Material	Engineered Wood
Color	Espresso Oak
Item Weight	64 Pounds (29 kg)
Number of Shelves	6
Number of Doors	1 (Flip-Up with Fluted Glass)
Monitor Clearance (under hutch)	Up to 18 inches high
Assembly Required	Yes



Closed Storage Dimensions  
**H** 12.60" (32.0 cm) x **W** 22.28" (56.6 cm) x **D** 10.43" (64.5 cm)

Figure 8.1: Detailed dimensions of the Cabot 60W Desk Hutch.

## 9. WARRANTY INFORMATION

The Bush Home Cabot 60W Desk Hutch is backed by a **1-year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For specific details regarding warranty coverage and limitations, refer to the warranty documentation included with your product or visit the Bush Home official website.

## 10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bush Home customer support. Contact information can typically be found on the manufacturer's website or in the product packaging.

Please have your model number (WC31831) and proof of purchase ready when contacting support.