

BarcaLounger 7-4148

BarcaLounger Presidential II Manual Recliner User Manual

Model: 7-4148

INTRODUCTION

Thank you for choosing the BarcaLounger Presidential II Manual Recliner. This manual provides essential information for the proper setup, operation, and maintenance of your new recliner. The Presidential II model 7-4148 features classic elegance with deep button tufting, a barrel back, and accenting nail head trim. It is constructed with durable materials for lasting comfort and style.

Key features include:

- Stetson Coffee Top Grain Leather upholstery.
- Espresso Wood Legs.
- Glued joints with corner blocks for enhanced stability.
- Mechanisms bolted to the frame with t-bolts.
- Five no-sag springs with tie wires.
- Delrin bushings on all mechanisms for smooth operation.
- Upholstered handles and underside for a finished look.
- Padding on sides and backs for safety.
- High resilience 1.8 density seat foam for superior durability and comfort.
- Hardwood frames with mortise and tenon construction.

SETUP INSTRUCTIONS

The BarcaLounger Presidential II Manual Recliner is designed for minimal assembly. Typically, no complex assembly is required beyond attaching the backrest and feet.

1. **Unpacking:** Carefully remove all packaging materials from the chair. Ensure all components are present.
2. **Attaching the Backrest:** The backrest slides onto the main chair frame. Align the metal brackets on the backrest with the corresponding slots on the chair base and slide down until securely locked.
3. **Attaching the Feet:** Screw the wooden feet into the designated threaded holes at the bottom of the chair. Ensure they are tightened securely to provide stability.

4. **Placement:** Position the recliner in your desired location, ensuring adequate space behind the chair for reclining.



Image: Front view of the BarcaLounger Presidential II Manual Recliner. This image shows the chair in its upright position, highlighting the tufted back and nail head trim.

OPERATING INSTRUCTIONS

The Presidential II is a manual recliner, offering ease of use for various reclining positions.

1. **To Recline:** To engage the reclining mechanism, gently push back on the chair's backrest while simultaneously

pushing forward on the armrests. The footrest will extend, and the backrest will recline.

2. **Adjusting Recline Position:** The chair offers two reclining positions. Continue to apply pressure to the backrest to achieve the desired angle.
3. **To Return to Upright Position:** To bring the chair back to its upright position, gently push down on the footrest with your legs and lean forward. The footrest will retract, and the backrest will return to the seated position.



Image: Side view of the recliner in a partially reclined state. This illustrates the extended footrest and the initial recline angle.

MAINTENANCE

Proper care will extend the life and appearance of your recliner.

- **Cleaning:** For general cleaning, use a soft, dry cloth. For spills or stains, follow the "Spot Wash" instructions. Use a mild leather cleaner specifically designed for top grain leather, testing in an inconspicuous area first.
- **Spot Wash:** Apply a small amount of mild soap solution to a clean cloth and gently blot the stained area. Do not rub vigorously. Wipe with a clean, damp cloth to remove soap residue, then dry immediately with a clean, dry cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause leather to fade and dry out. Position your recliner away from direct sunlight or use window coverings.
- **Avoid Heat Sources:** Keep the recliner away from heat sources like radiators or fireplaces to prevent drying and cracking of the leather.
- **Fluffing Cushions:** Periodically fluff and rotate removable cushions to maintain their shape and even out wear.

SPECIFICATIONS

Feature	Detail
Brand	BarcaLounger
Model Name	Presidential II (Model 7-4148)
Color	Stetson Coffee (Brown)
Upholstery Material	Top Grain Leather
Frame Material	Hardwood Plywood with Mortise and Tenon Construction
Product Dimensions (D x W x H)	40.5"D x 34.5"W x 40"H
Approximate Seat Dimensions (H x W x D)	20.5"H x 20"W x 23"D
Item Weight	125 pounds
Back Style	Tufted Back
Arm Style	Rounded
Leg Style	Tapered Leg (Espresso Wood)
Reclining Position Count	2
Assembly Required	No (minimal attachment of backrest and feet)

TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common solutions:

- **Reclining Mechanism Stiff:** Ensure the chair is placed on a level surface and there are no obstructions behind or beneath it. Apply gentle, even pressure when reclining.
- **Footrest Not Engaging/Retracting:** Check for any objects obstructing the footrest mechanism. Ensure the backrest is fully engaged in the upright position before attempting to retract the footrest.
- **Loose Components:** Periodically check all screws and bolts, especially those securing the feet and backrest, and tighten if necessary.
- **Squeaking Noises:** Apply a small amount of silicone-based lubricant to moving metal parts of the reclining mechanism if squeaking occurs. Avoid oil-based lubricants on wooden parts.

For persistent issues not resolved by these steps, please contact customer support.

WARRANTY INFORMATION

BarcaLounger provides the following warranty coverage for the Presidential II Manual Recliner:

- **Manufacturing Defects:** One (1) year warranty against manufacturing defects.
- **Mechanisms:** Five (5) year warranty on reclining mechanisms.
- **Foam and Frame Parts:** Three (3) year warranty on foam and frame parts.

This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, abuse, accidents, commercial use, or unauthorized repairs. Please retain your proof of purchase for warranty claims.

SUPPORT & CONTACT

For further assistance, product inquiries, or warranty claims, please visit the official BarcaLounger store or contact customer support.

Official BarcaLounger Store: [Visit Store](#)

