

Manuals.plus /

- › [Standard Motor Products](#) /
- › Standard Motor Products S-1410 Electrical Connector User Manual

Standard Motor Products S-1410

Standard Motor Products S-1410 Electrical Connector User Manual

Model: S-1410 | Brand: Standard Motor Products

1. PRODUCT OVERVIEW

The Standard Motor Products S-1410 Electrical Connector is a high-quality replacement component designed for automotive electrical systems. It ensures a secure and reliable connection for various applications, maintaining optimal circuit integrity.

This connector is engineered to meet or exceed OEM specifications, providing a durable and long-lasting solution for repairing or upgrading vehicle wiring harnesses.



Figure 1.1: The S-1410 Electrical Connector, showing the gray connector body, black locking tab, and pre-attached white wires, along with four heat-shrink butt connectors.

2. WHAT'S INCLUDED

- 1 x Standard Motor Products S-1410 Electrical Connector with pre-attached wires
- 4 x Heat-shrink butt connectors (typically included for splicing)

3. SPECIFICATIONS

Attribute	Detail
Model Number	S-1410
Brand	Standard Motor Products
Product Type	Electrical Connector
Item Weight	0.01 ounces (approx.)
Product Dimensions	2.8 x 1 x 7.1 inches (approx.)
Exterior Finish	Machined

4. INSTALLATION GUIDE

Proper installation of the S-1410 Electrical Connector is crucial for safety and performance. If you are unsure about any step, consult a qualified automotive technician.

4.1. Safety Precautions

- Always disconnect the vehicle's battery before working on electrical systems to prevent electrical shock or short circuits.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves.
- Ensure the work area is well-lit and free of obstructions.
- Use only appropriate tools for electrical work.

4.2. Installation Steps

1. **Identify the Original Connector:** Locate the faulty or damaged electrical connector that needs replacement. Ensure it matches the S-1410 connector in terms of pin configuration and application.




Figure 4.1: Detailed view of the connector's internal pin configuration, showing the "STANDARD" branding and the blue and gray plastic inserts.

2. **Disconnect and Remove:** Carefully disconnect the old connector from its mating component. Cut the wires leading to the old connector, leaving enough length on the vehicle's harness for splicing.
3. **Prepare Wires:** Strip approximately 1/4 to 3/8 inch of insulation from the ends of the wires on both the vehicle's harness and the new S-1410 connector. Ensure wires are clean and free of fraying.
4. **Splice Wires:** Using the provided heat-shrink butt connectors (or other suitable splicing methods like solder and heat shrink tubing), connect the wires from the new S-1410 connector to the vehicle's harness. Ensure correct wire-

to-wire matching (e.g., color-to-color, if applicable, or according to wiring diagrams). Crimp the butt connectors securely.



Figure 4.2: Side profile of the S-1410 Electrical Connector, highlighting the robust construction and the black locking mechanism.

5. **Heat Shrink (if applicable):** If using heat-shrink butt connectors, apply heat evenly to shrink the tubing and create a sealed, insulated connection.
6. **Connect New Connector:** Once all wires are securely spliced and insulated, connect the new S-1410 Electrical Connector to its mating component. Ensure it clicks firmly into place.
7. **Test Functionality:** Reconnect the vehicle's battery. Test the electrical system or component that the connector serves to ensure proper operation.

5. OPERATING CONSIDERATIONS

Once installed, the S-1410 Electrical Connector operates as a passive component within the vehicle's electrical system. Its primary function is to provide a stable and conductive pathway for electrical signals or power.

- Ensure the connector is fully seated and locked to prevent intermittent connections or disconnections due to vibration.
- Avoid pulling on the wires when disconnecting; always grasp the connector body.

6. MAINTENANCE

The S-1410 Electrical Connector requires minimal maintenance once installed. However, periodic inspection can help ensure its longevity and reliable performance.

- **Visual Inspection:** Periodically inspect the connector for signs of corrosion, damage, or loose connections. Look for cracked plastic, frayed wires, or discolored terminals.
- **Cleaning:** If necessary, gently clean the exterior of the connector with a soft, dry cloth. For stubborn dirt or light corrosion on terminals (only if disconnected and safe to do so), use a specialized electrical contact cleaner. Ensure the connector is completely dry before reconnecting.
- **Secure Mounting:** Ensure any associated wiring or the connector itself is properly secured to prevent strain or abrasion from vehicle movement.

7. TROUBLESHOOTING

If you experience issues after installing the S-1410 Electrical Connector, consider the following troubleshooting steps:

- **No Power/Intermittent Connection:**
 - Verify that the connector is fully seated and locked.
 - Check the integrity of the wire splices. Ensure they are crimped securely and insulated properly.
 - Inspect the pins within the connector for bending or corrosion.
 - Use a multimeter to check for continuity across the connector and through the spliced wires.
- **Component Malfunction:**
 - Ensure the correct connector was used for the application. Verify pinout and wire assignments against the vehicle's wiring diagram.
 - Confirm that the issue is not with the component itself or other parts of the electrical circuit.
- **Physical Damage:**
 - If the connector body or wires appear damaged, it may need to be replaced.

If troubleshooting does not resolve the issue, it is recommended to consult a professional automotive technician.

8. WARRANTY AND SUPPORT

Standard Motor Products offers a limited warranty on its products. For specific warranty terms, conditions, and duration, please refer to the official Standard Motor Products website or contact their customer support directly. For technical assistance or product inquiries, please visit the [Standard Motor Products official website](#) or contact their customer service department.

© 2024 Standard Motor Products. All rights reserved.
This manual is for informational purposes only. Always follow vehicle manufacturer's service procedures.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B005F9N1Q6>

More documents and user manuals: <https://manuals.plus/>