

Manuals.plus /
› Lighting EVER /
› Lighting EVER LE LED Headlamp Flashlight (Model 3200001) User Manual

Lighting EVER 3200001

Lighting EVER LE LED Headlamp Flashlight (Model 3200001) User Manual

Brand: Lighting EVER | Model: 3200001

INTRODUCTION

This manual provides instructions for the safe and efficient operation of your Lighting EVER LE LED Headlamp Flashlight, Model 3200001. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Do not look directly into the LED light when it is on, as this may cause temporary vision impairment.
- Keep out of reach of children.
- Ensure batteries are inserted with correct polarity.
- Remove batteries if the headlamp will not be used for an extended period to prevent leakage.
- Do not mix old and new batteries, or different types of batteries.
- The headlamp is IP44 water resistant, meaning it is protected against splashing water from all directions. It is not designed for submersion in water.

PACKAGE CONTENTS

- 1 x LE LED Headlamp Flashlight
- 3 x AAA Batteries

PRODUCT FEATURES

- 4 Lighting Modes:** Includes 3 levels of white light brightness (2 LEDs, 10 LEDs, 18 LEDs) and a red flashing mode.
- Adjustable & Lightweight:** The headlamp is 90° tiltable for oriented lighting and weighs approximately 3.2 oz (90g) for comfortable wear.
- IP44 Water Resistant:** Designed to withstand splashing water from any angle.
- Battery Powered:** Operates on 3 AAA batteries (included).
- Versatile Use:** Suitable for various activities such as running, hiking, camping, fishing, cycling, and reading.

SETUP

1. Battery Installation

1. Locate the battery compartment on the side of the headlamp.
2. Open the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.




Image: The LE LED Headlamp Flashlight shown with three AAA batteries, illustrating the power source.

2. Adjusting the Headband

The elastic headband is adjustable to fit various head sizes for both adults and children. Use the sliding buckles on the sides to tighten or loosen the strap for a comfortable and secure fit.

OPERATING INSTRUCTIONS

1. Power On/Off and Mode Selection

The power button is located on the side of the headlamp. Press the button to cycle through the lighting modes:

1. **First Press:** Activates 2 white LEDs (low brightness).
2. **Second Press:** Activates 10 white LEDs (normal brightness).
3. **Third Press:** Activates 18 white LEDs (high brightness).
4. **Fourth Press:** Activates red flashing mode.
5. **Fifth Press:** Turns the headlamp off.




Image: Visual representation of the four distinct lighting modes: High Beam, Normal Light, Low Intensity, and Flashing Safety Light (red).

Your browser does not support the video tag.

Video: Demonstration of the LE LED Headlamp Flashlight's features, including its red light and water resistance. This video highlights the product's functionality in various conditions.

2. Adjusting Beam Angle

The headlamp unit can be tilted up to 90 degrees to direct the light precisely where needed. Gently push or pull the light unit to adjust its angle.

90° Tiltable For Oriented Lighting



Image: Illustration showing the headlamp's 90-degree tiltable feature, allowing users to adjust the light direction for optimal visibility.

MAINTENANCE

- **Cleaning:** Wipe the headlamp with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace all three AAA batteries simultaneously when the light dims significantly. Refer to the "Battery Installation" section for proper procedure.
- **Storage:** Store the headlamp in a cool, dry place. Remove batteries if storing for more than a few weeks.



IP44 Waterproof

Protected against splashing from every angle

Image: Close-up of the LE LED Headlamp showing water droplets, emphasizing its IP44 water-resistant rating.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headlamp does not turn on.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace with fresh AAA batteries.
Light is dim.	Low battery power.	Replace all three AAA batteries.
Headlamp flickers.	Loose battery connection or low battery power.	Ensure batteries are seated correctly. Replace batteries if necessary.

SPECIFICATIONS

- **Model:** 3200001

- **Brand:** Lighting EVER (LE)
- **Light Source Type:** LED
- **Lighting Modes:** 3 White Light (2 LEDs, 10 LEDs, 18 LEDs), 1 Red Flashing
- **White Brightness:** 78 Lumens
- **Power Source:** 3 x AAA Batteries (included)
- **Average Battery Life:** Up to 10 hours (in red light mode)
- **Water Resistance Level:** IP44 (Water Resistant)
- **Material:** ABS
- **Item Weight:** 3.2 ounces (approx. 90 grams)
- **Product Dimensions:** 3.66"D x 1.67"W x 1.67"H
- **Special Feature:** 90° Adjustable Tilt

WARRANTY AND SUPPORT

This product comes with a **2-year manufacturer's warranty**. For warranty claims or technical support, please contact Lighting EVER customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

For more information, visit the [Lighting EVER Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B005FEGYJC>

More documents and user manuals: <https://manuals.plus/>