

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Rockland](#) /

› Rockland Double Handle Rolling Backpack Instruction Manual

Rockland B005FKVEN2

Rockland Double Handle Rolling Backpack Instruction Manual

MODEL: B005FKVEN2

Product Overview

The Rockland Double Handle Rolling Backpack is designed for versatile use, offering both the convenience of a rolling bag and the portability of a backpack. Constructed from durable polyester, it features multiple compartments for organized storage, including two zippered front pockets (one with an organizer), a spacious main compartment, and two mesh side pockets. The bag is equipped with double skate wheels and a telescoping pull handle for easy transport, along with padded shoulder straps for comfortable carrying.





Image: Rockland Double Handle Rolling Backpack (Black Dot) with its telescopic handle extended.

Key Features:

- Dimensions: 12.5"L x 10"W x 19.5"H (with wheels)
- Double In-Line Skate Wheels
- Front Pocket with Built-in Organizer
- Two Mesh Side Pockets
- Padded Shoulder Straps
- Telescopic Extendable Handle
- Durable Polyester Material

Initial Setup

Extending the Telescopic Handle:

1. Locate the button on the top of the telescopic handle.
2. Press and hold the button.
3. Gently pull the handle upwards until it locks into your desired extended position.
4. Release the button to secure the handle.

Adjusting Shoulder Straps:

- To use as a backpack, pull the padded shoulder straps out from their storage compartment (located behind the back panel).
- Adjust the strap length using the buckles at the bottom to achieve a comfortable fit.
- When not in use, the shoulder straps can be tucked back into the compartment to prevent dragging or damage while rolling.

Operating Instructions

Using the Rolling Function:

- Extend the telescopic handle to a comfortable height.
- Tilt the backpack slightly so that the double skate wheels are in contact with the ground.
- Pull the backpack along behind you. The wheels are designed for smooth movement on various surfaces.

Using the Backpack Function:

- Ensure the telescopic handle is fully retracted and secured.
- Pull out and adjust the padded shoulder straps.
- Place the backpack on your back, ensuring even weight distribution for comfort.

Care and Maintenance

Cleaning:

- For general cleaning, wipe the exterior with a damp cloth and mild soap.
- Do not machine wash or tumble dry, as this may damage the material and structural components.
- Allow the backpack to air dry completely before storing.

Wheels and Zippers:

- Periodically check the wheels for any debris or hair that may hinder smooth rolling. Clean as needed.
- Lubricate zippers with a silicone-based spray if they become stiff.
- Avoid overfilling pockets to prevent stress on zippers.

Troubleshooting

Telescopic Handle Issues:

- **Handle not extending/retracting smoothly:** Check for any obstructions in the telescopic tubes.

Ensure the release button is fully depressed when adjusting.

Wheel Issues:

- **Wheels not rolling smoothly:** Inspect wheels for trapped debris (e.g., hair, lint). Clean the wheel axles if necessary.

Zipper Issues:

- **Zipper sticking or difficult to close:** Apply a small amount of zipper lubricant or graphite from a pencil to the zipper teeth. Avoid forcing the zipper.

Product Specifications



Image: General luggage size guide for travel duration.

Feature	Detail
Model Number	B005FKVEN2
Brand	Rockland
Dimensions (L x W x H)	12"L x 8"W x 20"H
Weight	Not specified in data, typically lightweight for a rolling backpack.
Material Type	Polyester, Metal, Plastic
Wheel Type	In-Line Skate (Double wheels)
Handle Type	Telescopic Extendable Handle
Strap Type	Padded Shoulder Straps (Stretchable)
Capacity	13 Liters (Storage Volume: 20 Liters)
Number of Sections	5
Number of Pockets	3 (External)
Water Resistance Level	Water Resistant
Lock Type	Zipper

Feature	Detail
UPC	675478701010

Warranty & Support

This Rockland Double Handle Rolling Backpack comes with a **5-year manufacturer warranty**, covering defects in materials and workmanship under normal use. For warranty claims, product support, or additional information, please visit the official Rockland Store or contact their customer service.

Official Rockland Store: [Rockland Store on Amazon](#)