

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Marley](#) /
- › [House of Marley Exodus On-Ear Headphones Instruction Manual](#)

Marley EM-FH003-HA

House of Marley Exodus On-Ear Headphones

INSTRUCTION MANUAL - MODEL: EM-FH003-HA

Introduction

Thank you for choosing the House of Marley Exodus On-Ear Headphones. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your headphones. Designed with FSC-certified Beechwood, recycled aluminum, and ultra-soft leather, these headphones deliver a high-quality audio experience with an integrated microphone and three-button remote for convenient control.



Image: The House of Marley Exodus On-Ear Headphones shown alongside their protective carrying case.

What's in the Box

Please ensure all the following components are present in your package:

- House of Marley Exodus On-Ear Headphones
- 4ft Braided Audio Cable with Integrated Microphone and Three-Button Remote
- Storage/Carry Case



Image: The Exodus headphones and their durable canvas carrying case, designed for protection and portability.



Image: The retail packaging for the House of Marley Exodus On-Ear Headphones, highlighting key features and design.

Setup

1. **Connect the Audio Cable:** Insert the 3.5mm audio jack of the braided cable into the audio port on your headphones. Then, connect the other end of the cable to the 3.5mm audio output on your device (smartphone, tablet, computer, etc.).



Image: A close-up view of the L-shaped 3.5mm audio jack, featuring a braided cable for durability.

2. **Adjust for Fit:** Place the headphones on your head. The ear cushions are designed for comfort and a proper fit. Adjust the headband as needed to ensure the earcups sit comfortably over your ears. The headband features a flexible design for adaptability.

Operating Instructions

Your House of Marley Exodus headphones feature an integrated microphone and a three-button remote for convenient control of your audio and calls.



Image: The inline three-button remote control and microphone, integrated into the braided audio cable.

Music Control:

- **Play/Pause:** Press the center button once.
- **Next Track:** Press the center button twice quickly.
- **Previous Track:** Press the center button three times quickly.

Call Control:

- **Answer/End Call:** Press the center button once during an incoming call or an active call.
- **Decline Call:** Press and hold the center button during an incoming call.

Volume Control:

- Use the '+' and '-' buttons on the remote to adjust the volume. *Note: Volume control functionality may vary depending on your device's operating system and specific model. Some Android devices may have limited or no volume control via the inline remote.*

Maintenance

Proper care will extend the life and performance of your headphones.

- **Cleaning Ear Cushions:** Gently wipe the ear cushions with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Cleaning Headband:** For the leather headband, use a soft, dry cloth. If necessary, a slightly damp cloth can be used, followed by immediate drying.
- **Cable Care:** Avoid sharp bends or excessive pulling on the braided cable. When storing, coil the cable loosely.
- **Storage:** When not in use, store your headphones in the provided storage/carry case to protect them from dust, scratches, and impacts.
- **Environmental Conditions:** Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight for prolonged periods.

Troubleshooting

If you encounter issues with your headphones, please refer to the following common solutions:

Problem	Possible Cause	Solution
No sound or low volume	Loose cable connection, device volume too low, incorrect audio output selected on device.	Ensure the 3.5mm audio cable is securely plugged into both the headphones and your audio device. Increase the volume on your audio device. Check your device's audio settings to confirm the correct output is selected.
Poor sound quality (distortion, static)	Damaged cable, dirty audio jack, low-quality audio source.	Inspect the audio cable for any visible damage. Clean the 3.5mm audio jack on both the headphones and your device. Try a different audio source or device to isolate the issue.

Problem	Possible Cause	Solution
Microphone not working	Loose cable connection, device microphone settings, incompatible device.	Ensure the audio cable is fully inserted. Check your device's settings to ensure the external microphone is enabled and selected. Some older devices may not fully support inline microphone functionality.
Headphones are uncomfortable	Improper fit, prolonged use.	Adjust the headband to find a more comfortable position. Take breaks during extended listening sessions. The ear cushions are designed to be comfortable, but individual comfort may vary.

Specifications

Model Name	Exodus
Model Number	EM-FH003-HA
Connectivity Technology	Wired
Audio Driver Type	40mm Dynamic Drivers
Earpiece Shape	On-Ear
Hardware Interface	3.5mm Audio Jack
Control Type	Remote (Three-Button)
Special Feature	Microphone Included
Material	Aluminum, FSC-certified Beechwood, Leather
Item Weight	1 Pound
Product Dimensions	10.2 x 8.62 x 9 inches
Compatible Devices	Laptops, Desktops, Telephones, Smartphones

Warranty and Support

For warranty information and customer support, please refer to the official House of Marley website or contact their customer service directly. Details regarding warranty periods and service procedures are typically provided with your purchase documentation or on the manufacturer's website.