



Manuals.plus /

- › Breil /
- › Breil Women's Watch BW0290 User Manual

Breil BW0290

Breil Women's Watch BW0290 User Manual

Model: BW0290

INTRODUCTION

This manual provides essential instructions for the proper use, setup, and maintenance of your Breil Women's Watch, model BW0290. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

PRODUCT OVERVIEW

The Breil BW0290 is an elegant women's wristwatch featuring a gold-tone finish and a black dial with Roman numerals. It includes a date display and is designed for daily wear.



Image 1: Front view of the Breil BW0290 watch, showcasing its gold-tone case, black dial with Roman numerals, and date window.



Image 2: Angled view of the Breil BW0290 watch, highlighting the textured bracelet and the detailing around the watch face.

SETUP

Setting the Time

1. Pull the crown (the small knob on the side of the watch) out to position 2.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown back into position 1 (normal operating position) to start the watch.

Setting the Date

1. Pull the crown out to position 1 (first click).
2. Turn the crown clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.

3. Once the correct date is displayed, push the crown back into the normal operating position.

OPERATING

Wearing Your Watch

Ensure the watch is worn comfortably on your wrist. The bracelet can be adjusted by a professional jeweler if needed to ensure a proper fit.

Water Resistance

This watch is generally designed for everyday use and can withstand splashes or brief immersion. However, it is not suitable for swimming or diving. Always ensure the crown is fully pushed in to maintain water resistance.

MAINTENANCE

Cleaning

Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and dirt. For more thorough cleaning, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops or the second hand begins to jump erratically (if applicable), the battery may need replacement. It is recommended to have the battery replaced by a qualified watchmaker to ensure proper sealing and function.

Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. The original packaging or a watch box is ideal for protection.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is fully pushed in. If it is, the battery may need replacement. Consult a professional watchmaker.
- **Date Not Changing:** Ensure the time is set correctly and the crown is fully pushed in. Avoid setting the date during the night transition hours.
- **Condensation Under Crystal:** This may indicate a loss of water resistance. Avoid further contact with water and have the watch inspected by a professional immediately.

SPECIFICATIONS

Feature	Detail
Model Number	BW0290
Brand	Breil
Movement	Quartz
Display Type	Analog
Case Material	Stainless Steel
Band Material	Stainless Steel
Water Resistance	Splash resistant
Approximate Package Dimensions	11.6 x 10.6 x 8.8 cm
Approximate Package Weight	180 grams

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Breil website or contact your authorized retailer. Keep your proof of purchase for any warranty claims.

Official Breil Website: www.breil.com