

[manuals.plus](#) /› [KitchenAid](#) /› [KitchenAid KHB1231 2-Speed Hand Blender Instruction Manual](#)

KitchenAid KHB1231

KitchenAid KHB1231 2-Speed Hand Blender Instruction Manual

Model: KHB1231ER | Brand: KitchenAid

PRODUCT OVERVIEW

The KitchenAid KHB1231 2-Speed Hand Blender is designed for blending, pureeing, and crushing ingredients with ease. Its compact design and simple operation make it a versatile tool for various kitchen tasks. The removable blending arm ensures quick and easy cleanup.



Image: The KitchenAid KHB1231 2-Speed Hand Blender disassembled, showing the motor body, blending arm with fixed blade, and 3-cup BPA-free blending jar with lid.

SETUP AND ASSEMBLY

- 1. Unpack Components:** Carefully remove all parts from the packaging. Ensure you have the motor body, blending arm with fixed blade, and 3-cup BPA-free blending jar with lid.
- 2. Attach Blending Arm:** Align the blending arm with the motor body. Twist the blending arm gently until it clicks into place.

securely into place. Ensure it is firmly attached before use.

3. **Prepare Ingredients:** Place ingredients into the 3-cup blending jar or another suitable container. For best results, ensure liquids cover the blade assembly.



Image: The KitchenAid KHB1231 Hand Blender assembled and ready for use, positioned next to its 3-cup blending jar.

OPERATING INSTRUCTIONS

1. **Plug In:** Connect the hand blender to a standard 120-volt electrical outlet.
2. **Select Speed:** The hand blender features two-speed settings. Press the top button for low speed or the bottom button for high speed. The motor will only run while the button is actively pressed, providing a safety feature.
3. **Begin Blending:** Immerse the blending arm into the ingredients. Press and hold the desired speed button to begin blending. Move the blending arm up and down gently to ensure all ingredients are processed evenly.
4. **Stop Blending:** Release the speed button to stop the blender.



Image: The KitchenAid KHB1231 Hand Blender in action, pureeing soup directly in a pot, demonstrating its immersion capability.



Image: The KitchenAid KHB1231 Hand Blender blending guacamole in its measuring cup, showcasing its versatility for dips and sauces.

CARE AND MAINTENANCE

- 1. Unplug Before Cleaning:** Always unplug the hand blender from the power outlet before cleaning any parts.
- 2. Detach Blending Arm:** Twist the blending arm to detach it from the motor body.
- 3. Dishwasher Safe Parts:** The removable blending arm, 3-cup BPA-free blending jar, and its lid are dishwasher safe (top rack recommended).
- 4. Clean Motor Body:** The motor body should be wiped clean with a damp cloth. Do NOT immerse the motor body in water or any other liquid.
- 5. Storage:** Store the hand blender and its accessories in a dry place. The blending arm can be detached for compact storage.

TROUBLESHOOTING

- Blender Not Turning On:** Ensure the unit is securely plugged into a working electrical outlet. Confirm that the

blending arm is correctly attached to the motor body. The blender operates only when the speed button is continuously pressed.

- **Blending Arm Detaches During Use:** Ensure the blending arm is twisted firmly into place until it clicks. Improper attachment can cause it to loosen during operation.
- **Ineffective Blending:** Ensure the ingredients are adequately covered by liquid for optimal blending. For thicker mixtures, use the high-speed setting and move the blending arm up and down to circulate ingredients.

SPECIFICATIONS

- **Brand:** KitchenAid
- **Model:** KHB1231ER
- **Color:** Empire Red
- **Special Feature:** Manual
- **Capacity:** 0.7 Liters (3-Cup Blending Jar)
- **Product Dimensions:** 2.3"D x 2.3"W x 15.7"H
- **Included Components:** Hand Blender, 3-Cup BPA-Free Blending Jar with Lid
- **Power Source:** Corded Electric
- **Number of Speeds:** 2
- **Voltage:** 120 Volts
- **Material Type Free:** BPA Free
- **Blade Material:** Stainless Steel
- **Item Weight:** 2 pounds

WARRANTY INFORMATION

For detailed warranty information, please refer to the warranty card included with your product or visit the official KitchenAid website. Warranty terms and conditions may vary by region and product.

CUSTOMER SUPPORT

Should you require assistance, have questions about your KitchenAid KHB1231 2-Speed Hand Blender, or need to order replacement parts, please contact KitchenAid customer service. You can find contact details and support resources on the official KitchenAid website or through the contact information provided in your product packaging.
