

Logitech 981-000341

Logitech H600 Wireless Headset User Manual

Model: 981-000341

INTRODUCTION

This manual provides comprehensive instructions for the Logitech H600 Wireless Headset. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. The Logitech H600 is a lightweight, portable wireless headset designed for clear audio communication and listening, featuring laser-tuned drivers, a 10-meter wireless range, and a 6-hour rechargeable battery.

WHAT'S IN THE BOX

The Logitech H600 Wireless Headset package includes the following components:

- Logitech H600 Wireless Headset
- USB Nano Receiver
- USB Charging Cable
- User Documentation (this manual)

PRODUCT OVERVIEW

Familiarize yourself with the components and features of your Logitech H600 Wireless Headset.



Figure 1: Front view of the Logitech H600 Wireless Headset, showing the adjustable headband, foam earcups, and the microphone boom extended.



Figure 2: The Logitech H600 Wireless Headset with its flexible microphone boom rotated upwards and tucked away, indicating its portability and ease of storage.



Figure 3: Illustration of the Logitech H600's microphone articulation, showing its range of motion for optimal positioning during calls.



Figure 4: The Logitech H600 Wireless Headset folded compactly, demonstrating its design for easy storage and transport.



Figure 5: Rear view of the Logitech H600 Wireless Headset, highlighting the headband and earcups from behind.



Figure 6: A user wearing the Logitech H600 Wireless Headset while using a laptop, illustrating its comfortable fit and practical use in a home environment.

SETUP

Follow these steps to set up your Logitech H600 Wireless Headset for the first time.

1. **Charge the Headset:** Connect the USB charging cable to the headset's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). Allow the headset to fully charge before first use. The charging indicator light will provide status. A full charge provides approximately 6 hours of battery life.
2. **Insert the USB Nano Receiver:** Locate the tiny USB Nano receiver. Plug this receiver into an available USB port on your computer. The receiver is designed to be left in your computer for convenience.
3. **Power On the Headset:** Press and hold the Power button on the headset until the indicator light illuminates, indicating it is powered on and attempting to connect.
4. **Pairing:** The headset and the USB Nano receiver should automatically pair. If pairing does not occur, or if you experience connection issues, refer to the Troubleshooting section or visit the Logitech support website for the re-

pairing utility.

5. **Configure Audio Settings:** On your computer, ensure the Logitech H600 Headset is selected as the default audio input (microphone) and output (speakers) device in your operating system's sound settings and within any communication applications (e.g., Skype, Zoom, Microsoft Teams).

OPERATING INSTRUCTIONS

Learn how to use the various functions of your Logitech H600 Wireless Headset.

Controls

- **Power Button:** Press and hold to turn the headset on or off.
- **Volume Controls:** Buttons on the earcup allow you to increase or decrease the audio volume.
- **Mute Button:** A dedicated button on the earcup or microphone boom allows you to mute or unmute the microphone. An audible tone will typically indicate the mute status change.
- **Microphone Boom:** The flexible microphone boom can be adjusted for optimal voice pickup. Rotate it upwards to store it when not in use.

Usage Tips

- **Wireless Range:** The headset operates effectively up to 10 meters (33 feet) from your computer. Performance may vary depending on environmental factors and obstacles.
- **Battery Life:** The integrated rechargeable battery provides up to 6 hours of continuous use. Recharge the headset when the battery low indicator appears or when audio quality degrades.
- **Compatibility:** The headset is compatible with Windows and Mac operating systems, and works with common calling applications such as Skype, Yahoo! Messenger, Gmail, Windows Live Messenger, and AIM.

MAINTENANCE

Proper care and maintenance will extend the life of your Logitech H600 Wireless Headset.

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the headset in a cool, dry place. The headset can be folded for compact storage. The USB Nano receiver can be stored securely within the headset itself for portability.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in constant use.
- **Handle with Care:** While durable, avoid dropping the headset or subjecting it to excessive force, especially the microphone boom and adjustable headband.

TROUBLESHOOTING

If you encounter issues with your Logitech H600 Wireless Headset, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No audio or microphone not working	Headset not powered on, not paired, or incorrect audio settings.	Ensure headset is powered on. Verify the USB Nano receiver is securely plugged in. Check your computer's sound settings to ensure the Logitech H600 is selected as the default playback and recording device. Restart your computer.

Problem	Possible Cause	Solution
Poor audio quality or crackling sound	Out of range, interference, or low battery.	Move closer to the USB Nano receiver. Ensure there are no major obstructions between the headset and receiver. Charge the headset fully. Avoid using near other wireless devices that may cause interference.
Headset not pairing	Pairing issue or driver problem.	Download and run the Logitech re-pairing utility from the official Logitech support website. Ensure the headset is fully charged. Try plugging the USB Nano receiver into a different USB port.
Short battery life	Battery not fully charged or aging battery.	Ensure the headset is charged for the recommended duration (approx. 6 hours for full charge). If the battery life has significantly degraded over time, it may be reaching the end of its lifespan.

SPECIFICATIONS

Detailed technical specifications for the Logitech H600 Wireless Headset.

- **Model Name:** 981-000341
- **Connectivity Technology:** Wireless (USB Nano Receiver)
- **Frequency Response (Headset):** 40Hz - 10KHz
- **Frequency Response (Microphone):** 100Hz - 6.5kHz
- **Input Impedance:** 32 Ohms
- **Wireless Range:** Up to 10 meters (33 feet)
- **Battery Life:** Up to 6 hours (rechargeable Lithium Polymer battery)
- **Controls:** On-earcup controls (Volume, Mute)
- **Microphone:** Noise-cancelling, flexible boom
- **Earcups:** Foam, over-ear design
- **Weight:** Approximately 0.55 Pounds (8.8 ounces)
- **Product Dimensions:** 9.5 x 3 x 7.12 inches (LxWxH)
- **Compatibility:** Windows, Mac, common calling applications







WARRANTY AND SUPPORT

Logitech provides a limited hardware warranty for the H600 Wireless Headset. For detailed warranty information, technical support, or to download the latest drivers and software, please visit the official Logitech support website.

Official Logitech Support: <https://support.logi.com/>

For further assistance, you may also refer to the official User Manual (PDF) available at:

<https://manuals.plus/m/e85acb55379cef9e93d190a9226097cdd23d992b6fe2492759de680708ba840e>

	<p>Logitech Wireless Headset H600 Complete Setup Guide</p> <p>This guide provides complete setup instructions for the Logitech Wireless Headset H600, covering charging, connection, and fitting for optimal audio performance.</p>
	<p>Logitech H600 Wireless Headset Setup Guide</p> <p>This guide provides essential information for setting up and using the Logitech H600 Wireless Headset, including connection instructions, fitting adjustments, and product features for optimal audio experience.</p>
	<p>Logitech G435 Headset Update and Bluetooth Pairing Guide</p> <p>Learn how to update your Logitech G435 headset and pair it with your Nintendo Switch via Bluetooth. This guide provides step-by-step instructions for firmware updates and Bluetooth connectivity.</p>
	<p>Logitech H800 Wireless Headset Quick Start Guide</p> <p>Learn how to set up and use your Logitech H800 Wireless Headset for music, calls, and Bluetooth connectivity. This guide covers features, connection steps, troubleshooting, and battery information.</p>
	<p>Logitech USB Headset H390: Comfortable, Clear Audio for Calls and Entertainment</p> <p>Explore the Logitech USB Headset H390, featuring plush comfort, pure digital stereo sound, and an adjustable noise-cancelling microphone. Ideal for clear voice/video calls, music, and gaming, with easy USB plug-and-play setup and broad OS compatibility.</p>
	<p>Logitech G522 LIGHTSPEED Headset Setup Guide</p> <p>A comprehensive setup guide for the Logitech G522 LIGHTSPEED Headset, covering connection to PC and Bluetooth devices, wired USB audio, resetting and pairing, switching modes, adjusting volume, and muting the microphone.</p>