

[Manuals.plus](#) /

› [THQ](#) /

› uDraw Game Tablet with uDraw Studio: Instant Artist - Instruction Manual

THQ 785138305509

uDraw Game Tablet with uDraw Studio: Instant Artist - Instruction Manual

Model: 785138305509 | Brand: THQ

1. PRODUCT OVERVIEW

The uDraw Game Tablet for Nintendo Wii, bundled with uDraw Studio: Instant Artist, transforms your television into a digital canvas. This innovative peripheral allows users to draw, paint, and create digital art directly on their console. It integrates seamlessly with the Wii Remote, leveraging its motion-sensing capabilities for a unique interactive experience.

Wii™

uDraw

GAMETABLET®



This image displays the uDraw Game Tablet alongside its bundled software, uDraw Studio: Instant Artist. The tablet is black, designed for use with the Nintendo Wii console, and features a drawing surface and integrated controls.

2. GETTING STARTED

2.1 Package Contents

Ensure all components are present before proceeding with setup:

- uDraw Game Tablet (Black)
- uDraw Studio: Instant Artist Game Disc (Nintendo Wii)
- Stylus
- Quick Start Guide (if applicable)

2.2 Connecting the uDraw Game Tablet

Follow these steps to connect your uDraw Game Tablet to your Nintendo Wii console:

1. Ensure your Nintendo Wii console is powered off.
2. Open the battery cover on the back of your Wii Remote (sold separately) and remove the batteries.
3. Carefully slide the Wii Remote into the designated slot on the uDraw Game Tablet. Ensure it clicks securely into place. The tablet draws power directly from the Wii Remote.
4. Replace the battery cover on the Wii Remote, now integrated into the tablet.
5. Connect the stylus to the tablet via its tethered cord.
6. Insert the uDraw Studio: Instant Artist game disc into your Wii console.
7. Power on your Wii console and select the uDraw Studio: Instant Artist game from the Wii Menu.



A detailed view of the uDraw Game Tablet, highlighting the stylus and the dedicated slot for integrating the Wii Remote. This design allows the tablet to draw power from the Wii Remote and utilize its motion-sensing capabilities for interactive drawing and gameplay.

3. OPERATING THE UDRAW GAME TABLET

3.1 Basic Controls

- **Stylus:** Use the stylus to interact with the drawing surface. It is pressure-sensitive, allowing for varied brush styles and line thickness.
- **Tablet Buttons:** The tablet features buttons that mimic the C and Z buttons of the Wii Nunchuk, providing easy operation for intricate movements within the game.
- **Tilt Functionality:** The integrated Wii Remote enables unique tilt movement options. Players can control characters or manipulate elements within the game by tilting the tablet.

3.2 uDraw Studio: Instant Artist Modes

uDraw Studio: Instant Artist offers three primary modes to explore your creativity:

Art School

Guided by the animated host, Remmy, Art School provides interactive tutorials. Start with fundamental drawing techniques and progress through 15 lessons of increasing complexity, building your artistic skills.

Art Camp

Rediscover classic creative activities in Art Camp, such as number painting, dot drawing, and coloring books. This mode offers a relaxed environment for casual artistic expression.

Art Play

Engage in freestyle drawing with an enhanced user interface and a wide array of new tools. Art Play allows for unrestricted creativity, including features like animated stamps and various brush types.

3.3 Saving and Sharing Artwork

Artwork created in uDraw Studio: Instant Artist can be saved. The game supports saving masterpieces to an SD card (not included) inserted into the Wii console, allowing for easy sharing and transfer of your creations.

4. CARE AND MAINTENANCE

Proper care ensures the longevity and optimal performance of your uDraw Game Tablet:

- **Cleaning:** Use a soft, dry cloth to clean the tablet surface and stylus. Avoid abrasive cleaners or solvents.

- **Storage:** Store the tablet and stylus in a cool, dry place away from direct sunlight and extreme temperatures. The tablet features a convenient storage area for the wrist strap and stylus.
- **Stylus Care:** Do not apply excessive force to the stylus tip. Ensure the stylus is properly stored in its designated slot when not in use to prevent damage.
- **Wii Remote:** When not in use for extended periods, it is recommended to remove the Wii Remote from the tablet to conserve its battery life, although the tablet itself does not drain the Wii Remote's battery when disconnected.

5. TROUBLESHOOTING

If you encounter issues with your uDraw Game Tablet, refer to the table below for common problems and their solutions:

Problem	Solution
Tablet not responding.	Ensure the Wii Remote is securely inserted into the tablet and that its batteries are charged. Re-sync the Wii Remote with the console if necessary.
Stylus not drawing or inconsistent lines.	Check that the stylus is properly connected to the tablet. Ensure the drawing surface is clean and free of debris. Recalibrate the stylus within the game settings if available.
Game disc not loading.	Clean the game disc with a soft cloth. Ensure the Wii console's disc drive is functioning correctly.
Tilt controls are inaccurate.	Recalibrate the Wii Remote and tablet's motion sensors through the Wii console's system settings or within the game's options. Ensure no strong magnetic fields are nearby.

6. TECHNICAL SPECIFICATIONS

- **Model Number:** 785138305509
- **Brand:** THQ
- **Dimensions:** 7.7 x 10.9 x 2.5 inches
- **Weight:** 1.4 pounds
- **Compatibility:** Nintendo Wii
- **Release Date:** November 15, 2011

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This product is covered by a limited manufacturer's warranty. Please refer to the original product packaging or the official THQ website for detailed warranty terms and conditions. Keep your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting, or product inquiries, please visit the official THQ support website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's official website.

