

## Nerf 36056-TRU

# Nerf Walkie Talkie Instruction Manual

Model: 36056-TRU | Brand: Nerf

## INTRODUCTION

The Nerf Walkie Talkie set provides a fun and effective way for kids to communicate over distances up to 1000 feet. Designed for rugged outdoor play, these walkie-talkies are perfect for adventures in the park, woods, or during camping trips. They feature a simple push-to-talk operation and even include a Morse code button for alternative communication.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your Nerf Walkie Talkies to ensure optimal performance and enjoyment.

## SETUP

### Battery Installation

Each Nerf Walkie Talkie requires one 9V battery (not included). A Phillips head screwdriver is needed to open the battery compartment.

1. Locate the battery compartment on the back of the walkie-talkie.
2. Using a Phillips head screwdriver, unscrew the small screw securing the battery compartment cover.
3. Carefully remove the cover.
4. Insert one 9V battery, ensuring the polarity (+/-) matches the diagram inside the compartment.
5. Replace the battery compartment cover and secure it with the screw. Do not overtighten.





Figure 1: Rear view showing the battery compartment and belt clip.

## OPERATING INSTRUCTIONS

**Power On/Off**

To turn the walkie-talkie ON or OFF, locate the power switch on the right side of the device. Slide the switch to the 'ON' position to power on, and to the 'OFF' position to power off.






Figure 2: Side view highlighting the On/Off switch.

### Communication (Push-to-Talk)

To speak to another walkie-talkie user:

1. Ensure both walkie-talkies are powered ON.
2. Press and hold the large orange Push-to-Talk (PTT) button located on the left side of the walkie-talkie.
3. Speak clearly into the speaker grille on the front of the walkie-talkie.
4. Release the PTT button when you are finished speaking to allow the other person to respond.





Figure 3: Side view highlighting the Push-to-Talk button.

## Morse Code Function

The walkie-talkies include a Morse code button for sending coded messages.

- Press the circular button on the front of the walkie-talkie to activate the Morse code beeps.
- Use short and long presses to create Morse code signals.





Figure 4: Front view showing the Morse code button.

## Range

The Nerf Walkie Talkies have a maximum talking range of approximately 1000 feet (305 meters) in open outdoor environments. Obstacles such as buildings, trees, and terrain can reduce the effective range.

## MAINTENANCE

- **Cleaning:** Wipe the walkie-talkies with a dry, soft cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place away from direct sunlight.
- **Durability:** The rugged sports design of these walkie-talkies makes them durable for active play. However, avoid excessive force or dropping them from significant heights to prevent damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power / Not turning on	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh 9V batteries.
Static or unclear sound	Out of range, interference, or low battery.	Move closer to the other walkie-talkie. Avoid areas with strong electronic interference. Replace batteries.
Cannot transmit or receive	PTT button not pressed/released correctly, or power is off.	Ensure the PTT button is held down while speaking and released to listen. Verify both units are powered on.
Morse code button not working	Low battery or internal issue.	Replace batteries. If the issue persists, contact customer support.

## SPECIFICATIONS

**Product Dimensions:** 8 x 11.5 x 2 inches

**Item Weight:** 8.8 ounces

**Model Number:** 36056-TRU

**Manufacturer Recommended Age:** 6 - 9 years

**Batteries:** 1 x 9V battery per unit (not included)

**Brand:** Nerf

**Manufacturer:** Sakar

**Number of Channels:** 8

**Special Feature:** Long Range

**Talking Range Maximum:** 1000 Feet

**Tuner Technology:** UHF

**Water Resistance Level:** Water Resistant

## WARRANTY AND SUPPORT

Sakar International, the manufacturer of Nerf Walkie Talkies, prides itself on providing high-quality products. For any issues or inquiries regarding your product, please refer to the manufacturer's website or contact their customer support directly.

You may also find additional information and a downloadable user manual in PDF format at the following link [User Manual \(PDF\)](#)