

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [WOFI](#) /
- › [WOFI 992910060000 LED RGB Ceiling Light User Manual](#)

## WOFI 992910060000

# WOFI 992910060000 LED RGB Ceiling Light User Manual

Model: 992910060000

[Introduction](#)   [Safety Instructions](#)   [Package Contents](#)   [Setup & Installation](#)   [Operation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for purchasing the WOFI 992910060000 LED RGB Ceiling Light. This modern ceiling fixture combines nine G4 halogen bulbs with integrated RGB LEDs, offering both functional illumination and atmospheric color-changing effects. This manual provides essential information for safe installation, operation, and maintenance of your new lighting product. Please read it thoroughly before use and retain it for future reference.



Figure 1: WOFI 992910060000 LED RGB Ceiling Light showcasing its color-changing capabilities. The fixture features a square glass base with nine crystal-like light elements.

## 2. SAFETY INSTRUCTIONS

---

Always observe the following safety precautions to prevent injury or damage to the product:

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Ensure the main power supply is switched off at the circuit breaker before installation, maintenance, or bulb replacement.
- **Handling:** Handle the product with care. The glass components are fragile.
- **Environment:** This product is designed for indoor use only (IP20 rating). Do not expose it to moisture, direct water spray, or extreme temperatures.
- **Bulb Type:** Use only G4 halogen bulbs as specified. Do not exceed the maximum wattage.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Avoid abrasive cleaners or solvents.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- WOFI 992910060000 Ceiling Light Fixture (Metal base, glass plate, 9 light elements)
- 9 x G4 Halogen Bulbs
- Remote Control (with batteries included)
- Mounting Hardware (screws, wall plugs)
- Instruction Manual (this document)

## 4. SETUP & INSTALLATION

---

Follow these steps for proper installation:

### 1. Prepare for Installation:

- Switch off the main power supply at the circuit breaker to the room where the light will be installed.
- Ensure the mounting surface is suitable to support the weight of the fixture (approximately 4.97 kg).

### 2. Mount the Fixture Base:

- Carefully remove the glass plate from the metal base if it's pre-assembled.
- Position the metal base against the ceiling at the desired location. Mark the drilling points for the mounting screws.
- Drill holes at the marked points and insert appropriate wall plugs.
- Secure the metal base to the ceiling using the provided screws.

### 3. Electrical Connection:

- Connect the household electrical wires to the terminal block on the fixture base. Ensure correct polarity (Live, Neutral, Earth). If unsure, consult a qualified electrician.
- Double-check all connections for security.

### 4. Install Bulbs and Glass Elements:

- Insert the 9 G4 halogen bulbs into their respective sockets on the fixture. Avoid touching the glass of the bulbs directly with bare hands; use a clean cloth or gloves.
- Carefully attach the crystal-like light elements over each bulb.
- Reattach the glass plate to the metal base, securing it firmly but gently.

### 5. Final Check:

- Ensure all components are securely fastened.
- Restore power at the circuit breaker.
- Test the light fixture.



**ACTION**

992910060000



Diese Leuchte enthält eingebaute LED-Lampen und hat Fassungen für Leuchtmittel der Energieklassen:

A<sup>++</sup>

A<sup>+</sup>

A


~~B~~

C

D

E

} LED

} 

Diese Leuchte wird verkauft mit einem Leuchtmittel der Energieklasse:

C

874/2012



Figure 2: Detail view of the individual light elements and their arrangement on the glass plate.

## 5. OPERATION

The WOFI 992910060000 ceiling light can be operated using the included remote control.

### 5.1. Remote Control Functions

The remote control allows you to switch the light on/off, adjust the halogen brightness, and control the RGB LED color-changing features.

- **ON/OFF:** Press the power button to turn the light fixture on or off.

- **Halogen Light:** Dedicated buttons may control the G4 halogen bulbs, typically for standard white illumination.
- **RGB LED Control:**
  - **Color Selection:** Buttons for specific colors (e.g., Red, Green, Blue) or a color wheel/cycle button to change the LED color.
  - **Mode Selection:** Buttons for different lighting modes (e.g., static color, fade, flash).
  - **Brightness Adjustment:** Buttons to increase or decrease the intensity of the RGB LEDs.

Refer to the remote control's specific button layout for detailed functions. Ensure the remote control batteries are correctly inserted.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling light.

### 6.1. Cleaning

- Always switch off the power supply at the circuit breaker before cleaning.
- Use a soft, dry, lint-free cloth to wipe the metal and glass surfaces.
- For stubborn marks on glass, a slightly damp cloth with mild glass cleaner can be used, followed by a dry wipe. Avoid spraying cleaner directly onto the fixture.
- Do not use abrasive cleaners, scouring pads, or chemical solvents, as these can damage the finish.

### 6.2. Bulb Replacement

- Ensure the power is off and the bulbs have cooled down completely before attempting replacement.
- Carefully remove the glass light element covering the bulb.
- Gently pull out the old G4 halogen bulb.
- Insert a new G4 halogen bulb of the same wattage. Avoid touching the new bulb's glass with bare hands.
- Reattach the glass light element.

## 7. TROUBLESHOOTING

If you encounter issues with your WOFI ceiling light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Faulty bulb(s). Loose wiring connection.	Check circuit breaker. Replace faulty G4 bulbs. Consult an electrician to check wiring.
Remote control not working.	Dead batteries. Remote not aimed correctly. Obstruction between remote and receiver.	Replace remote control batteries. Aim remote directly at the light fixture. Remove any obstructions.
RGB LEDs not changing color.	Incorrect remote command. Internal LED fault.	Ensure correct buttons are pressed. If problem persists, contact customer support.

Problem	Possible Cause	Solution
Light flickers.	Loose bulb. Unstable power supply. Faulty dimmer switch (if applicable).	Ensure bulbs are securely seated. Consult an electrician. Ensure dimmer is compatible or remove it.

## 8. SPECIFICATIONS

Feature	Detail
<b>Model Number</b>	992910060000
<b>Brand</b>	WOFI
<b>Manufacturer</b>	ACTION by WOFI
<b>Dimensions (L x W x H)</b>	35.99 x 35.99 x 10.01 cm
<b>Weight</b>	4.97 kg
<b>Material</b>	Metal, Glass
<b>Color</b>	White (fixture base), RGB (LEDs)
<b>Number of Bulbs</b>	9
<b>Bulb Type</b>	G4 Halogen (included)
<b>Integrated Lighting</b>	RGB LEDs
<b>Voltage</b>	1 Voltios ( <i>Note: This value appears to be an error in the source data. Standard mains voltage for ceiling lights in Europe is typically 220-240V.</i> )
<b>Total Electrical Power</b>	189 Watts (Includes 9 x G4 Halogen bulbs and integrated LEDs)
<b>Halogen Bulb Power</b>	9 x 20W G4 (180 Watts total)
<b>IP Rating</b>	IP20 (Indoor use only)
<b>Batteries Included</b>	Yes (for remote control)
<b>Energy Efficiency Class</b>	C (for included light source)



Figure 3: Energy efficiency label for the WOFI 992910060000 ceiling light, indicating built-in LED lamps and an included light source of energy class C.

## 9. WARRANTY & SUPPORT

---

For warranty information and customer support, please refer to the documentation provided with your purchase or contact WOFI customer service directly. Keep your proof of purchase for any warranty claims.

### **WOFI Customer Service:**

- Website: [www.wofi.de](http://www.wofi.de) (Please check for local contact information)
- Contact details may vary by region.