

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bulova](#) /

› [Bulova Cambria Mantel Clock with Westminster Chime \(Model B1765\) Instruction Manual](#)

Bulova B1765

Bulova Cambria Mantel Clock (Model B1765) Instruction Manual

Your guide to setup, operation, and care.

PRODUCT OVERVIEW

The Bulova Cambria Mantel Clock (Model B1765) is a classic timepiece designed to enhance any living space. It features a solid wood and wood veneer case with an antique walnut finish, a two-tone metal dial, and a protective glass lens. This clock is equipped with a quartz, battery-operated movement and plays the Westminster melody on the hour.



Front view of the Bulova Cambria Mantel Clock, highlighting its elegant design and detailed dial.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the clock. This is typically covered by a small panel.
2. Remove the battery compartment cover.
3. Insert one (1) AA battery into the clock movement compartment, observing the correct polarity (+/-).
4. If your model includes a chime function, insert two (2) additional AA batteries into the separate chime unit compartment, observing the correct polarity (+/-).
5. Replace the battery compartment cover securely.

2. Setting the Time

1. Turn the time-setting knob, usually located on the back of the clock movement, clockwise to advance the hands to the correct time.
2. Ensure the minute hand is aligned precisely with the minute markers for accurate timekeeping.

OPERATING INSTRUCTIONS

Chime Function (Westminster Melody)

The Bulova Cambria Mantel Clock features a Westminster melody that plays on the hour. Some models may offer additional chime options or settings.

- **Hourly Chime:** The clock will play the full Westminster melody at the top of each hour.
- **Night Shut-off:** Some models may include an automatic night shut-off feature, typically from 11:00 PM to 5:45 AM, to prevent chimes during sleeping hours. Refer to your specific model's controls for this feature.
- **Volume Control:** A volume control dial or switch may be present on the back of the clock or the chime unit to adjust the loudness of the melody.
- **Chime On/Off:** A switch is usually available to turn the chime function completely off if desired.

MAINTENANCE

Cleaning

- Wipe the wooden case with a soft, dry cloth. Avoid using abrasive cleaners or polishes that may damage the finish.
- For the glass lens, use a soft, lint-free cloth and a mild glass cleaner. Spray the cleaner onto the cloth, not directly onto the clock.

Battery Replacement

Replace batteries annually or when the clock begins to lose time or the chime weakens. Always use fresh, high-quality AA batteries.

1. Follow the battery installation steps in the Setup section.
2. Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

- **Clock Not Keeping Time:** Ensure batteries are fresh and correctly installed. Check that the time-setting knob is not loose.
- **Chime Not Sounding:** Verify that the chime batteries are fresh and correctly installed. Check if the chime function is turned on and not in night shut-off mode. Ensure the volume is not set to minimum.
- **Irregular Chime:** This may indicate low chime battery power. Replace the chime batteries.

SPECIFICATIONS

Brand	Bulova
Model Number	B1765
Dimensions (H x W x D)	7.75 inches x 12 inches x 3.25 inches
Case Material	Solid wood and wood veneer
Finish	Antique Walnut
Dial Type	Two-tone metal, Analog
Lens Material	Protective glass
Movement Type	Quartz
Power Source	Battery Powered (AA batteries)
Chime Type	Westminster melody on the hour

WARRANTY INFORMATION

This Bulova clock comes with a limited warranty. For specific details regarding coverage, duration, and claims, please refer to the warranty card included with your purchase or visit the official Bulova website.

SUPPORT

For further assistance, technical support, or inquiries about your Bulova Cambria Mantel Clock, please contact Bulova customer service through their official website or the contact information provided in your product packaging.

