

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Craftmade](#) /

> [Craftmade K10743 Piccolo 30-inch Outdoor Ceiling Fan User Manual](#)

Craftmade K10743

Craftmade K10743 Piccolo 30-inch Outdoor Ceiling Fan User Manual

Model: K10743

INTRODUCTION

This manual provides comprehensive instructions for the safe installation, efficient operation, and proper maintenance of your Craftmade K10743 Piccolo 30-inch Outdoor Ceiling Fan. Please read all instructions carefully before beginning installation or use to ensure optimal performance and safety.

SAFETY INFORMATION

- Always disconnect power at the circuit breaker before installing, cleaning, or servicing the fan.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electrical Code (NEC).
- The fan is cULus listed, indicating compliance with safety standards for use in damp locations.
- **California Proposition 65 Warning:** This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.
- Always check your local laws and regulations regarding product installation and usage.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Craftmade Piccolo Ceiling Fan in White (Model K10743)
- 30-inch Piccolo White ABS Blades (5 blades included)
- Mounting hardware and accessories (check packaging for full list)

SETUP AND INSTALLATION

This ceiling fan is designed for outdoor usage and features a downrod mounting type. Professional installation is recommended.

1. **Preparation:** Ensure the mounting location is structurally sound and can support the fan's weight. Turn off

power at the main circuit breaker.

2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling joist or an approved outlet box.
3. **Downrod Assembly:** Attach the downrod to the fan motor assembly.
4. **Wiring:** Connect the fan's electrical wires to the household wiring (120 Volts, US style plug format) according to the wiring diagram provided in the separate installation guide (not included in this manual). Ensure all connections are secure.
5. **Fan Assembly:** Carefully lift the fan assembly and hang it on the mounting bracket.
6. **Blade Attachment:** Securely attach the five ABS blades to the fan motor.
7. **Final Checks:** Double-check all connections and ensure the fan is securely mounted before restoring power.



Image: The Craftmade K10743 Piccolo 30-inch Outdoor Ceiling Fan installed in a laundry room, showcasing its compact design and white finish. The fan is mounted on the ceiling, with its pull chain visible, above a white door.

OPERATING INSTRUCTIONS

The Craftmade K10743 Piccolo fan is operated using a pull chain mechanism, offering three distinct power levels.

1. **Turning On/Off:** Pull the chain once to turn the fan on to its highest speed. Pulling the chain again will cycle through the speeds and eventually turn the fan off.
2. **Adjusting Speed:** The fan has 3 power levels. Each pull of the chain will cycle the fan through these speeds (High, Medium, Low) and then off.
3. **Directional Control:** Locate the directional switch on the fan motor housing (if present). Slide the switch to change the blade rotation direction for summer (downward airflow) or winter (upward airflow) operation.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.

- **Blade Balance:** If the fan wobbles, check that all blades are securely fastened and balanced. A balancing kit (sold separately) may be used if necessary.
- **Tighten Fasteners:** Annually, check and tighten all screws and fasteners on the fan assembly and mounting bracket.
- **Motor Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING

If your fan is not operating correctly, consult the following common issues before contacting customer support:

- **Fan Does Not Start:**
 - Check that the power supply is turned on at the circuit breaker.
 - Ensure all electrical connections are secure.
 - Verify the pull chain is fully engaged.
- **Fan Wobbles:**
 - Confirm all blade screws are tight.
 - Check that the downrod is securely fastened to the mounting bracket and motor.
 - Ensure blades are not bent or damaged.
- **Noisy Operation:**
 - Check for loose screws on the motor housing or blades.
 - Ensure the fan is not touching any part of the ceiling or wall.

SPECIFICATIONS

Brand	Craftmade
Model Number	K10743
Size	30 inches (Cutting Diameter, Assembled Diameter)
Color	White-white Blades
Electric Fan Design	Ceiling Fan
Power Source	Corded Electric
Style	Traditional
Room Type	Outdoor (Suitable for damp locations like laundry rooms)
Special Feature	Pull Chain
Wattage	46.00 Watts
Finish Type	White
Number of Blades	5
Voltage	120 Volts

Switch Type	Pull Chain
Item Weight	10.89 Pounds
Included Components	Craftmade Piccolo Ceiling Fan in White with 30" Piccolo White Blades (K10743)
Indoor/Outdoor Usage	Outdoor
Specification Met	cULus
Control Method	Pull Chain
Number of Power Levels	3
Material	Acrylonitrile Butadiene Styrene (ABS)
Mounting Type	Downrod
Plug Format	A- US style

WARRANTY INFORMATION

Craftmade provides the following warranty for this product:

- **Replacement Parts Policy:** All products purchased have a 30-day replacement parts policy to ensure a fully working item.
- **Product Warranty:** All products are covered under a 1-Year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped.
- **Coverage:** The warranty covers all items and conditions identified in the original manufacturer's warranty.
- **Exclusions:** Items specifically not covered by the warranty include loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Craftmade customer service. Refer to your product packaging or the official Craftmade website for the most current contact information.

You can also visit the [Craftmade Store on Amazon](#) for more product information.