

[Manuals.plus](#) /

> [Kerbl](#) /

> Kerbl Replacement Net for Outdoor Pet Pen Model 82708

Kerbl 82708-2

Kerbl Replacement Net for Outdoor Pet Pen Model 82708

Brand: Kerbl | Model: 82708-2

1. PRODUCT OVERVIEW

The Kerbl Replacement Net (Model 82708-2) is designed as an accessory for the Kerbl outdoor pet pen, specifically model 82708. This net provides essential shade and enhanced security for small animals housed in the outdoor enclosure. It is made from durable plastic material and features a green and black color scheme.



Image 1: Kerbl outdoor pet pen with the replacement net installed, providing shade for two rabbits.

2. SETUP INSTRUCTIONS

This replacement net is designed for easy attachment to the Kerbl outdoor pet pen model 82708. No complex assembly is required.

1. **Unpack the Net:** Carefully remove the replacement net from its packaging.
2. **Identify Attachment Points:** Locate the attachment points or clips on your Kerbl outdoor pet pen (Model 82708). The net is designed to fit securely over the top of the pen.

3. **Secure the Net:** Drape the net over the top of the pen. Use the integrated fasteners or clips to secure the net firmly to the pen's frame. Ensure all sides are properly attached to prevent gaps.
4. **Check for Security:** Once attached, gently pull on the net to ensure it is securely fastened and cannot be easily dislodged by pets or wind.



Image 2: Detail of the net's material and how it might attach to the pen.

3. OPERATING INSTRUCTIONS (USAGE)

The replacement net serves two primary functions for your outdoor pet pen:

- **Shade Provision:** Position the pen with the net in an area where it can provide adequate shade for your small animals, especially during sunny periods. This helps prevent overheating.
- **Enhanced Security:** The net acts as an additional barrier, preventing pets from escaping and offering protection from potential predators from above.

Ensure the net is always securely fastened when the pen is in use outdoors.

4. MAINTENANCE

Maintaining the Kerbl Replacement Net is straightforward to ensure its longevity and effectiveness.

- **Cleaning:** The net is easy to clean. Use a damp cloth with mild soap and water to wipe away dirt or debris. Rinse thoroughly and allow it to air dry completely before reattaching or storing.
- **Inspection:** Regularly inspect the net for any signs of wear, tears, or damage. Promptly replace the net if significant damage is observed to maintain security and shade.
- **Storage:** When not in use, especially during adverse weather conditions or off-season, remove the net from the pen, clean it, and store it in a dry, protected area to prolong its lifespan.

5. TROUBLESHOOTING

This product is a simple replacement net and typically does not require complex troubleshooting.

- **Net does not fit:** Ensure you have the correct replacement net for your Kerbl outdoor pet pen model 82708. Verify the model number on your pen and the net packaging.
- **Net is damaged:** If the net is torn or has holes, it should be replaced to ensure the safety and containment of your pets.

6. SPECIFICATIONS

Feature	Detail
Brand	Kerbl
Model Number	82708-2
Product Dimensions (L x W x H)	32L x 24B x 3H centimeters
Material	Plastic
Color	Green, Black
Usage	Outdoor
Assembly Required	No (attachment to existing pen)
GTIN	04018653031469
Target Species	Small animals (e.g., rabbits, rodents)

7. WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the original product packaging or contact Kerbl customer service directly.

You can typically find contact details on the official Kerbl website or through your retailer.