



[Manuals.plus](#) /

› [Villeroy & Boch](#) /

› Villeroy & Boch Omnia Toilet Seat 88236101 Instruction Manual

## Villeroy & Boch 88236101

# Villeroy & Boch Omnia Toilet Seat 88236101 Instruction Manual

Model: 88236101

[Introduction](#)   [Safety Information](#)   [Package Contents](#)   [Setup & Installation](#)   [Operation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Villeroy & Boch Omnia Toilet Seat, model 88236101. Please read this manual carefully before installation and use to ensure proper function and longevity of the product. Keep this manual for future reference.



Image 1.1: Villeroy & Boch Omnia Toilet Seat (Model 88236101) in Classic White. This image shows the D-shaped Duroplast seat with stainless steel hinges.

## 2. SAFETY INFORMATION

---

Observe the following safety guidelines to prevent injury or damage to the product:

- Ensure all components are securely fastened during installation. Loose parts can cause instability.
- Do not stand on the toilet seat or lid. This product is designed for sitting only.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the Duroplast material and stainless steel hinges.
- Keep small children away from the toilet seat during installation to prevent accidental injury from tools or small parts.
- The maximum load capacity of the ring seat is 240 kg. Do not exceed this weight.

## 3. PACKAGE CONTENTS

---

Verify that all items listed below are present in the package:

- 1 x Villeroy & Boch Omnia Toilet Seat (Duroplast, Classic White)
- 1 x Set of Stainless Steel Hinges (pre-attached or separate, depending on packaging)
- 1 x Set of Mounting Hardware (bolts, washers, nuts)

## 4. SETUP & INSTALLATION

---

Follow these steps to properly install your Villeroy & Boch Omnia Toilet Seat:

- 1. Preparation:** Ensure the toilet bowl surface is clean and dry. If replacing an old seat, remove it completely and clean any residue from the mounting holes.
- 2. Positioning the Hinges:** Place the toilet seat onto the toilet bowl, aligning the hinge posts with the mounting holes on the ceramic. The hinges are designed for a middle distance of 150 mm.
- 3. Securing the Seat:** Insert the provided bolts through the hinge posts and the mounting holes on the toilet bowl. From underneath the toilet bowl, attach the washers and nuts to the bolts.
- 4. Tightening:** Hand-tighten the nuts first to ensure the seat is centered and aligned. Once properly positioned, use a suitable wrench to firmly tighten the nuts. Do not overtighten, as this can damage the ceramic or the mounting hardware.
- 5. Final Check:** Gently lift and lower the seat and lid to ensure smooth operation and stability. The seat should not wobble or shift.

*Note:* The product includes a fixed hinge made of stainless steel and plastic components for secure attachment.

## 5. OPERATION

The Villeroy & Boch Omnia Toilet Seat is designed for straightforward use. Simply lift the seat or lid to the desired position and lower it gently when finished. Avoid slamming the seat or lid, as this can cause premature wear or damage to the hinges.

## 6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygienic condition of your toilet seat.

- Cleaning:** Use a soft cloth and mild, non-abrasive cleaning agents (e.g., soap and water) to clean the Duroplast surface. Wipe dry with a clean cloth.
- Avoid:** Do not use harsh chemicals, abrasive sponges, or scouring powders, as these can scratch the surface or damage the material.
- Hinges:** Periodically check the stainless steel hinges for any signs of corrosion or looseness. Clean them with a damp cloth and dry thoroughly. If hinges become loose, re-tighten the mounting nuts as described in the installation section.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Toilet seat wobbles or shifts.	Mounting nuts are loose.	Re-tighten the mounting nuts underneath the toilet bowl.
Seat does not stay up.	Hinges may be worn or damaged.	Inspect hinges for damage. If damaged, replacement may be necessary.
Stains on the seat surface.	Improper cleaning agents used or prolonged contact with staining substances.	Clean immediately with a mild soap and water solution. For stubborn stains, a specialized Duroplast cleaner may be used, following product instructions.

## 8. SPECIFICATIONS

<b>Brand:</b>	Villeroy & Boch
<b>Model Number:</b>	88236101
<b>Style:</b>	Classic
<b>Color:</b>	White
<b>Material:</b>	Duroplast
<b>Hinge Material:</b>	Stainless Steel and Plastic
<b>Shape:</b>	D-Shaped
<b>Product Dimensions (L x W):</b>	43.8 cm x 37 cm (16.93"L x 14.57"W)
<b>Middle Distance (Hinges):</b>	150 mm
<b>Item Weight:</b>	7.05 Pounds (approx. 3.2 kg)
<b>Max. Load Capacity (Ring Seat):</b>	240 kg

## 9. WARRANTY AND SUPPORT

This product comes with no manufacturer guarantee as per available information. For any product-related inquiries or support, please contact your retailer or visit the official Villeroy & Boch website for further assistance. You can also visit the [Villeroy & Boch Store on Amazon](#) for more information on their product range.

