

[Manuals.plus](#) /

› [GoodCook](#) /

› GoodCook Deluxe Salad Spinner Model 08242 Instruction Manual

GoodCook 08242

GoodCook Deluxe Salad Spinner Model 08242 Instruction Manual

This manual provides comprehensive guidance for the GoodCook Deluxe Salad Spinner, Model 08242, designed for efficient washing and drying of leafy greens and other produce. Learn about its features, setup, operation, and maintenance for optimal kitchen use.

PRODUCT OVERVIEW

The GoodCook Deluxe Salad Spinner is designed to simplify the process of washing and drying your fresh produce. Its robust construction and thoughtful features ensure clean, crisp greens for your salads.



Image: The GoodCook Deluxe Salad Spinner, fully assembled, showcasing its green lid, clear bowl, and white handle.

COMPONENTS

The GoodCook Deluxe Salad Spinner consists of three main components:

- **Outer Bowl:** A clear, durable 6-quart container with a handle and pour spout.
- **Inner Basket:** A removable green colander basket, designed to hold produce during washing and spinning.
- **Lid:** A green lid with an easy-turn knob for spinning and integrated holes for draining.

Wash, rinse and spin dry lettuce and produce



Image: An exploded view of the salad spinner, showing the clear outer bowl, the green inner basket, and the green lid with its spinning mechanism.

SETUP AND ASSEMBLY

1. Place the green inner basket inside the clear outer bowl.
2. Position the green lid securely on top of the outer bowl, ensuring it aligns with the basket's spinning mechanism.

Your browser does not support the video tag.

Video: An official product video demonstrating the assembly and basic operation of the GoodCook Everyday Salad Spinner.

OPERATING INSTRUCTIONS

Washing Produce:

1. Place your leafy greens, herbs, or other small produce into the inner colander basket.
2. Rinse the produce thoroughly under running water while it is still in the basket. The basket can be used independently as a colander.

Built-in spout & sturdy handle for easy pouring



Image: The green inner basket being used as a colander to rinse strawberries under running water in a sink.

Spinning to Dry:

1. After rinsing, place the inner basket with the wet produce back into the outer bowl.
2. Secure the lid onto the bowl.
3. Hold the outer bowl firmly with one hand and use the easy-turn knob on the lid to spin the inner basket. Spin for several seconds until excess water is removed.

Non-slip spinning knob makes drying easy



Image: A hand turning the non-slip spinning knob on the lid of the salad spinner, demonstrating the drying process.

Draining Excess Water:

- The lid features a built-in pour spout. After spinning, you can drain the collected water from the outer bowl without removing the lid.
- Simply tilt the spinner over a sink and allow the water to flow out through the spout.

Dimensions



Image: The GoodCook Deluxe Salad Spinner tilted over a sink, with water draining from its built-in pour spout on the lid.

MAINTENANCE AND CLEANING

The GoodCook Deluxe Salad Spinner is designed for easy cleaning.

- All components are **top-rack dishwasher safe**.
- For manual cleaning, disassemble the spinner into its three main parts (outer bowl, inner basket, lid). Wash with warm, soapy water and rinse thoroughly.
- Ensure all parts are completely dry before reassembling or storing.

Top Rack Dishwasher Safe



Image: The disassembled components of the GoodCook Deluxe Salad Spinner (outer bowl, inner basket, and lid) placed in the top rack of a dishwasher for cleaning.

SPECIFICATIONS

Brand:	GoodCook
Model Number:	08242
Material:	Plastic (BPA-free polypropylene)
Color:	Green
Capacity:	6-quart outer bowl, 4-quart inner basket
Product Dimensions (L x W x H):	12.5" x 10.25" x 7"
Dishwasher Safe:	Yes (Top Rack)

6-quart large capacity container



Image: The GoodCook Deluxe Salad Spinner with key dimensions (length, width, height) indicated, providing a visual reference for its size.

ADDITIONAL TIPS

- For best results, do not overfill the inner basket with produce. This allows for optimal spinning and drying.
- The clear outer bowl can also be used as a serving bowl for your freshly prepared salads.
- Store the disassembled components nested together to save space in your kitchen cabinets.