

Bulbrite LED/C9P

Bulbrite LED/C9P C9 Pink Bulbs Instruction Manual

Model: LED/C9P

1. INTRODUCTION

Thank you for choosing Bulbrite LED/C9P C9 Pink Bulbs. These energy-efficient LED bulbs are designed for long-lasting performance and vibrant illumination. This manual provides important information regarding the safe installation, operation, and maintenance of your new bulbs.

2. SAFETY INFORMATION

Please read and understand all safety instructions before installing or using these bulbs. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Risk of Electric Shock:** Always disconnect power before installing or replacing bulbs.
- **Indoor/Outdoor Use:** These bulbs are suitable for both indoor and outdoor use, provided they are installed in appropriate, weather-resistant fixtures.
- **Voltage:** Ensure the power supply voltage matches the bulb's rated voltage (120V).
- **Not Dimmable:** These bulbs are **not dimmable**. Do not use with dimmer switches, as this may damage the bulbs or the dimmer.
- **Handle with Care:** Avoid dropping or subjecting bulbs to excessive force.
- **Disposal:** Dispose of used bulbs according to local regulations.

3. PACKAGE CONTENTS

Your package should contain the following items:

- 25 x Bulbrite LED/C9P C9 Pink Bulbs



Figure 1: Bulbrite LED C9 Pink Bulbs (25-pack). This image displays the product packaging containing the 25 LED C9 pink bulbs.

4. SETUP AND INSTALLATION

Follow these steps to safely install your Bulbrite LED/C9P C9 Pink Bulbs:

1. **Power Off:** Ensure the power to the fixture or string lights is completely turned off at the circuit breaker or by unplugging the power cord.
2. **Remove Old Bulbs:** Carefully unscrew any existing bulbs from the sockets.
3. **Inspect Sockets:** Check the sockets for any damage or corrosion. Ensure they are clean and dry.
4. **Install New Bulbs:** Gently screw the Bulbrite LED/C9P C9 Pink Bulbs into the Intermediate (E17) base sockets. Do not overtighten.
5. **Restore Power:** Once all bulbs are securely installed, restore power to the fixture or string lights.
6. **Test:** Verify that all bulbs illuminate correctly.

Note: These bulbs have an Intermediate (E17) base. Ensure your fixture or string lights are compatible with this base type.

5. OPERATING INSTRUCTIONS

Operating your Bulbrite LED/C9P C9 Pink Bulbs is straightforward:

- **Power On/Off:** Control the bulbs by turning the power to the fixture or string lights on or off using the standard wall switch or plug.
- **Non-Dimmable:** As these bulbs are not dimmable, they will operate at full brightness when power is supplied. Do not attempt to use them with dimmer switches.
- **Energy Saving:** These LED bulbs consume only 0.35 watts, providing significant energy savings compared to traditional incandescent bulbs.

6. MAINTENANCE

Bulbrite LED/C9P C9 Pink Bulbs require minimal maintenance due to their long lifespan.

- **Cleaning:** Ensure power is off before cleaning. Gently wipe the bulbs with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Replacement:** With an average rated life of 50,000 hours, these bulbs are designed for extended use. Replace individual bulbs as needed by following the installation steps.
- **Storage:** If storing the bulbs or string lights, ensure they are clean, dry, and stored in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your Bulbrite LED/C9P C9 Pink Bulbs, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bulb does not light up.	- No power to the fixture. - Bulb not screwed in properly. - Defective bulb. - Fixture/socket issue.	- Check power supply and circuit breaker. - Ensure bulb is securely tightened. - Replace with a known working bulb. - Inspect fixture/socket for damage; consult an electrician if necessary.
Bulb flickers.	- Loose connection. - Incompatible dimmer switch (if accidentally used). - Voltage fluctuations.	- Tighten the bulb. - Ensure no dimmer switch is in use; these bulbs are non-dimmable. - Consult an electrician to check household wiring.
Bulb is dim.	- Incompatible dimmer switch (if accidentally used). - Low voltage supply.	- Ensure no dimmer switch is in use; these bulbs are non-dimmable. - Consult an electrician to check household wiring.

8. SPECIFICATIONS

Detailed specifications for the Bulbrite LED/C9P C9 Pink Bulbs:

- Model:** LED/C9P
- Bulb Type:** LED C9
- Color:** Pink
- Quantity:** 25 Bulbs per pack
- Wattage:** 0.35 Watts
- Voltage:** 120 Volts
- Base Type:** Intermediate (E17)
- Dimmable:** No (Not Dimmable)
- Average Rated Life:** 50,000 Hours
- Beam Angle:** 360 degrees
- UPC:** 700580411141
- Manufacturer:** Bulbrite

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Bulbrite website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Bulbrite Contact Information:

- Website:** www.bulbrite.com (Note: This is a placeholder URL, please verify the actual Bulbrite website for support)
- Customer Service:** Refer to the website for contact numbers or email support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question