

## ORE 6336F

# ORE International 6336F Floating Shade Floor Lamp User Manual

Model: 6336F

Brand: ORE

## INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your ORE International 6336F Floating Shade Floor Lamp. Please read this manual thoroughly before installation and retain it for future reference.

The ORE International 6336F is a modern floor lamp featuring a rectangular white linen shade, a brushed nickel body stand, and an espresso wooden base. It is designed for indoor use and includes an on/off step switch.

## IMPORTANT SAFETY INSTRUCTIONS

- **Read all instructions:** Before assembling or using this lamp, carefully read and understand all instructions.
- **Electrical Safety:** Ensure the power supply is disconnected before assembly, installation, or maintenance. Use only the specified bulb type and wattage.
- **Indoor Use Only:** This lamp is designed for indoor use in dry locations. Do not expose to water or moisture.
- **Stable Placement:** Place the lamp on a flat, stable surface to prevent tipping.
- **Cord Safety:** Do not run the power cord under carpets or in areas where it can be tripped over or damaged. Keep the cord away from heat sources.
- **Bulb Handling:** Allow bulbs to cool before touching or replacing. Do not exceed the maximum wattage indicated on the lamp.
- **Cleaning:** Clean with a soft, dry cloth. Do not use liquid or abrasive cleaners.
- **UL Listed:** This product is UL listed, indicating compliance with safety standards.

## PARTS LIST

---

Before beginning assembly, ensure all parts are present and undamaged. Refer to the diagram below for identification.



**Figure 1:** ORE International 6336F Floating Shade Floor Lamp. This image displays the fully assembled lamp, featuring a rectangular white linen shade positioned above a slender brushed nickel stand, which is anchored by a solid black wooden base.

1. Base (Wooden)
2. Lower Pole Section (Brushed Nickel)
3. Upper Pole Section (Brushed Nickel)
4. Lamp Head with Socket (Brushed Nickel)
5. Rectangular Linen Shade

6. Shade Support Frame (if separate)
7. Power Cord with Step Switch
8. Hardware (Screws, Washers, Allen Wrench - specific to model)

## ASSEMBLY INSTRUCTIONS

---

Follow these steps carefully to assemble your floor lamp. It is recommended to assemble the lamp on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out and verify against the Parts List.
2. **Attach Lower Pole to Base:** Connect the lower pole section (2) to the wooden base (1). Secure it using the provided hardware (screws/washers) and the appropriate tool (e.g., Allen wrench). Ensure the pole is firmly seated and stable.
3. **Connect Upper Pole:** Screw the upper pole section (3) onto the lower pole section (2). Gently twist until securely tightened. Be careful not to cross-thread.
4. **Install Lamp Head:** Attach the lamp head with socket (4) to the top of the upper pole section (3). Ensure the electrical wire passes freely through the pole sections and is not pinched.
5. **Assemble Shade:** If the shade (5) requires assembly, follow the specific instructions provided with the shade components. Typically, this involves attaching the shade fabric to a metal frame.
6. **Attach Shade to Lamp Head:** Carefully place the assembled shade (5) onto the lamp head (4). Secure it using the shade ring or finial, if applicable, by screwing it onto the lamp socket.
7. **Insert Bulb:** Screw a suitable light bulb (not included, refer to specifications for type and wattage) into the lamp socket. Do not overtighten.
8. **Position Lamp:** Place the assembled lamp in its desired location, ensuring the power cord is not obstructed or under tension.

## OPERATING INSTRUCTIONS

---

1. **Connect to Power:** Plug the lamp's power cord into a standard electrical outlet.
2. **Turn On/Off:** Locate the step switch on the power cord. Press the switch with your foot to turn the lamp ON. Press it again to turn the lamp OFF.
3. **Dimmable Feature:** This lamp is designed to be dimmable. If you wish to utilize this feature, ensure you use a dimmable bulb and connect the lamp to a compatible dimmer switch (not included). The integrated step switch provides simple on/off functionality.

## MAINTENANCE

---

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe the metal and wooden surfaces. For the linen shade, a lint roller or a soft brush can be used to remove dust. Avoid using abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it. Unscrew the old bulb and screw in a new bulb of the correct type and wattage (refer to Specifications).
- **Regular Checks:** Periodically check the power cord for any signs of damage or fraying. Ensure all connections remain secure.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light up.	Lamp not plugged in. Bulb is loose or burnt out. Power outlet is not functioning. Step switch is faulty.	Ensure the power cord is securely plugged into a working outlet. Tighten the bulb or replace it with a new one. Test the outlet with another appliance. Contact customer support if the switch is suspected to be faulty.
Lamp flickers.	Loose bulb. Incorrect bulb type (non-dimmable bulb with dimmer). Faulty wiring.	Tighten the bulb. Ensure a dimmable bulb is used if connected to a dimmer. Unplug the lamp and inspect the cord for damage. If damage is found or suspected, discontinue use and contact a qualified electrician or customer support.
Lamp is unstable.	Assembly not fully tightened. Uneven surface.	Review assembly instructions and ensure all pole sections and the base are securely fastened. Place the lamp on a flat, level surface.

## SPECIFICATIONS

<b>Model Number</b>	6336F
<b>Brand</b>	ORE International
<b>Product Dimensions</b>	14"D x 7"W x 62"H
<b>Item Weight</b>	0.01 Ounces (Note: This weight seems unusually low and may be a data entry error. Actual weight will be higher.)
<b>Material</b>	Metal (Brushed Nickel), Wood (Base), Linen (Shade)
<b>Shade Material</b>	Linen

<b>Base Material</b>	Wood
<b>Finish Type</b>	Nickel
<b>Color</b>	Black (Base), White (Shade)
<b>Power Source</b>	Corded Electric
<b>Wattage</b>	110 watts (Max)
<b>Special Feature</b>	Dimmable (requires compatible bulb and dimmer switch)
<b>Certification</b>	UL Listed
<b>Switch Type</b>	On/Off Step Switch

## WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. ORE International products typically come with a limited manufacturer's warranty.

Should you require technical assistance, replacement parts, or have questions not covered in this manual, please contact ORE International customer support. Contact details can usually be found on the manufacturer's official website or on your purchase receipt.

You may also visit the [ORE Store on Amazon](#) for additional product information.

© 2023 ORE International. All rights reserved.

This manual is subject to change without notice.