

[manuals.plus](#) /› [Fossil](#) /› [Fossil Machine Quartz Chronograph Watch \(FS4682IE\) Instruction Manual](#)

## Fossil FS4682IE

# Fossil Machine Quartz Chronograph Watch (FS4682IE) Instruction Manual

Model: FS4682IE

## 1. PRODUCT OVERVIEW

The Fossil Machine Quartz Chronograph Watch (Model FS4682IE) is a men's timepiece featuring a matte black IP stainless steel case and bracelet. It is designed for durability and functionality, combining industrial aesthetics with refined details.

Key features include:

- **Case & Movement:** 42mm case diameter, 22mm band width, hardened mineral crystal lens for scratch resistance, accurate Quartz movement with analog display, date window, and three subdials for chronograph functions (minutes, seconds, 24-hour time).
- **Dial:** Black dial with brown/cream accents, housed within a round black stainless steel case.
- **Watch Band:** Black stainless steel bracelet with a secure fold-over clasp. Links can be removed for a customized fit. The band is interchangeable with all 22mm Fossil watch straps.
- **Water Resistance:** Rated up to 50 meters (165 feet) or 5 ATM. Suitable for short periods of recreational swimming and showering, but not for diving or snorkeling.





Figure 1: Front view of the Fossil Machine Quartz Chronograph Watch.

## 2. SETUP AND INITIAL USE

### 2.1. Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to position 2 for setting the date,

or position 3 for setting the time.

2. **Set the date:** In position 2, turn the crown clockwise or counter-clockwise until the correct date appears in the date window.
3. **Set the time:** In position 3, turn the crown to move the hour and minute hands to the correct time. Ensure to account for AM/PM if the watch has a 24-hour subdial.
4. **Push in the crown:** Once the time and date are set, push the crown back into position 1 to start the watch and seal it against water and dust.

## 2.2. Adjusting the Bracelet

The stainless steel bracelet features removable links to achieve a customized fit. It is recommended to have a professional jeweler adjust the bracelet to prevent damage. The fold-over clasp ensures a secure closure.




Figure 2: The secure fold-over clasp on the watch bracelet.

## 2.3. Initial Power

This watch is powered by a Lithium Metal battery, which is included and pre-installed. The watch should begin running once the crown is pushed into position 1. If the watch does not start, refer to the troubleshooting section.

## 3. OPERATING THE CHRONOGRAPH FUNCTIONS

The watch features a chronograph with three subdials for precise time measurement.

1. **Start/Stop Chronograph:** Press the top pusher button (located above the crown) to start the chronograph. Press it again to stop the timing.
2. **Reset Chronograph:** While the chronograph is stopped, press the bottom pusher button (located below the

crown) to reset all chronograph hands to zero.

3. **Subdials:** The three subdials typically track elapsed minutes, seconds, and a 24-hour indicator. Consult the specific dial markings for exact functions.

Your browser does not support the video tag.

Video 1: Demonstration of the Fossil Men's FS4682 Stainless Steel Analog Black Dial Watch, showcasing its design and features.

## 4. CARE AND MAINTENANCE

### 4.1. Water Resistance

The watch is water-resistant up to 5 ATM (50 meters / 165 feet). This means it is suitable for short periods of recreational swimming and showering. However, it is **not** recommended for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water.

### 4.2. Cleaning

To maintain the appearance of your watch, wipe the case and bracelet with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. For the mineral crystal, use a soft, lint-free cloth.

### 4.3. Battery Replacement

The watch uses one Lithium Metal battery. When the watch stops running or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance is maintained.

## 5. TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed into position 1. If it still does not run, the battery may need replacement.
- **Time inaccuracy:** If the watch is consistently fast or slow, the movement may require servicing. Avoid exposing the watch to strong magnetic fields, which can affect accuracy.
- **Condensation under crystal:** This indicates a breach in the water resistance. Immediately take the watch to a service center to prevent further damage.

## 6. SPECIFICATIONS

<b>Model Number</b>	FS4682IE
<b>Brand</b>	Fossil
<b>Case Material</b>	Stainless Steel
<b>Case Diameter</b>	42mm
<b>Band Width</b>	22mm
<b>Movement</b>	Quartz Chronograph
<b>Crystal Type</b>	Hardened Mineral
<b>Water Resistance</b>	5 ATM (50 meters / 165 feet)

<b>Battery Type</b>	1 Lithium Metal (included)
<b>Product Dimensions</b>	2.83 x 3.54 x 3.54 inches; 0.02 ounces




Figure 3: Men's Watch Case Size Guide for reference.

## 7. WARRANTY AND SUPPORT

This Fossil watch is covered by the manufacturer's warranty. For specific warranty terms, conditions, and duration, please refer to the warranty information provided with your purchase or visit the official Fossil website. For technical support, repairs, or service inquiries, please contact Fossil customer service directly.