

Gillette GIL1192E

Gillette 2 Men's Disposable Razor Instruction Manual

Model: GIL1192E

[Introduction](#) [Safety Information](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Gillette 2 Men's Disposable Razor. Please read these instructions thoroughly before first use and retain for future reference. The Gillette 2 razor is designed for a close and comfortable shave, featuring two precision blades.





Image 1.1: Gillette 2 Men's Disposable Razor. This image displays a single blue disposable razor alongside a package containing five similar razors, highlighting the product's design and packaging.





Image 1.2: Gillette 2 Men's Disposable Razor packaging. A clear view of the product's retail packaging, showing a pack of five Gillette 2 disposable razors.

2. SAFETY INFORMATION

- Keep out of reach of children.
- Blades are sharp. Handle with care to avoid cuts.
- Do not touch the blades directly.
- Store in a dry place to prevent rust and maintain blade sharpness.
- Do not use if the razor appears damaged.
- Dispose of used razors responsibly.

3. SETUP

The Gillette 2 disposable razor requires minimal setup. It is ready for use directly out of its packaging.

1. Carefully remove one razor from the packaging.
2. Inspect the razor for any visible damage before use.



Image 3.1: Razor and packaging. This image shows a single Gillette 2 disposable razor next to its individual packaging, illustrating how the product is presented.



Image 3.2: Close-up of razor head. A detailed view of the razor head, showing the two blades and the protective strip.

4. OPERATING INSTRUCTIONS

Follow these steps for an effective and comfortable shave:

1. **Prepare Skin:** Wet the area to be shaved with warm water. Apply shaving cream or gel to create a lather.
2. **Shave:** Hold the razor at a comfortable angle. Shave in the direction of hair growth using light, gentle strokes. Avoid applying excessive pressure.
3. **Rinse Blades:** Periodically rinse the razor blades under running water to clear away hair and shaving cream buildup.
4. **Repeat if Necessary:** For a closer shave, reapply shaving cream and shave against the grain, if comfortable.
5. **Finish:** After shaving, rinse your skin with cool water and apply an aftershave or moisturizer.



Image 4.1: Shaving preparation. A man is shown looking into a mirror, holding a Gillette 2 razor, illustrating the typical use scenario for the product.



Image 4.2: Razor blades detail. A magnified view of the Gillette 2 razor's twin blades, emphasizing their design for effective hair removal.

5. MAINTENANCE

To ensure hygiene and optimal performance for the lifespan of the disposable razor:

- **Rinse Thoroughly:** After each use, rinse the razor head thoroughly under running water to remove all hair and shaving cream. Do not tap the razor against the sink, as this can damage the blades.
- **Air Dry:** Allow the razor to air dry completely before storing. Do not wipe the blades, as this can dull them.
- **Storage:** Store the razor in a dry place.
- **Disposal:** When the blades become dull or you experience discomfort during shaving, dispose of the razor and use a new one.



Image 5.1: Razor side profile. This image provides a clear side view of the Gillette 2 disposable razor, showing the angle of the head and the handle's design.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Razor pulling hair or causing discomfort	Dull blades; insufficient lubrication; incorrect shaving technique.	Replace the razor; ensure adequate shaving cream/gel; use lighter strokes and shave with the grain.
Nicks or cuts	Excessive pressure; uneven skin surface; dull blades.	Reduce pressure; stretch skin taut; replace the razor.
Razor clogging easily	Hair or shaving cream buildup.	Rinse blades more frequently during shaving.

7. SPECIFICATIONS

- **Brand:** Gillette
- **Model Number:** GIL1192E
- **Number of Blades:** 2
- **Manual Shaving Razor Type:** Disposable Razor
- **Handle Material:** Plastic (Acrylonitrile Butadiene Styrene)
- **Item Weight:** 26 Grams
- **Item Dimensions:** 0.39 x 0.39 x 0.39 inches
- **Unit Count:** 10.0 Count (for a pack of 2, each containing 5 razors)
- **Global Trade Identification Number (GTIN):** [03014260287030](#)




Image 7.1: Packaging dimensions. This image shows the product packaging with measurements, indicating a height of 7.4 inches (18 cm).



Image 7.2: Back of packaging. The reverse side of the Gillette 2 disposable razor packaging, displaying various product details and multilingual information, including the GTIN 03014260287030.

8. WARRANTY & SUPPORT

For information regarding product warranty or customer support, please refer to the contact details provided on the product packaging or visit the official Gillette website. As a disposable product, specific warranty terms may vary.

Manufacturer: Procter & Gamble

Official Gillette Store: [Visit the Gillette Store on Amazon](#)