De'Longhi ECAM 22.110.SB

De'Longhi Magnifica XS Fully Automatic Espresso and Cappuccino Machine

Model Number: ECAM 22.110.SB

Brand: De'Longhi

About Your Magnifica XS

Be your own barista with the Magnifica XS by De'Longhi. This compact automatic espresso machine includes all of the features of our full-size machines, but in a smaller, more convenient size. You and your guests can enjoy delicious cappuccinos and lattes anytime. It's never been easier to create authentic Italian drinks with our patented cappuccino system frother. Simply place a container with milk under the nozzle to create a rich, creamy froth. The Magnifica XS does all the work for you! It not only makes incredible espresso drinks, but also saves you money while doing it, with the energy-saving switch and single boiler system. Select either whole beans or ground coffee, the machine does both. For the freshest results, the patented direct-to-brew system grinds beans instantly before brewing. With five coffee-strength settings from extra-mild to extra-strong, everyone gets their ideal flavor. The choices don't end there, select from four cup-size options to suit your preferred taste. Other highlights include easy-to-use manual controls, convenient water filtration, as well as a cup warmer and a removable drip tray. Enjoy coffee for years to come with the Magnifica XS!

Key Features

- **FRESH ESPRESSO FOR EVERY CUP:** The professional burr grinder with 13 adjustable settings grinds fresh beans every time to ensure maximum freshness. You can also use pre-ground in the second chamber. Your choice of regular, specialty or decaf.
- **YOUR FOAM, YOUR WAY:** A manual frother mixes steam and milk to create a rich, creamy froth for evenly textured drinks – just the way you like them.
- **CONSISTENT BREWING EVERY TIME:** Each cup is automatically brewed to the perfect temperature, richness and density. And you can customize the settings to ensure its always just the way you like it.
- **EASY TO CLEAN AND HANDLE:** The compact, extractable brew unit is not only easy to clean, it self-adjusts for one or two shots of espresso.
- **DELICIOUS CAPPUCCINO AND LATTE:** The adjustable manual Cappuccino System mixes steam and milk to create the thickest, longest-lasting foam for your cappuccino. And it’s easy to adjust the levels to prepare a creamy latte, macchiato or flat white.

1. Initial Setup

Unpacking and Placement

Carefully remove all packaging materials. Place the machine on a stable, level surface away from heat sources and water.

Water Tank Installation

The water tank is located on the side of the machine. Pull it out, fill it with fresh, clean water, and reinsert it securely.





Image: Front view of the De'Longhi Magnifica XS espresso machine, highlighting its compact design and control panel.



Image: Close-up view of the water tank being removed from the side of the machine.

Coffee Bean Container

Open the lid on top of the machine and fill the bean container with fresh whole coffee beans. Ensure the lid is closed properly after filling.



Image: Top view of the coffee bean container filled with whole coffee beans.

First Use / Priming

Before first use, or after a long period of inactivity, the machine needs to be primed. Follow the on-screen prompts or refer to the user guide for detailed steps. This typically involves dispensing hot water through the steam wand.

2. Brewing Coffee

Powering On

Press the power button to turn on the machine. The machine will perform an automatic rinse cycle. Wait for the indicator lights to become steady, indicating it's ready for use.

Adjusting Coffee Strength and Quantity

Use the central dial to select your desired coffee strength (from extra-mild to extra-strong). Use the cup buttons to select

the desired quantity of coffee (single or double espresso/coffee).



Image: Close-up of the machine dispensing two cups of espresso simultaneously.

Making Espresso/Coffee

Place one or two cups under the coffee spouts. Press the corresponding button for a single or double shot. The machine will grind the beans and brew automatically.

Using Pre-Ground Coffee

The machine also supports pre-ground coffee. Open the dedicated compartment on top, add one scoop of pre-ground coffee, and select the desired brew.

Frothing Milk (Manual Cappuccino System)

To prepare frothed milk for cappuccinos or lattes, ensure the steam wand is clean. Fill a pitcher with cold milk. Press the steam button and wait for the steam light to become steady. Immerse the steam wand into the milk and turn the steam

dial to the '1' position. Move the pitcher slowly up and down to create creamy froth. Once desired froth is achieved, turn the steam dial back to '0' and clean the wand immediately.

Video: Demonstration of the De'Longhi ECAM22110SB Compact Automatic Cappuccino, Latte and Espresso Machine in operation, including brewing and frothing functions.

3. Cleaning and Maintenance

Daily Cleaning

Empty and clean the drip tray and coffee grounds container daily. Wipe down the exterior of the machine with a soft, damp cloth.

Brew Unit Cleaning

The brew unit is extractable for easy cleaning. Remove it and rinse under running water at least once a month. Allow it to air dry before reinserting.

Descaling

The machine will indicate when descaling is required (often by a red light). Follow the instructions in the user manual for the descaling procedure using a suitable descaling solution. Regular descaling is crucial for machine longevity and coffee quality.

Steam Wand Cleaning

After each use, wipe the steam wand with a damp cloth. Periodically, remove the nozzle and clean any milk residue to prevent blockages.

4. Common Issues and Solutions

Problem	Possible Cause	Solution
Coffee not dispensing	No water in tank; clogged spouts	Fill water tank; clean coffee spouts
Water leaking	Drip tray full; water tank not seated correctly	Empty drip tray; re-seat water tank
Milk not frothing	Clogged steam wand; cold milk not used	Clean steam wand; use cold milk

5. Product Specifications

- **Brand:** De'Longhi
- **Model Name:** ECAM22110SB
- **Color:** Silver
- **Product Dimensions:** 16.93"D x 9.37"W x 13.39"H
- **Item Weight:** 19.84 pounds
- **Voltage:** 110 Volts
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic
- **Special Feature:** Removable Brew Unit, 15 Bar Pump, Adjustable Coffee Length, Hot Water Function, Adjustable Brew Strength

6. Warranty and Customer Support

Warranty Information

For detailed warranty information, please refer to the official warranty card included with your product or visit the De'Longhi website.

Customer Support

If you encounter any issues not covered in this manual, please contact De'Longhi customer support.
Official User Guide (PDF): Download Here
Visit the De'Longhi Store: De'Longhi Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question