

[Manuals.plus](#) /

› [XtremeMac](#) /

› XtremeMac 10W USB Speaker Tango BAR USB-B22-03 Instruction Manual

XtremeMac USB-B22-03

XtremeMac 10W USB Speaker Tango BAR USB-B22-03 Instruction Manual

1. INTRODUCTION

Thank you for purchasing the XtremeMac Tango BAR USB-B22-03 10W USB Speaker. This soundbar is designed to enhance your audio experience for computers, smartphones, and tablets, delivering clear stereo sound through a simple USB connection. Please read this manual carefully to ensure proper setup, operation, and maintenance of your device.

2. PACKAGE CONTENTS

Please check the package for the following items:

- XtremeMac Tango BAR USB-B22-03 Speaker
- Integrated USB Cable
- Instruction Manual (this document)

3. PRODUCT OVERVIEW

The XtremeMac Tango BAR is a sleek, tabletop soundbar designed for convenient audio playback. It features a 10W stereo output and connects via a single USB cable for both power and audio.



Figure 1: Close-up of the speaker's illuminated volume knob and textured grille.



Figure 2: Angled view of the XtremeMac Tango BAR USB speaker.



Figure 3: XtremeMac Tango BAR USB speaker positioned beneath an Apple iMac.

4. SETUP

1. **Placement:** Position the Tango BAR speaker on a stable, flat surface, such as a tabletop or desk, preferably beneath your computer monitor or in front of your device.
2. **Connect USB:** Plug the integrated USB cable from the Tango BAR into an available USB 2.0 port on your computer, laptop, or a compatible USB power adapter (not included) if connecting to a smartphone or tablet.
3. **Audio Source Selection:** Your operating system should automatically detect the speaker. You may need to select the "XtremeMac Tango BAR" or "USB Audio Device" as the default audio output in your device's

sound settings.

5. OPERATING INSTRUCTIONS

The XtremeMac Tango BAR features a touch-sensitive control for volume adjustment.

- **Power On/Off:** The speaker powers on automatically when connected to a powered USB port. There is no separate power button.
- **Volume Control:** Use the touch-sensitive control dial located on the speaker to adjust the volume. Rotate clockwise to increase volume and counter-clockwise to decrease volume.
- **Audio Playback:** Once connected and selected as the audio output, simply play audio from your connected device (computer, smartphone, tablet).

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Moisture:** This speaker is not waterproof. Keep it away from water and other liquids.

7. TROUBLESHOOTING

- **No Sound:**
 - Ensure the USB cable is securely connected to both the speaker and your device.
 - Check your device's sound settings to confirm the XtremeMac Tango BAR is selected as the default audio output.
 - Increase the volume on both the speaker and your connected device.
 - Try connecting the speaker to a different USB port or a different device to rule out a port or device issue.
- **Distorted Sound:**
 - Reduce the volume on both the speaker and your connected device.
 - Ensure the audio source is of good quality.
- **Speaker Not Detected:**
 - Disconnect and reconnect the USB cable.
 - Restart your computer or device.
 - Check for any necessary audio drivers for your operating system (though typically USB audio devices are plug-and-play).

8. SPECIFICATIONS

Feature	Specification
Brand	XtremeMac
Model Name	Tango BAR USB-B22-03 (0049720023975)

Speaker Type	Soundbar
Maximum Speaker Power Output	10 Watts
Audio Output Mode	Stereo
Connectivity Technology	USB
Control Method	Touch
Mounting Type	Tabletop
Speaker Size	22 Inches
Item Weight	3 Kilograms
Recommended Uses	For Computers, Smartphones, or Tablets

9. WARRANTY AND SUPPORT

XtremeMac products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your purchase or visit the official XtremeMac website. Please retain your proof of purchase for warranty claims.