

[Manuals.plus](#) /

› [Trend Lighting](#) /

› Trend Lighting Nimbus Table Lamp User Manual

Trend Lighting BT7143

Trend Lighting Nimbus Table Lamp User Manual

Model: BT7143

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Trend Lighting Nimbus Table Lamp, model BT7143. Please read this manual thoroughly before installation and operation, and retain it for future reference.

The Nimbus Table Lamp features a metallic silver and polished chrome finish, complemented by a clean sheer snow/shantung double shade. Its transitional style allows it to integrate well with various interior designs.



Figure 1: The Trend Lighting Nimbus Table Lamp, showcasing its metallic silver and polished chrome base with a white double fabric shade.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury to persons:

- Always disconnect the power supply before cleaning or replacing the bulb.
- Do not use with a damaged cord or plug. If the cord or plug is damaged, do not attempt to repair it yourself. Contact qualified service personnel.

- Do not operate the lamp near water or in excessively damp environments.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- This product operates on 120 Volts. Please check your local laws and electrical codes before purchasing and installing this product.
- Use only incandescent bulbs with a maximum wattage of 75W. Exceeding the recommended wattage may cause overheating and fire.

PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- 1 x Lamp Base Assembly (Metallic Silver/Polished Chrome)
- 1 x Double Fabric Shade (Sheer Snow/Shantung)
- 1 x Harp and Finial (pre-attached or separate)
- 1 x User Manual (this document)

Note: Light bulb is not included and must be purchased separately. Recommended bulb type: Incandescent, max 75W.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Assemble Lamp Base:** Ensure the lamp base is stable and all connections are secure. The lamp column should be firmly attached to the base.
3. **Install Harp (if separate):** If the harp (the U-shaped wire frame that holds the shade) is not pre-attached, slide its two prongs into the saddle on the lamp socket.
4. **Attach Shade:** Place the double fabric shade onto the harp. Ensure it rests evenly.
5. **Secure Finial:** Screw the finial (the decorative cap) onto the threaded rod at the top of the harp until the shade is securely held in place. Do not overtighten.
6. **Install Light Bulb:** Screw an incandescent bulb (max 75W) into the lamp socket. Do not exceed the maximum wattage.
7. **Connect to Power:** Plug the lamp's power cord into a standard 120V electrical outlet.

OPERATING INSTRUCTIONS

The Nimbus Table Lamp is designed for simple operation.

- **Turning On/Off:** Locate the switch on the lamp cord or socket. Toggle the switch to turn the lamp on or off.
- **Dimmable Feature:** This lamp is dimmable. If connected to a compatible dimmer switch (sold separately) in your wall outlet, you can adjust the light intensity by operating the dimmer switch. Ensure the bulb used is also dimmable.

MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and functionality of your lamp.

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe the metallic silver

and polished chrome finish. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish. For the fabric shade, use a lint roller or a soft brush to remove dust.

- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down before attempting to replace it. Unscrew the old bulb and screw in a new incandescent bulb (max 75W).
- **Cord Care:** Periodically inspect the power cord for any signs of damage, fraying, or cuts. If damage is found, discontinue use and contact a qualified electrician or the manufacturer.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Lamp not plugged in. Light bulb is loose or burnt out. Power outlet is not functioning. Switch is faulty.	Ensure the plug is fully inserted into the outlet. Tighten the bulb or replace it with a new one. Test the outlet with another appliance. Check circuit breaker. Contact customer support if the switch is faulty.
Light flickers.	Loose bulb. Incorrect bulb type for dimmer (if applicable). Faulty wiring.	Tighten the bulb. Ensure dimmable bulb is used with a dimmer switch. Unplug the lamp and contact a qualified electrician.
Shade is crooked.	Harp not seated correctly. Finial not tightened evenly.	Adjust the harp to ensure it is seated properly in the saddle. Loosen and re-tighten the finial, ensuring the shade is centered.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Attribute	Detail
Model Number	BT7143
Brand	Trend Lighting
Lamp Type	Table Lamp
Style	Transitional
Finish Type	Metallic Silver/ Polished Chrome Finish
Base Material	Metal
Shade Color	White (Sheer Snow/Shantung Double Shade)
Light Source Type	Incandescent
Number of Light Sources	1

Max Wattage	75 Watts
Voltage	120 Volts
Power Source	Corded Electric
Special Feature	Dimmable
Product Dimensions (D x W x H)	14"D x 13.5"W x 30"H
Item Weight	8 Pounds
UPC	741142046548

WARRANTY AND SUPPORT

Warranty: This Trend Lighting product is covered by a 1-year limited manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accident, modification, or unauthorized repair.

Customer Support: For technical assistance, warranty claims, or to inquire about replacement parts, please contact Trend Lighting customer service. Please have your model number (BT7143) and proof of purchase ready when contacting support.

For more information, visit the official Trend Lighting website or contact your retailer.