

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Smoby](#) /

› [Smoby Metal Baby Swing Instruction Manual - Model 310046](#)

Smoby 310046

Smoby Metal Baby Swing Instruction Manual - Model 310046

For ages 6 months and up

1. PRODUCT OVERVIEW

The Smoby Metal Baby Swing, Model 310046, is designed to provide a safe and enjoyable swinging experience for children aged 6 months and older. It features a robust metal structure with a wide-diameter frame and a cradle-like design, ensuring enhanced stability and durability. The seamless construction minimizes breakage risks, and the swing seat includes a safety bar for secure use. This swing is suitable for both indoor and outdoor environments, offering versatility for playtime.

Plastic components are treated with anti-UV protection to ensure long-lasting color and resistance to environmental factors. The maximum weight capacity for this swing is 25 kg. Assembly is designed to be straightforward.



An adult supervises a happy child seated in the Smoby Metal Baby Swing. The swing features a sturdy metal frame and a secure, colorful seat with a safety bar.

2. SAFETY INFORMATION

WARNING: Small parts. Adult assembly required. Keep small parts away from children before and during assembly.

- Always ensure adult supervision when a child is using the swing.
- Do not exceed the maximum weight limit of 25 kg.
- Ensure the swing is placed on a level, soft surface, such as grass or a play mat, away from obstacles.
- Regularly inspect all components for wear, damage, or loose parts. Discontinue use if any damage is found.
- Ensure all connections are securely fastened before each use.
- This product is intended for domestic use only.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact Smoby customer support.


- Metal frame components (legs, top bar)

- Swing seat with safety bar
- Connecting pieces and fasteners
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

The Smoby Metal Baby Swing is designed for easy assembly. Follow these steps carefully:

1. Unpack all components and lay them out on a clean, flat surface.
2. Connect the metal frame components according to the diagrams provided in the separate assembly sheet (not included in this digital manual). The wide-diameter frame and seamless construction ensure stability.
3. Attach the swing seat to the top bar using the provided hooks or connectors. Ensure the safety bar is correctly positioned.
4. Verify that all connections are tight and secure.
5. Place the assembled swing on a stable, level surface.



A technical drawing showing the dimensions of the Smoby Metal Baby Swing: 120 cm (width) x 124 cm (depth) x 120 cm (height).

5. OPERATING INSTRUCTIONS

To ensure safe and proper use of the Smoby Metal Baby Swing:

- Always place the child securely in the swing seat, ensuring the safety bar is properly engaged.
- Gently push the swing to initiate movement. Avoid excessive force or high swinging.
- Maintain constant supervision of the child while they are in the swing.
- The swing seat is designed to be convertible. For older children, the safety bar can be removed (refer to the separate assembly guide for specific instructions).



A young child is comfortably seated in the Smoby Baby Swing, demonstrating the secure design of the seat and safety bar.



This diagram illustrates the 2-in-1 convertible design of the swing seat, allowing it to adapt as the child grows. The safety bar can be removed for older children.

6. MAINTENANCE

Proper maintenance will extend the life of your Smoby Metal Baby Swing:

- **Cleaning:** Wipe down plastic and metal surfaces with a damp cloth and mild soap. Rinse thoroughly and dry. Avoid abrasive cleaners.
- **Inspection:** Regularly check all bolts, nuts, and connections to ensure they are tight. Inspect the swing seat, ropes, and frame for any signs of wear, cracks, or damage.
- **UV Protection:** The plastic parts are UV-treated for color retention and durability. However, prolonged exposure to direct sunlight and harsh weather conditions can still cause fading over time.
- **Storage:** If not in use for extended periods, especially during adverse weather, consider storing the swing indoors to protect it from elements.

7. TROUBLESHOOTING

If you encounter any issues with your Smoby Metal Baby Swing, consider the following:

- **Swing feels unstable:** Ensure all frame connections are securely tightened and the swing is placed on a completely level surface.
- **Squeaking noises:** Check for any friction points. A small amount of silicone-based lubricant can be applied to moving metal parts, avoiding contact with plastic.
- **Parts appear damaged:** Discontinue use immediately. Do not attempt to repair damaged structural components. Contact Smoby customer support for replacement parts or advice.




8. SPECIFICATIONS


Attribute	Detail
Brand	Smoby
Model Number	310046
Color	Green/Orange
Product Dimensions (L x W x H)	120 cm x 124 cm x 120 cm (approx. 137.01 x 37.01 x 15.01 cm packaged)
Material	Metal (frame), Plastic (seat)
Item Weight	6 Kilograms (approx. 13.23 Pounds)
Maximum Weight Recommendation	25 Kilograms
Minimum Age Recommendation	6 Months
Frame Material	Metal
Number of Compatible Seats	1
Finish Type	Polished
Seat Depth	14.6 Centimeters

9. WARRANTY AND SUPPORT

Smoby products are manufactured to high-quality standards. For information regarding warranty coverage, spare parts availability, or technical support, please refer to the warranty card included with your purchase or visit the official Smoby website. Keep your proof of purchase for any warranty claims.

You can find more information and contact details on the official Smoby website: www.smoby.com

 <p>Smoby Baby Nurse Toilet Assembly Instructions and Safety Guide</p> <p>Comprehensive assembly instructions and safety warnings for the Smoby Baby Nurse Toilet toy. Learn how to assemble the play toilet with clear steps and component identification.</p>	
 <p>Smoby Baby Nurse Crib Assembly Instructions</p> <p>A comprehensive guide to assembling your Smoby Baby Nurse Crib, featuring clear, step-by-step instructions, safety warnings, and a list of included parts. Model AAP2210B.</p>	
 <p>Smoby Landau Calin Baby Doll Stroller Assembly Instructions</p> <p>This document provides comprehensive assembly instructions for the Smoby Landau Calin baby doll stroller. It details the parts included, offers step-by-step guidance for assembly, and highlights crucial safety warnings for safe usage.</p>	
 <p>Smoby 7600312303 Chef's Kitchen 2-in-1 with Dining Area User Manual</p> <p>Comprehensive user manual for the Smoby 7600312303 Chef's Kitchen 2-in-1 with Dining Area. This guide provides detailed assembly instructions, safety warnings, and usage information for this children's play kitchen.</p>	
 <p>Smoby Baby Nurse Electronic Doll Bath - Assembly Instructions and Safety Guide</p> <p>Comprehensive guide for assembling and safely using the Smoby Baby Nurse Electronic Doll Bath (Model AAP2330C), including parts list, step-by-step instructions, and important safety warnings for children.</p>	
 <p>Smoby Playhouse Slabs: Configurations and Requirements</p> <p>A guide to Smoby's modular slab system for playhouses, detailing configurations and the number of slab sets required for various models like Jura Lodge, Chef House, Friends House, and Tipi. Includes product references and coverage information.</p>	



[\[pdf\]](#) User Manual

Impresión de fax página completa Elia ΟΔΗΓΙΕΣ Smoby Παιδική Κουνιά Baby Swing Metal Με Βάση 310046 PrimeKid Παιδικά Παιχνίδια Τρακτέρ Ποδήλατα ! manualcdn simba dickie group |||

...

lang: score:20 filesize: 3.99 M page_count: 4 document date: 2013-04-22