Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mr. Dj DJ5800

Mr. DJ USA DJ-5800 Professional 3 Way DJ Speaker User Manual

Model: DJ5800

1. Introduction

Thank you for choosing the Mr. DJ USA DJ-5800 Professional 3 Way DJ Speaker. This manual provides essential information for the safe and efficient operation of your speaker. Please read it thoroughly before use and retain it for future reference.
The DJ-5800 is designed for professional audio applications, featuring a 3-way loudspeaker system with a high-quality horn tweeter, delivering powerful and clear sound reproduction. Its robust construction ensures durability and reliable performance.

2. Safety Instructions

To prevent fire, electric shock, or injury, always follow these basic safety precautions:

- **Power Source:** Connect the speaker only to a power supply of the type described in this manual or on the unit.
- **Grounding:** Ensure the power cord is properly grounded to prevent electric shock.
- **Ventilation:** Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- **Heat:** Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Water and Moisture:** Do not use this apparatus near water. Do not expose to dripping or splashing.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Overloading:** Do not overload wall outlets or extension cords as this can result in a risk of fire or electric shock.
- **Placement:** Place the speaker on a stable, level surface to prevent it from falling.

3. Package Contents

Please check that all items are present in the package:

- One (1) Mr. DJ USA DJ-5800 Professional 3 Way DJ Speaker
- One (1) Power Cable
- One (1) User Manual (this document)

4. Product Features

The Mr. DJ USA DJ-5800 speaker offers the following key features:

- **Power Output:** 5800 Watts Max Peak Momentary Power
- **Speaker Configuration:** 3 Way Loudspeaker system
- **Construction:** Heavy Duty 3/4 Inch MDF (Medium-Density Fiberboard) for enhanced durability and acoustic performance.
- **Tweeter:** Equipped with a High Quality Horn Tweeter for crisp high-frequency reproduction.
- **Mounting Type:** Designed for Floor Standing placement.
- **Audio Channels:** Supports 3 audio channels.





An image showing the front view of the Mr. DJ USA DJ-5800 Professional 3 Way DJ Speaker, highlighting its robust construction and speaker components.

5. Setup

1. **Unpacking:** Carefully remove the speaker from its packaging. Inspect for any signs of damage during transit.
2. **Placement:** Position the speaker on a stable, level floor surface. Ensure there is adequate space around the speaker for proper ventilation and sound dispersion. Avoid placing it directly against walls or in corners if possible, as this can affect sound quality.
3. **Audio Connection:** Connect the speaker to your amplifier or audio source using appropriate speaker cables. Ensure correct polarity (positive to positive, negative to negative) for optimal sound. Refer to your amplifier's manual for specific connection instructions.
4. **Power Connection:** Plug the provided power cable into the speaker's power input, then connect the other end to a suitable electrical outlet.

6. Operating Instructions

1. **Power On:** Ensure all connections are secure. Turn on your amplifier or audio source first, then power on the DJ-5800 speaker.
2. **Volume Control:** Adjust the volume level from your amplifier or audio source. Start with a low volume and gradually increase it to a comfortable listening level. Avoid excessively high volumes to prevent speaker damage and hearing loss.
3. **Audio Playback:** Begin playing audio from your connected source.
4. **Power Off:** When finished, turn off the DJ-5800 speaker first, then power off your amplifier or audio source.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.
- **Dust:** Regularly dust the speaker grilles and surfaces to prevent dust buildup, which can affect performance and aesthetics.
- **Moisture:** Keep the speaker away from moisture and direct sunlight.
- **Storage:** If storing the speaker for an extended period, ensure it is in a dry, cool environment and protected from dust.

8. Troubleshooting

If you encounter issues with your DJ-5800 speaker, refer to the following common problems and solutions:

- **No Sound:**
  - Check if the speaker is properly connected to the power outlet and turned on.
  - Verify that the audio cables are securely connected to both the speaker and the amplifier/audio source.
  - Ensure the amplifier/audio source is powered on and its volume is not set to minimum or muted.
  - Test with a different audio source or cable if possible.
- **Distorted Sound:**
  - Reduce the volume level on your amplifier or audio source.
  - Check the audio source for distortion; try playing a different track or source.
  - Ensure speaker cables are not damaged and are securely connected.
  - Verify that the amplifier is not being overdriven.
- **Speaker Not Powering On:**
  - Confirm the power cable is firmly plugged into both the speaker and a working electrical outlet.
  - Check the circuit breaker or fuse for the outlet.

If the problem persists after attempting these solutions, please contact customer support.

9. Specifications

Brand	Mr. Dj
Model Name	FBA_DJ5800
Model Number	DJ5800
Speaker Configuration	3 Way Loudspeaker with High Quality Horn Tweeter
Power Output	5800 Watts Max Peak Momentary Power
Construction Material	Heavy Duty 3/4 Inch MDF
Mounting Type	Floor Standing
Number of Audio Channels	3
Item Dimensions (D x W x H)	50"D x 23"W x 18"H
Item Weight	85 pounds
Power Source	Corded Electric
UPC	847169004124
Manufacturer	Mr. Dj Inc.

10. Warranty Information

The Mr. DJ USA DJ-5800 Professional 3 Way DJ Speaker comes with a**1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation. Please retain your proof of purchase for warranty claims.

11. Support Information

For technical assistance, customer service, or to inquire about warranty claims, please contact Mr. Dj customer support. You can typically find contact details, including phone numbers and email addresses, on the official Mr. Dj website or through your retailer.
When contacting support, please have your model number (DJ5800) and proof of purchase readily available.

© 2023 Mr. Dj Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B005O6563Q

More documents and user manuals: **https://manuals.plus/**