

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Logilink](#) /

› [Logilink ID-0062 Flat Style Slim USB Optical Mouse User Manual](#)

## Logilink ID-0062

# Logilink ID-0062 Flat Style Slim USB Optical Mouse

## USER MANUAL

### Introduction

This manual provides detailed instructions for the Logilink ID-0062 Flat Style Slim USB Optical Mouse. Please read this manual thoroughly before using the device to ensure proper setup and operation. Keep this manual for future reference.

### Package Contents:

- 1 x Logilink ID-0062 Flat Style Slim USB Optical Mouse

### Setup

The Logilink ID-0062 mouse is designed for easy installation with its Plug and Play functionality. No additional drivers are typically required for basic operation.

### Connecting the Mouse:

1. Locate an available USB port on your computer.
2. Insert the USB connector of the Logilink ID-0062 mouse into the USB port.
3. Your operating system (Windows or Apple MacOS) will automatically detect and install the necessary drivers. This process may take a few moments.
4. Once installation is complete, the mouse is ready for use.



Figure 1: Logilink ID-0062 mouse in its retail packaging, showing the product as received.

## Operation

The Logilink ID-0062 is a standard 3-button optical mouse with a scroll wheel, offering precise 1000 dpi movement resolution.

### Basic Functions:

- **Left Button:** Primary click function, typically used for selecting items, opening files, or activating links.
- **Right Button:** Secondary click function, typically used to open context menus or access additional options.
- **Scroll Wheel:** Used for vertical scrolling through documents and web pages. The scroll wheel also functions as a middle button when pressed.
- **Optical Sensor:** The optical sensor on the underside of the mouse tracks movement on most surfaces, providing accurate cursor control.



Figure 2: The Logilink ID-0062 mouse, showcasing its slim profile and button layout.

## Maintenance

Proper care and maintenance will extend the lifespan of your Logilink ID-0062 mouse.

### Cleaning:

- Disconnect the mouse from your computer before cleaning.
- Use a soft, slightly damp cloth to wipe the surface of the mouse. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture.
- For the optical sensor, use a dry cotton swab to gently remove any dust or debris. Do not insert any objects into the sensor opening.

### Storage:

- Store the mouse in a clean, dry environment away from extreme temperatures and direct sunlight.
- Avoid bending or kinking the USB cable excessively to prevent damage.

## Troubleshooting

---

If you encounter issues with your Logilink ID-0062 mouse, refer to the following common problems and solutions.

### Mouse Not Responding:

- **Check USB Connection:** Ensure the USB connector is fully inserted into the computer's USB port. Try unplugging and re-plugging the mouse.
- **Try a Different USB Port:** Connect the mouse to another USB port on your computer to rule out a faulty port.
- **Restart Computer:** Sometimes, a simple computer restart can resolve connectivity issues.
- **Test on Another Computer:** If possible, test the mouse on a different computer to determine if the issue is with the mouse or your computer's setup.

### Erratic Cursor Movement:

- **Clean Optical Sensor:** Dust or debris on the optical sensor can interfere with tracking. Refer to the Maintenance section for cleaning instructions.
- **Change Surface:** The optical sensor may not track well on highly reflective, transparent, or uneven surfaces. Try using a mouse pad or a different surface.

## Specifications

---

Feature	Description
Model	ID-0062
Connectivity Technology	Wired, USB
Interface	1 x USB - 4 PIN USB Type A
Movement Detection	Optical
Movement Resolution	1000 dpi
Buttons Quantity	3 (Left, Right, Scroll Wheel/Middle)
Features	Scrolling wheel, Flat Style, Slim Design, Plug and Play
Compliant Standards	Plug and Play, RoHS
Operating System Support	Apple Mac OS, Microsoft Windows
Item Weight	2.46 ounces (approx. 70 grams)
Product Dimensions (LxWxH)	2.17 x 5.91 x 0.67 inches (approx. 5.5 x 15 x 1.7 cm)
Color	White
Power Source	Corded Electric (via USB)

## Warranty and Support

---

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. For technical support or further assistance, please contact Logilink customer service through their official website or the contact information provided with the product.

© 2023 Logilink. All rights reserved.