**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Hudora 71655

# HUDORA All Stars 205 Adjustable Height Portable Basketball Hoop Instruction Manual

Model: 71655

## Introduction

Thank you for choosing the HUDORA All Stars 205 Basketball Hoop. This manual provides essential information for the safe assembly, operation, and maintenance of your product. Please read it thoroughly before use and retain it for future reference.





*Image: The complete HUDORA All Stars 205 Basketball Hoop, showcasing its design and the 'All Stars 205' model identifier.*

## Safety Information

- Always ensure the base is filled with water or sand for maximum stability before use.
- Regularly check all bolts and connections to ensure they are securely tightened.
- Do not hang on the rim or backboard, as this may cause injury or damage to the product.
- Supervise children during play.
- Position the hoop on a flat, stable surface.
- Inspect the product for any damage before each use. Discontinue use if any damage is found.

## Setup and Assembly

The HUDORA All Stars 205 Basketball Hoop is designed for easy assembly. It is recommended that two adults assemble the unit.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the included parts list (not provided in this manual, refer to original packaging).
2. **Assemble the Pole:** Connect the pole sections as per the manufacturer's instructions. Ensure all locking mechanisms are engaged.
3. **Attach Backboard and Rim:** Securely fasten the backboard to the upper pole section, then attach the rim and net.
4. **Connect to Base:** Attach the assembled pole to the base unit.
5. **Fill the Base:** The vinyl base must be filled with approximately 28.7 liters of water or sand to ensure stability. This prevents tipping during play.




*Image: This diagram illustrates the adjustable height range of the basketball hoop, from 165 cm to 205 cm, and the dimensions of the backboard (70cm wide, 45cm high) and rim (40cm diameter).*




*Image: This image highlights the secure base, which can be filled with sand or water for stability, and the two integrated wheels that allow for easy movement of the hoop. The base capacity is approximately 29 liters.*

## Operating Instructions

### Height Adjustment:

The hoop's height can be adjusted from 165 cm to 205 cm. To adjust, loosen the locking mechanism on the pole, slide the upper section to the desired height, and securely tighten the mechanism. This feature allows the hoop to adapt to different age groups and skill levels.

### Portability:

Thanks to the two integrated wheels on the base, the basketball hoop can be easily moved. Tilt the hoop slightly and roll it to your desired location, whether it's the garden, patio, or driveway.



*Image: A young boy demonstrates the use of the HUDORA All Stars 205 basketball hoop, shooting a ball outdoors.*

## Maintenance

- **Cleaning:** Wipe down the backboard, rim, and pole with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Weather Resistance:** The steel frame, powder-coated metal ring, and weather-resistant polyester net are designed for outdoor use. However, for prolonged product life, consider storing the hoop indoors during extreme weather conditions or long periods of non-use.
- **Base Fluid:** Periodically check the water or sand level in the base and refill if necessary to maintain stability.
- **Net Replacement:** The tricolor polyester net is durable but may require replacement over time due to wear and tear. Replacement nets can be sourced from the manufacturer.




*Image: This graphic emphasizes the hoop's durability due to its metal rim and weather-resistant steel frame, and its flexible use for games in various outdoor settings like the garden or garage.*

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Hoop is wobbly or unstable. | Base not sufficiently filled, or placed on uneven ground. | Ensure the base is completely filled with water or sand. Move the hoop to a flat, stable surface. Check all connections for tightness. |
| Backboard or pole bending. | Excessive force applied (e.g., hanging on the rim) or loose connections. | Avoid hanging on the rim. Check and tighten all bolts and connections. If structural damage occurs, contact customer support for replacement parts. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Base is leaking. | Damage to the base or improper sealing of the fill cap. | Inspect the base for cracks or punctures. Ensure the fill cap is securely closed. If the base is damaged, replacement may be necessary. |

## Specifications

- **Model Number:** 71655
- **Adjustable Height:** 165 cm - 205 cm
- **Product Dimensions:** 57 x 15.49 x 77.5 cm (packaged); 20f. x 8an. x 2050al. millimeters (assembled, max height)
- **Product Weight:** 8.5 kg
- **Base Capacity:** Approximately 28.7 liters (for water or sand)
- **Material:** Polypropylene (base), Steel (frame), Powder-coated metal (rim), Polyester (net)
- **Color:** Black, Blue, Red
- **Usage:** Outdoor
- **Special Feature:** Portable with wheels

## Warranty and Support

For specific warranty details, please refer to the documentation included with your purchase or visit the official Hudora website. Hudora offers spare parts for most of its products, allowing for easy replacement of worn components and extending the product's lifespan.
For customer support or to inquire about spare parts, please contact Hudora directly through their official channels. Contact information can typically be found on the product packaging or their website.

© 2024 Hudora. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B005OQ4OKW**

More documents and user manuals: **https://manuals.plus/**