

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Baby Einstein](#) /

› [Baby Einstein Discovering Music Activity Table \(Model 90592\) User Manual](#)

Baby Einstein 90592

Baby Einstein Discovering Music Activity Table (Model 90592) User Manual

For Ages 6 Months +

INTRODUCTION

The Baby Einstein Discovering Music Activity Table is designed to engage infants and toddlers in musical exploration and early learning. This versatile activity center offers multiple modes of play to support developmental milestones from sitting to standing.

Key Features:

- Empowers baby to make their own magical music.
- Ages up from sit & play to standing toy by attaching or removing legs.
- Features piano, drum, guitar, and French horn activities.
- Piano keys teach numbers and colors.
- Switch between 3 languages (English, Spanish, French).
- Suitable for children from 6 to 36 months.
- Wipeable for easy cleaning.
- Includes expert-developed Einstein Way Play Tips to inspire curiosity and foster purposeful parent-baby playtime.

SETUP

Battery Installation:

1. Locate the battery compartment on the underside of the activity table.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure with the screw.

Assembling the Legs:

The activity table can be used with or without legs, adapting to your child's developmental stage.

- **For Floor Play (without legs):** Ensure the legs are detached. This mode is ideal for younger babies who are sitting or engaging in tummy time.
- **For Stand & Play (with legs):** Align each leg with the corresponding slot on the underside of the table. Push firmly until you hear a click, indicating the leg is securely in place. To remove, press the release button on each leg and pull it out.



Image: The Baby Einstein Discovering Music Activity Table with all legs attached, ready for stand-and-play mode.



Image: A baby sitting on the floor, interacting with the activity table with its legs removed for floor play.



“Must have toy.
My daughter
loves this toy.”

– PaintedNightSky

Image: A baby standing and engaging with the activity table, which has its legs attached.

OPERATING INSTRUCTIONS

Power On/Off and Volume Control:

- Locate the power switch and volume control on the underside of the table.
- Slide the switch to turn the unit ON or OFF.
- Adjust the volume to a comfortable level using the volume control switch.

Modes of Play:

The activity table features two primary modes: Music Mode and Discovery Mode. Switch between modes using the central lever.

- **Music Mode:** In this mode, pressing the piano keys will produce musical notes. Interacting with the drum, guitar, and French horn elements will activate various musical sounds and melodies.
- **Discovery Mode:** In this mode, pressing the piano keys will introduce colors and numbers. Interacting with the

other instruments will provide educational phrases related to instruments or animals.

Language Selection:

A language switch is located near the central lever. Slide this switch to select English, Spanish, or French. The spoken content in Discovery Mode will change accordingly.



Image: A detailed view of the activity table's top surface, showing the piano keys, central lever, and various instrument buttons.



Image: A baby's hands pressing the colorful piano keys and interacting with other features on the activity table.

Official Product Video:

Your browser does not support the video tag.

Video: A brand story video from Baby Einstein (Kids II, Inc.), showcasing the brand's philosophy and various products, including the activity table. This video provides an overview of the brand's commitment to fostering curiosity in children.

MAINTENANCE

To clean the Baby Einstein Discovering Music Activity Table, simply wipe it with a damp cloth and mild soap. Do not immerse the product in water. Ensure the product is completely dry before allowing children to play with it again.

TROUBLESHOOTING

- No Sound or Lights:** Check if the power switch is in the ON position. Ensure batteries are correctly installed and are not depleted. Replace with fresh AAA batteries if necessary.

- **Intermittent Functionality:** This may indicate low battery power. Replace batteries. Also, ensure no debris is obstructing buttons or switches.
- **Legs Not Attaching/Detaching Smoothly:** Ensure the release buttons are fully pressed when detaching. When attaching, align correctly and push until a click is heard. Avoid forcing the legs.

SPECIFICATIONS

Feature	Detail
Product Dimensions	16.5 x 4.5 x 15 inches
Item Weight	2.73 pounds
Item Model Number	90592
Manufacturer Recommended Age	6 months - 3 years
Batteries Required	3 AAA batteries
Release Date	August 18, 2012
Manufacturer	Kids2, Inc.

WARRANTY INFORMATION

This product is covered by the manufacturer's standard warranty. Please refer to the packaging or the manufacturer's official website for detailed warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Baby Einstein Discovering Music Activity Table, please contact Kids2, Inc. customer service. Contact information can typically be found on the product packaging or their official website.

 <p>Ocean Explorers Curiosity Cove™ 2-in-1 Activity Jumper Activity Center • Center de Actividades • Centro Actividades • Activity Center Importante: Conservar o para referencia futura. IMPORTANT: KEEP FOR FUTURE REFERENCE. IMPORTANT: CONSERVÉR D'ORIGINE POUR CONSULTATION ULTERIEURE. WICHTIG: ZUM SPÄTEREN WACHSCHLAG AUFBEWAHREN. ANDARE: MAI DIAZACONU, MAI STOCCHIACI, MAI STOCCHIACI. IMPORTANTE: CONSERVARE PER CONSULTAZIONI SUCCESSIVE. babystein.com</p> <p>152944-BBWS</p>	<p>Baby Einstein Ocean Explorers Curiosity Cove 2-in-1 Activity Jumper User Manual</p> <p>User manual for the Baby Einstein Ocean Explorers Curiosity Cove 2-in-1 Activity Jumper, providing safety instructions, assembly guide, care tips, battery information, and product features. Includes multilingual safety warnings and detailed parts list.</p>
 <p>152944-BBWS</p>	<p>Baby Einstein 4-in-1 Kickin' Tunes Musical Meadow Gym - User Manual & Assembly Guide</p> <p>Comprehensive user manual and assembly guide for the Baby Einstein 4-in-1 Kickin' Tunes Musical Meadow Music & Language Discovery Gym (Model 17447-BBWS). Includes safety warnings, care instructions, parts list, and battery information.</p>
 <p>152944-BBWS</p>	<p>Baby Einstein 4-in-1 Kickin' Tunes Jellyfish Jamboree Activity Gym - Instructions and Safety</p> <p>This document provides essential safety warnings, care instructions, battery information, assembly guidance, operating modes, and a parts list for the Baby Einstein 4-in-1 Kickin' Tunes Jellyfish Jamboree Music & Language Discovery Gym. Designed for infants up to 36 months.</p>
 <p>152944-BBWS</p>	<p>Baby Einstein 4-in-1 Kickin' Tunes Music and Language Discovery Gym Manual</p> <p>Comprehensive guide for the Baby Einstein 4-in-1 Kickin' Tunes Music and Language Discovery Gym, covering safety, assembly, care, and battery information. Features multiple languages.</p>
 <p>152944-BBWS</p> <p>Importante: Conservar o para referencia futura. IMPORTANT: KEEP FOR FUTURE REFERENCE. IMPORTANT: CONSERVÉR D'ORIGINE POUR CONSULTATION ULTERIEURE. WICHTIG: ZUM SPÄTEREN WACHSCHLAG AUFBEWAHREN. ANDARE: MAI DIAZACONU, MAI STOCCHIACI, MAI STOCCHIACI. IMPORTANTE: CONSERVARE PER CONSULTAZIONI SUCCESSIVE. babystein.com</p>	<p>Neighborhood Symphony Activity Jumper™ - Baby Einstein - Operating and Safety Manual</p> <p>Comprehensive guide for the Baby Einstein Neighborhood Symphony Activity Jumper™. Includes safety warnings, assembly instructions, operating guide, battery information, care instructions, and parts list. Ensure safe and proper use of your activity jumper.</p>
 <p>152944-WVS</p> <p>Importante: Conservar o para referencia futura. IMPORTANT: KEEP FOR FUTURE REFERENCE. IMPORTANT: CONSERVÉR D'ORIGINE POUR CONSULTATION ULTERIEURE. WICHTIG: ZUM SPÄTEREN WACHSCHLAG AUFBEWAHREN. ANDARE: MAI DIAZACONU, MAI STOCCHIACI, MAI STOCCHIACI. IMPORTANTE: CONSERVARE PER CONSULTAZIONI SUCCESSIVE. babystein.com</p>	<p>Baby Einstein Curiosity Table™ - Interactive Activity Toy for Toddlers</p> <p>Explore the Baby Einstein Curiosity Table™, an interactive toddler toy designed to engage young minds with colorful activities, gears, and sounds. Includes safety, cleaning, battery, and assembly instructions.</p>