

Lasko 101

Lasko MyHeat Personal Space Heater Model 101 Instruction Manual

Model: 101

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Lasko MyHeat Personal Space Heater, Model 101. Designed for personal warmth, this compact ceramic heater is ideal for use in small spaces such as offices, bedrooms, or under desks. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: Front view of the Lasko MyHeat Personal Space Heater.

IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electrical shock, or injury, observe the following safety precautions:

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Use extreme caution when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been

dropped or damaged in any manner.

- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- This heater is equipped with **Automatic Overheat Protection**. If the heater overheats, an automatic safety device will shut off the heater. To reset, unplug the heater from the outlet, wait 10 minutes for the unit to cool, then plug it back in.
- The **Cool Touch Exterior** ensures the housing remains cool to the touch during operation, reducing burn risk.



Figure 2: Lasko MyHeat features triple safe protection including auto shut-off, overheat protection, and cool touch housing.

SETUP

The Lasko MyHeat Personal Space Heater requires no assembly. Simply remove it from its packaging and follow these steps:

1. Place the heater on a firm, level surface. Ensure it is positioned where it can provide targeted warmth without obstruction.
2. Plug the 6-foot power cord into a standard 120V wall outlet. The heater uses a 2-pronged plug.

Personal Heat, Where You Need It

Compact & Portable Design



Figure 3: The Lasko MyHeat heater positioned on a desk for personal warmth.

OPERATING INSTRUCTIONS

Operating your Lasko MyHeat heater is straightforward:

1. Once plugged in, locate the power switch on the front of the unit.
2. Flip the switch to the "ON" position. The switch will illuminate, indicating the heater is active and producing warmth.
3. To turn off the heater, flip the switch back to the "OFF" position. The light will turn off.

This heater is designed for personal use and provides a gentle, targeted heat. It is not intended to heat an entire room.

Triple Safe Protection



Figure 4: The simple on/off power switch with indicator light.

Product Video Overview

Your browser does not support the video tag.

Video 1: An official overview of the Lasko MyHeat 200 Watt Personal Ceramic Space Heater, highlighting its features and ease of use.

MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your heater:

- Always unplug the heater before cleaning.
- Clean the exterior of the heater with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the heater is completely dry before plugging it back in.
- Regularly check the air intake and exhaust openings for dust and debris. Use a vacuum cleaner with a brush attachment to gently remove any build-up.
- Store the heater in a cool, dry place when not in use.

TROUBLESHOOTING

If your Lasko MyHeat heater is not operating as expected, consult the following common issues:

| Problem | Possible Cause | Solution |
|--------------------------------|-----------------------------------|--|
| Heater does not turn on. | No power to the unit. | Ensure the power cord is securely plugged into a working 120V outlet. Check the circuit breaker. |
| Heater turns off unexpectedly. | Overheat protection activated. | Unplug the heater, wait 10 minutes for it to cool down, then plug it back in. Ensure air intakes/exhausts are not blocked. |
| Reduced heat output. | Dust or debris blocking air flow. | Clean the air intake and exhaust openings as described in the Maintenance section. |

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|--|
| Brand | Lasko |
| Model Number | 101 |
| Color | White |
| Power | 200 Watts |
| Voltage | 120 Volts |
| Amperage | 2 Amps |
| Heating Element | Ceramic |
| Product Dimensions (D x W x H) | 3.8"D x 4.3"W x 6.1"H |
| Item Weight | 1 pound |
| Special Features | Energy Efficient, Simple Operation, Portable, Overheat Protection, Cool Touch Exterior, Compact Design |



Figure 5: Dimensions of the Lasko MyHeat Personal Space Heater.

WARRANTY AND SUPPORT

Your Lasko MyHeat Personal Space Heater is covered by a **3-year limited warranty**. For warranty claims, technical support, or any questions regarding your product, please contact Lasko customer service. Visit the official Lasko Store for more information: [Lasko Store on Amazon](#)

