

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Bushnell](#) /

> [Bushnell Neo Golf GPS Rangefinder Instruction Manual](#)

Bushnell 368050

Bushnell Neo Golf GPS Rangefinder Instruction Manual

Model: 368050

PRODUCT OVERVIEW

The Bushnell Neo Golf GPS Rangefinder is a compact and easy-to-use device designed to provide golfers with essential distance information on the course. It comes pre-loaded with thousands of courses and offers features like auto-course recognition and auto hole advance.

- Instantly displays key distances on the course (front, center, back).
- Holds up to 10 GPS golf course files.
- Allows for up to 4 custom points per hole.
- Features an accurate Shot Distance calculator.
- Powered by an internal, rechargeable Li-ion battery.



Figure 1: Bushnell Neo Golf GPS Rangefinder. This image shows the device's display, indicating distances to the front, center, and back of the green, along with the current hole number.

SETUP

Charging the Device

Before first use, fully charge the Bushnell Neo. Connect the included USB cable to the device and a power source (e.g., computer USB port or USB wall adapter). The battery indicator on the screen will show charging progress.

Initial Course Loading

The Neo comes pre-loaded with over 16,000 American courses. For courses not pre-loaded or for updates, you can download courses from iGolf.com. Refer to the iGolf.com website for detailed instructions on course downloads and synchronization.

OPERATING INSTRUCTIONS

Powering On/Off

To power on the device, press and hold the power button (usually located on the side or front) until the screen illuminates. To power off, press and hold the power button again until the device shuts down.

Starting a Round

1. Ensure the device has a clear view of the sky to acquire GPS satellites.
2. Once powered on, the Neo will automatically search for nearby golf courses (Auto Course Recognition).
3. Select your desired course from the list displayed.
4. The device will automatically advance to the first hole (Auto Hole Advance).

Reading Distances

The main screen displays distances to the front, center, and back of the green. The largest number typically represents the distance to the center of the green.

Using Shot Distance Calculator

To measure a shot, stand at your starting point and activate the shot distance feature (refer to device buttons for specific activation). Walk to where your ball landed, and the device will display the distance traveled.

Custom Points

The Neo allows you to mark up to 4 custom points per hole. This feature is useful for marking hazards, layups, or other points of interest. Consult the device's on-screen menu for instructions on setting and recalling custom points.

MAINTENANCE

Cleaning

Wipe the device with a soft, damp cloth. Do not use abrasive cleaners or solvents. The device is rainproof, but avoid submerging it in water.

Storage

Store the Bushnell Neo in a cool, dry place when not in use. Avoid extreme temperatures.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the device regularly, especially if it will be stored for an extended period.

TROUBLESHOOTING

No GPS Signal

- Ensure you are outdoors with a clear view of the sky.
- Wait a few minutes for the device to acquire satellites.
- Move to an open area away from tall buildings or dense tree cover.

Incorrect Distances

- Verify that the correct course and hole are selected.
- Ensure the device has a strong GPS signal.
- Check for updated course maps on iGolf.com.

Device Not Turning On

- Ensure the battery is charged. Connect to a power source and try again.
- Perform a soft reset (refer to the device's specific instructions for button combinations, if available, otherwise suggest holding power button).

SPECIFICATIONS

Feature	Detail
Dimensions	1.75 by 3.25 by .75 inches
Battery Life	Up to 16 hours
GPS Chip	SiRFstarIII
Pre-loaded Courses	16,000+ American courses
Water Resistance	Rainproof
Display Type	High contrast LCD screen
Included Components	Belt clip
Model Number	368050

COMPLIANCE AND SAFETY

The Bushnell Neo Golf GPS Rangefinder adheres to USGA rules for competition play.

SUPPORT AND FURTHER INFORMATION

For additional support, updated course information, or to register your product, please visit the official Bushnell website or iGolf.com. You can also refer to the [Bushnell Store on Amazon](#) for more products and information.