Gold N Hot GH1053

Gold 'N Hot Professional Ionic Stand Bonnet Hair Dryer Instruction Manual

Model: GH1053

1. Introduction

This manual provides instructions for the safe and effective use of your Gold 'N Hot Professional Ionic Stand Bonnet Hair Dryer. Please read all instructions carefully before operation and retain this manual for future reference.
The Gold 'N Hot Professional Ionic Stand Bonnet Hair Dryer is designed for efficient hair drying and conditioning. It features an adjustable stand, bonnet, and face shield, along with multiple heat settings and an optional ionic generator for versatile styling.

2. Safety Information

For your safety, always adhere to the following guidelines:

- Always use the dryer in a well-ventilated area.
- Do not use the dryer while moving or in unstable positions. Ensure the base is stable and wheels are locked if applicable.
- Keep the power cord and plug away from heated surfaces.
- Do not submerge the dryer in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug the dryer from the power outlet when not in use, before cleaning, or before making any adjustments.
- Do not operate the dryer with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel.
- Do not block air openings or place the dryer on a soft surface where openings may be blocked.

3. Package Contents

Verify that all components are present in the package:

- Bonnet Dryer Head
- Adjustable Stand Pole
- Base with 5 Wheels (2 lockable)
- Power Cord
- Instruction Manual (this document)

4. Assembly

Follow these steps to assemble your stand bonnet hair dryer:

1. **Attach Wheels to Base:** Insert the five wheels into the designated slots on the base. Ensure the two lockable wheels are positioned for easy access.
2. **Secure Stand Pole to Base:** Insert the lower section of the adjustable stand pole into the center of the base. Tighten any securing mechanisms to ensure stability.
3. **Attach Bonnet Dryer Head:** Carefully align the bonnet dryer head with the top of the adjustable stand pole. Screw the bonnet head onto the pole until it is securely fastened. Ensure it is tightened completely to prevent wobbling.
4. **Adjust Height:** Loosen the adjustable tube collar to extend or retract the stand pole to your desired height. Tighten the collar firmly to lock the height in place.



Figure 1: Fully assembled Gold 'N Hot Professional Ionic Stand Bonnet Hair Dryer.




Figure 2: The dryer's base features five wheels, two of which are lockable for stability during use.



Figure 3: The adjustable tube allows for flexible height adjustments to suit various user needs.

5. Operating Instructions

To operate your Gold 'N Hot Professional Ionic Stand Bonnet Hair Dryer:

1. **Position the Dryer:** Place the assembled dryer on a stable, level surface. Lock the wheels if necessary to prevent movement.
2. **Adjust Height and Bonnet:** Adjust the height of the stand pole and the position of the bonnet and face shield to comfortably accommodate the user and any hair rollers. The large bonnet is designed to accommodate various roller sizes.
3. **Connect Power:** Plug the power cord into a standard electrical outlet.
4. **Select Heat Setting:** Choose one of the four available heat settings (Low, Medium, High, and Cool Shot) using the controls on the bonnet. Research the optimal setting for the specific hair type being dried.
5. **Activate Ionic Generator (Optional):** The dryer features an ionic generator. You can switch this function 'on' or 'off'

based on preference. The ionic generator helps to reduce frizz and enhance conditioning.

6. **Begin Drying:** Ensure the area is well-ventilated during use.
7. **After Use:** Once drying is complete, turn off the dryer, unplug it from the power outlet, and allow it to cool before storage.



Figure 4: The spacious bonnet is designed to accommodate larger hair rollers for various styling needs.



Figure 5: The adjustable face shield provides comfort and protection during drying.



Figure 6: The control panel displays the four styling heat settings for ultimate versatility.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your dryer:

- **Cleaning:** Ensure the dryer is unplugged and cool before cleaning. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Air Intake Filter:** Periodically check the air intake filter for lint and dust accumulation. Clean as needed to maintain proper airflow.
- **Storage:** For compact storage, the legs on the base are removable. Store the dryer in a dry, cool place away from direct sunlight and moisture.



Figure 7: The removable legs on the base allow for compact storage when the dryer is not in use.

7. Troubleshooting

If you encounter issues with your dryer, refer to the following common solutions:

- **Dryer Not Turning On:**
  - Check if the power cord is securely plugged into a functional electrical outlet.
  - Ensure the power switch on the dryer is in the 'ON' position.
  - Verify that the electrical outlet is receiving power (test with another appliance).
- **Insufficient Heat or Airflow:**
  - Ensure the selected heat setting is appropriate.
  - Check for any obstructions in the air intake or exhaust vents. Clean the air intake filter if it is clogged.

- **Unusual Noise:**
  - Ensure all parts, especially the bonnet head to the pole, are securely fastened. Loose connections can cause rattling.
  - If the noise persists and is unusual, discontinue use and contact customer support.
- **Bonnet Head Wobbles:**
  - Re-tighten the connection between the bonnet dryer head and the stand pole. Ensure it is screwed on completely and firmly.
  - Verify that the adjustable tube collar is securely tightened to lock the height.

If troubleshooting steps do not resolve the issue, please contact Gold 'N Hot customer support.

8. Specifications

Feature	Specification
Model Number	GH1053
Wattage	1875 watts
Power Source	Corded Electric
Special Feature	Ionic Generator, Portable, Adjustable Height, Large Bonnet
Product Dimensions	15.6 x 17.9 x 22.9 inches
Weight	2.45 Pounds
UPC	759894368870, 810667014001, 027043114143

9. Warranty and Support

This Gold 'N Hot Professional Ionic Stand Bonnet Hair Dryer comes with a one-year Limited Warranty, guaranteeing dependable performance and consistent results.
For warranty claims, technical support, or further assistance, please contact Gold 'N Hot customer service. Refer to the product packaging or the official Gold 'N Hot website for current contact information.

© 2023 Gold 'N Hot. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question