

## Canon PG-240XL

# Canon PG-240 XL Black Ink Cartridge Instruction Manual

Model: PG-240XL

## 1. PRODUCT OVERVIEW

---

The Canon PG-240 XL Black Ink Cartridge is designed to deliver high-quality black and white prints. This genuine Canon ink is formulated to work seamlessly with compatible Canon PIXMA printers, ensuring consistent performance and sharp document output.

Key features include:

- Genuine Canon Ink for crisp documents and beautiful photos.
- Utilizes FINE (Full-Photolithography Inkjet Nozzle Engineering) Technology for enhanced detail.
- ChromaLife 100 ink formulation offers a wide color range.
- Provides access to exclusive content via Creative Park Premium (with genuine Canon ink).



Figure 1: Canon PG-240 XL Black Ink Cartridge in its retail packaging.

## 2. COMPATIBLE PRINTERS

The Canon PG-240 XL Black Ink Cartridge is compatible with the following Canon PIXMA printer models:

- PIXMA MG2120, MG2220, MG3120, MG3122, MG3220, MG3222, MG3520, MG3522, MG3620, MG4120, MG4220
- PIXMA MX372, MX392, MX432, MX439, MX452, MX459, MX472, MX479, MX512, MX522, MX532
- PIXMA TS5120

# Genuine Canon Ink PG-240XL works with the following printers:



PIXMA MG2120	PIXMA MG2220
PIXMA MG3120	PIXMA MG3220
PIXMA MG4120	PIXMA MG4220
PIXMA MX512	PIXMA MG3520
PIXMA MX432	PIXMA MG3620
PIXMA MX372	PIXMA MX472
PIXMA MX522	PIXMA MX532
PIXMA MX452	PIXMA TS5120
PIXMA MX392	

Figure 2: Visual representation of a compatible Canon PIXMA printer and a comprehensive list of models that use the PG-240XL ink cartridge.

## 3. INSTALLATION INSTRUCTIONS

Follow these steps to install your new Canon PG-240 XL Black Ink Cartridge:


1. **Step 1: Remove Plastic Package.** Carefully open the ink cartridge packaging and remove the cartridge.
2. **Step 2: Remove Orange Tape.** Locate and gently peel off the orange protective tape from the ink cartridge. Avoid touching the electrical contacts or print nozzles.
3. **Step 3: Install.** Open your printer's ink cartridge cover. Wait for the print head to move to the replacement position. Insert the new ink cartridge firmly into its designated slot until it clicks into place. Close the printer cover.

# Easy Installation in 3 Simple Steps



## Step 1

Remove plastic package.



## Step 2

Remove orange tape.



## Step 3

Install.

Figure 3: Step-by-step visual guide for the easy installation of the ink cartridge.


## 4. OPERATING THE INK CARTRIDGE

Once installed, the Canon PG-240 XL ink cartridge is ready for use. Ensure your printer is powered on and connected to your device. Select your desired print settings (e.g., paper type, print quality) from your computer or printer's control panel, then initiate the print job.

This cartridge is designed for printing documents and photos, offering a page yield of approximately 300 pages. Actual page yield may vary based on content, print mode, and paper type.

# Print approximately 300 pages on a single color ink cartridge\*

Both cartridges must be installed in the printer and must have ink in them.



\*Page yield may vary depending on texts/photos printed, applications software used, print mode, a combination of the ink tank /ink cartridge size and type of paper used. When you use the Canon printer for the first time right after you install the provided ink tanks, the Canon printer consumes ink in the amount to enable printing by filling the nozzles of the Print Head with ink. For this reason, the number of sheets that can be printed with the first ink tanks is fewer than the succeeding ink tanks. The page yield is based on the consumption data from the succeeding ink tank /ink cartridge but not the first ink tank /ink cartridge. For details: [usa.canon.com/printers/inkjet-page-yields](http://usa.canon.com/printers/inkjet-page-yields)

Figure 4: The approximate page yield of 300 pages per cartridge, suitable for various printing needs.

## 5. MAINTENANCE AND CARE

To ensure optimal performance and longevity of your Canon PG-240 XL ink cartridge and printer:

- Store unused cartridges in their original sealed packaging in a cool, dry place until ready for use.
- Avoid touching the electrical contacts or print nozzles on the cartridge to prevent damage or print quality issues.
- Regularly perform print head cleaning and alignment from your printer's utility software to maintain print quality.
- Use genuine Canon ink cartridges to prevent potential damage to your printer and ensure warranty validity.

# Look for Canon Genuine Logo




Figure 5: Always look for the Canon Genuine Logo to ensure product authenticity and optimal performance.

## 6. TROUBLESHOOTING

If you encounter issues with your ink cartridge or printing, consider the following:

- **Poor Print Quality:** Ensure the protective tape has been completely removed from the cartridge. Perform a print head cleaning and alignment through your printer's maintenance utility. Check ink levels.
- **Cartridge Not Recognized:** Verify the cartridge is correctly seated in its slot. Remove and reinsert the cartridge. Ensure you are using a genuine Canon cartridge compatible with your printer model.
- **"E14" Error (Region Coded):** Some Canon products may be region-specific. Ensure the ink cartridge purchased is intended for use in your geographical region. Using a cartridge from a different region may result in compatibility errors.



# Warning



**Use of non-Canon ink cartridges or refilled ink cartridges can cause damage to your printer and may affect the limited warranty for that product.**

Figure 6: Important warning regarding the use of non-genuine or refilled ink cartridges.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Canon
Model Number	PG-240XL
Ink Color	Black
Ink Base	Pigment
Page Yield	Approximately 300 pages
Product Dimensions	3.3 x 2.2 x 4 inches
Item Weight	2.4 ounces
Compatibility Options	Genuine

## 8. WARRANTY AND SUPPORT

---

### Legal Disclaimer

This product is new and factory sealed. For specific warranty information, please refer to the documentation provided with your Canon printer or visit the official Canon support website. Use of non-Canon ink cartridges or refilled cartridges may affect the limited warranty for your product.

### Creative Park Premium

Genuine Canon Ink Cartridges provide free access to exclusive content via Creative Park Premium. This service is available to owners of select Canon PIXMA printers when all software and genuine Canon inks are installed. Users can download and print various creative content, including photographs, paintings, and illustrations.

© 2025 Canon Inc. All rights reserved.

For further assistance, please visit the [Canon Store](#) or consult your printer's user manual.