

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Tiny Love 33313024

Tiny Love Soothe 'n Groove Mobile User Manual

Model: 33313024



INTRODUCTION

The Tiny Love Soothe 'n Groove Mobile is designed to provide engaging entertainment and soothing comfort for infants and toddlers. This versatile product transitions from a crib mobile to a portable music box, offering a rich auditory experience with multiple musical categories and tunes. Its thoughtful design aims to stimulate development and provide continuous enjoyment for your child.

SAFETY INFORMATION

Always read and follow all instructions carefully before use. Keep this manual for future reference. Ensure all components are securely fastened before placing the mobile near your child. Do not leave children unattended with the product. This product is not a toy and should be used under adult supervision. Keep batteries out of reach of children. Dispose of batteries properly.

WARNING: Possible entanglement injury. Keep the mobile out of baby's reach. Remove the mobile from the crib or playpen when the baby begins to push up on hands and knees or reaches 5 months of age, whichever comes first. The mobile arm should be removed from the crib when the baby can sit up unaided.

PACKAGE CONTENTS

Please check that all parts are present before assembly:

- Main music box unit
- Mobile arm
- Mobile canopy with hanging toys (e.g., giraffe, monkey, elephant figures)
- Crib attachment strap/mechanism



Image: The Tiny Love Soothe 'n Groove Mobile, showing the main music box unit, mobile arm, and three hanging animal toys (giraffe, monkey, elephant).

SETUP

Battery Installation

1. Locate the battery compartment on the back of the main music box unit.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 3 "C" size batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Note: For optimal performance, use new alkaline batteries. Do not mix old and new batteries or different types of batteries.

Crib Mobile Assembly

1. Attach the mobile arm to the main music box unit, ensuring it clicks securely into place.
2. Connect the mobile canopy with the hanging toys to the top of the mobile arm.
3. Securely attach the entire unit to the crib rail using the provided attachment mechanism. Ensure it is firmly clamped and stable.
4. Adjust the mobile arm so that the hanging toys are at an appropriate distance from your baby, out of their reach.

Special soothing motion engages baby



Image: A baby lying in a crib, looking up at the attached Tiny Love Soothe 'n Groove Mobile with its rotating toys.

OPERATING INSTRUCTIONS

Power On/Off

Press the power button on the music box unit to turn the mobile on or off.

Music Selection

The Soothe 'n Groove Mobile features 6 different musical categories and 18 different tunes, providing up to 40 minutes of continuous, non-repeating music. Use the dedicated buttons on the music box to cycle through the musical categories (e.g., classical, lullabies, nature sounds) or to select specific tunes.

Features 6 different musical categories with 18 different tunes



Image: A baby reaching out to touch the buttons on the music box unit, illustrating the interactive music selection feature.

Volume Control

Adjust the volume using the volume control buttons on the music box unit to suit your child's preference and environment.

Mobile Motion

The mobile features a special soothing motion that engages the baby. This motion activates automatically when the mobile is turned on. Ensure the mobile arm is clear of any obstructions for smooth rotation.

Up to 40 minutes of continuous non-repeating music



Image: The Tiny Love Soothe 'n Groove Mobile in action, showing its soothing motion with hanging toys above a baby.

Transition to Portable Music Box

As your child grows, the mobile arm can be detached from the music box unit. The music box then functions as a stand-alone, portable music player that toddlers can carry and interact with independently.

Becomes a stand-alone portable music box for toddlers



Image: A toddler happily holding the music box unit, demonstrating its use as a portable music player.

MAINTENANCE

Cleaning

Wipe the mobile and music box unit with a damp cloth and mild soap. Do not immerse the electronic components in water. Ensure the product is completely dry before re-use.

Note: The product is not dishwasher safe.

Battery Replacement

Replace batteries when the sound becomes distorted or the mobile motion slows down. Follow the battery installation steps outlined in the Setup section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mobile does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with new "C" batteries.
Music is distorted or plays too slowly.	Low battery power.	Replace batteries.
Mobile arm does not rotate.	Obstruction or low battery power.	Ensure no objects are blocking the rotation. Replace batteries if needed.
Sound is too low or too high.	Volume setting is incorrect.	Adjust the volume using the control buttons on the music box.

SPECIFICATIONS

Model: 33313024

Brand: Tiny Love

Dimensions (L x W x H): 22.83 x 16.93 x 14.37 inches

Item Weight: Approximately 0.049 ounces (music box only) / 1.39 Grams (full product)

Power Source: 3 x "C" batteries (not included)

Battery Life: Approximately 20 hours

Material: Fabric

Special Features: Musical, Rotating, Nightlight, Converts to portable music box

Target Gender: Unisex

Mounting Type: Crib Mount

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Tiny Love website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Official User Guide (PDF): [Download PDF](#)

Manufacturer: Tiny Love

PRODUCT VIDEOS

Below are relevant product videos demonstrating features of the Tiny Love Soothe 'n Groove Mobile. Please note that only videos from the seller are included.

No official seller videos are available for embedding at this time.



© 2023 Tiny Love. All rights reserved.

[\[pdf\] Borchure](#)



Microsoft PowerPoint Hamleys Tiny Love All Compatibility Mode kbelch TINY LOVE 2015
babybrandsdirect co uk Gymini Move Play Princess Product code 33312029 RRP £64.99 Suitable from birth to 12 months Extra large mat with adjustable arches and foldable Collection 185 sysimages brochure brand document |||

TINY LOVE 2015 Who is Tiny Love Tiny Love was founded in 1991 by Shoshi and Isaac Oren with the aim to create a ... rld, nature, classic, lullaby, white sounds Requires 3 x C batteries not included Product code: **33313024** RRP: 49.99 Innovative movement Crib-side music box and night light Portable music box ...

lang:en **score:23** filesize: 3.72 M page_count: 77 document date: 2015-08-07