

[Manuals.plus](#) /

> [IKEA](#) /

> IKEA Glass-Door Cabinet User Manual

IKEA 101.192.06

IKEA Glass-Door Cabinet User Manual

Model: 101.192.06

PRODUCT OVERVIEW

The IKEA Glass-Door Cabinet (Model 101.192.06) is designed to display and protect your valuable items, such as glassware or collections. Its construction features a top/bottom panel made of particleboard with foil and ABS plastic, shelf supports of steel with epoxy/polyester powder coating, and tempered glass panels. This cabinet offers a clear view of your displayed objects while keeping them secure and dust-free.



Image: Front view of the IKEA Glass-Door Cabinet in black-brown, showcasing its transparent glass panels and internal shelves.

SAFETY INFORMATION

Important Safety Warning:

To prevent tipping, it is highly recommended to secure this furniture to the wall using the enclosed safety device. Different wall materials require specific types of fasteners. Always use fasteners that are suitable for the walls in your home to ensure maximum stability and safety.

SETUP AND ASSEMBLY

Assembly of the IKEA Glass-Door Cabinet is required. For detailed, step-by-step instructions, please refer to the official Installation Manual provided by IKEA. A digital version of this manual can be accessed via the following link: [IKEA Glass-Door Cabinet Installation Manual \(PDF\)](#).

Assembly Tips:

- It is strongly recommended to have two people for assembly due to the size and weight of the components, especially the glass panels.
- Unpack all components carefully. The packaging is designed to protect the contents, particularly the glass, during transit.
- Follow the pictorial instructions in the manual precisely. While there are no written instructions, the numbered pictures are designed to be clear and easy to understand.
- Ensure all parts are correctly aligned before tightening fasteners to avoid issues with fit.



Image: Side view of the IKEA Glass-Door Cabinet, illustrating its slender profile and glass construction.

OPERATING AND USAGE

The IKEA Glass-Door Cabinet is designed for displaying and protecting various items. Its glass doors allow for clear visibility of your collection while shielding them from dust and environmental factors.

Displaying Items

Utilize the multiple shelves within the cabinet to organize and showcase your items. The transparent nature of the cabinet ensures that your displayed objects are the focal point.

Lighting Integration

The cabinet is designed to accommodate lighting solutions, allowing you to enhance the visibility and aesthetic appeal of your displayed objects. There is a pre-cut, plugged hole at the top of the cabinet for easy installation of lighting fixtures (lighting sold separately).

MAINTENANCE

To maintain the clarity and appearance of your glass-door cabinet, regular cleaning is recommended. Use a soft, lint-free cloth and a glass cleaner to wipe down the glass panels. For thorough cleaning, it may be necessary to temporarily remove items from the shelves.

Periodically check all fasteners and connections to ensure they remain secure, especially after moving the cabinet or if any instability is noticed.

TROUBLESHOOTING

Cabinet Instability

If the cabinet feels unstable, ensure it is properly secured to the wall using the provided safety device. Verify that the fasteners used are appropriate for your wall material. Uneven flooring can also contribute to instability; consider using shims if necessary.

Difficulty During Assembly

If you encounter difficulties during assembly, double-check that all parts are oriented correctly according to the manual's diagrams. Sometimes, parts may appear similar but have subtle differences in their connection points. Ensure you have sufficient space and assistance during the assembly process.

Glass Panel Alignment

If glass panels do not align perfectly, loosen the connecting fasteners slightly, adjust the panels into position, and then re-tighten. This may require minor adjustments to achieve optimal alignment.

SPECIFICATIONS

Feature	Detail
Brand	IKEA
Model Number	101.192.06
Color	Black-brown
Product Dimensions	18"D x 66"W x 5"H
Item Weight	77.8 pounds
Material	Particleboard, Foil, ABS plastic, Steel, Tempered glass
Number of Shelves	4
Assembly Required	Yes
Mounting Type	Wall Mount (recommended)

WARRANTY AND SUPPORT

For specific warranty information regarding your IKEA Glass-Door Cabinet, please refer to the documentation included with your purchase or visit the official IKEA website. IKEA products typically come with a limited warranty covering defects in materials and workmanship.

For further assistance, technical support, or to inquire about replacement parts, please contact IKEA customer

service directly. You can find contact information on the official IKEA website or through your purchase receipt. Additional resources, including the full installation manual, can be found here:[Official Installation Manual \(PDF\)](#).

© 2023 IKEA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question