

Tatung TFS-J15HS

TATUNG Nutrition Maker TFS-J15HS User Manual

Model: TFS-J15HS | Brand: Tatung

INTRODUCTION

The Tatung Nutrition Maker TFS-J15HS is designed to assist with various food processing tasks, including preparing soy milk, juices, and hot liquids like pumpkin congee. It features a patented Stainless Steel Three-Blade turbo cutter engineered for micro-fiber processing, which helps to preserve the nutritional value of ingredients such as grape seeds, melon seeds, and pumpkin seeds.

Key Features:

- Durable motor and patented Stainless Steel Three-Blade turbo cutter.
- Rapid blending and Pulse function for precise control.
- Integrated 1-3 minutes timer for automated operation.
- Embedded safety lock mechanism for secure use.
- Large 42 oz (1250 ml) juice jar capacity.

SAFETY INSTRUCTIONS

To ensure safe operation and prevent injury or damage, please read and adhere to the following safety guidelines:

- Always unplug the appliance from the power outlet before cleaning, assembling, or disassembling parts.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the blending jar while operating to prevent severe injury.
- Ensure the lid is securely in place before operating the appliance. The embedded safety lock prevents operation if the jar and lid are not correctly assembled.
- Do not blend hot liquids without proper ventilation. Use caution when blending hot ingredients, as steam can build up and cause pressure.
- Avoid blending excessively hard ingredients that may damage the blades or motor.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of

the appliance by a person responsible for their safety.

- Children should be supervised to ensure they do not play with the appliance.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Tatung Nutrition Maker TFS-J15HS.



Figure 1: Tatung Nutrition Maker TFS-J15HS components. This image displays the main motor unit, the transparent blending jar with its lid and plunger, and a separate measuring cup. The main unit features control buttons and indicators.

Components:

- **Motor Base:** Contains the motor, control panel, and safety interlock mechanism.
- **Blending Jar (42 oz / 1250 ml):** Transparent jar with integrated Stainless Steel Three-Blade turbo cutter.
- **Lid:** Secures the blending jar and includes an opening for adding ingredients during operation.
- **Plunger/Tamper:** Used to push ingredients towards the blades for consistent blending.
- **Measuring Cup:** For precise ingredient measurement.

Control Panel:

- **Power Button:** Turns the appliance on/off.
- **Speed Control:** Adjusts blending speed (specific controls may vary, refer to unit markings).
- **Pulse Function Button:** Provides short bursts of power for controlled chopping or mixing.
- **Timer Settings:** Allows selection of 1-3 minute blending cycles.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the blending jar, lid, and measuring cup with warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth. *Do not immerse the motor base in water.*
3. **Assemble:**
 - Place the motor base on a stable, flat, and dry surface.
 - Ensure the blending jar is empty and clean.

- Align the blending jar onto the motor base. Twist or push down until it locks securely into place. The safety lock prevents operation if not correctly seated.
 - Place the lid onto the blending jar and ensure it is firmly closed.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of your Nutrition Maker.

1. **Prepare Ingredients:** Cut ingredients into appropriate sizes for blending. Do not overfill the blending jar beyond the maximum fill line.
2. **Add Ingredients:** Place prepared ingredients into the blending jar. For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.
3. **Secure Lid:** Place the lid firmly onto the blending jar. Ensure it is properly sealed to engage the safety lock.
4. **Select Function:**
 - **Continuous Blending:** Press the power button and select your desired speed setting.
 - **Pulse Function:** For short bursts of power, press and hold the Pulse button. Release to stop. This is ideal for chopping or breaking down larger pieces.
 - **Timer Function:** Select a 1, 2, or 3-minute timer setting for automated blending cycles. The appliance will stop automatically once the timer concludes.
5. **Blend:** Begin blending. If ingredients get stuck, use the plunger through the lid opening to push them towards the blades. *Never use your hands or other utensils.*
6. **Stop Operation:** Once blending is complete, turn off the appliance using the power button or wait for the timer to finish. Unplug the appliance from the power outlet.
7. **Remove Jar:** Carefully remove the blending jar from the motor base.
8. **Serve:** Pour out the blended contents.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your Nutrition Maker.

1. **Unplug:** Always ensure the appliance is unplugged before cleaning.
2. **Clean Blending Jar and Lid:**
 - Rinse the blending jar and lid immediately after use to prevent food from drying on the surfaces.
 - Wash with warm, soapy water using a non-abrasive sponge or brush.
 - Rinse thoroughly and allow to air dry, or dry with a soft cloth.
 - *Note: The blending jar and lid are NOT dishwasher safe. Hand wash only.*
3. **Clean Motor Base:**
 - Wipe the exterior of the motor base with a damp cloth.
 - For stubborn spots, use a mild detergent on the damp cloth, then wipe with a clean, damp cloth.
 - *Never immerse the motor base in water or any other liquid.*
4. **Storage:** Store the assembled Nutrition Maker in a clean, dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

Refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
Appliance does not turn on.	<ul style="list-style-type: none">• Not plugged in.• Blending jar or lid not correctly assembled.• Power outage.	<ul style="list-style-type: none">• Ensure the power cord is securely plugged into a working outlet.• Check that the blending jar is properly seated on the motor base and the lid is securely closed to engage the safety lock.• Verify power supply to the outlet.
Ingredients are not blending smoothly.	<ul style="list-style-type: none">• Too little liquid.• Overfilling the jar.• Ingredients are too large or dense.	<ul style="list-style-type: none">• Add more liquid as needed.• Reduce the amount of ingredients in the jar.• Cut ingredients into smaller pieces. Use the Pulse function or plunger to help move ingredients.
Motor smells or overheats.	<ul style="list-style-type: none">• Overloading the motor.• Continuous operation for too long.	<ul style="list-style-type: none">• Reduce the load by removing some ingredients.• Allow the appliance to cool down for at least 15-20 minutes before resuming operation.

SPECIFICATIONS

Brand	Tatung
Model Number	TFS-J15HS
Manufacturer	TATUNG
Item Weight	3 kg 720 g
Item Dimensions (LxWxH)	17 x 14.5 x 42.9 Centimeters
Blending Jar Capacity	42 oz (1250 ml)
Dishwasher Safe Parts	No
UPC	025517447773

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact Tatung customer service directly. Refer to the product packaging or the official Tatung website for the most current contact details and warranty terms applicable to your region.

Always provide your model number (TFS-J15HS) and purchase date when contacting support.

