

[manuals.plus](#) /› [Kryptonite](#) /› [Kryptonite KryptoLok Series 2 Standard Heavy Duty Bicycle U Lock with 4ft Flex Bike Cable Instruction Manual](#)

Kryptonite 001072

Kryptonite KryptoLok Series 2 Standard Heavy Duty Bicycle U Lock with 4ft Flex Bike Cable

MODEL: 001072

1. Introduction

Thank you for choosing the Kryptonite KryptoLok Series 2 Standard Heavy Duty Bicycle U Lock with 4ft Flex Bike Cable. This product is designed to provide robust security for your bicycle, resisting cutting and leverage attacks. This manual will guide you through the proper setup, operation, and maintenance to ensure optimal performance and longevity of your lock.

2. What's in the Box

- Kryptonite KryptoLok Series 2 Standard Bicycle U-Lock (4-Inch X 9-Inch)
- Transit FlexFrame-U Transportation System Bracket
- 4-Foot KryptoFlex Double Loop Cable
- 2 Stainless Steel Keys

3. Features

- **13mm Hardened MAX-PERFORMANCE STEEL SHACKLE:** Resists cutting and leverage attacks.
- **4' KRYPTOFLEX DOUBLE LOOP CABLE:** Provides additional security for front wheel or accessories.
- **Reinforced HARDEDNED CROSS BAR DESIGN:** Offers increased protection against attacks.
- **HIGH SECURITY DISC-STYLE CYLINDER:** Designed for enhanced pick resistance.
- **Center Keyway:** Defends against leverage attacks.
- **ANTI-RATTLE BUMPERS:** Reduce noise during transport.
- **Rotating Dustcover:** Protects the cylinder from dirt and debris.
- **NEW TRANSIT FLEXFRAME-U Transportation System:** Allows for versatile carrying options on your bike.
- **Protective Vinyl Coating:** Prevents scratching of your bike's finish.

4. Setup & Installation

The KryptoLok Series 2 U-Lock comes with a Transit FlexFrame-U bracket for convenient transportation on your bicycle frame. Follow these steps to install and use your lock:

1. **Install the Transit FlexFrame-U Bracket:** Attach the bracket to your bike frame using the provided hardware. Ensure it is securely fastened and does not interfere with pedaling or other bike components. The bracket allows for versatile carrying positions.
2. **Secure the U-Lock:** Slide the U-Lock into the Transit FlexFrame-U bracket until it clicks securely into place. The anti-rattle bumpers will help reduce noise during transport.
3. **Using the KryptoFlex Cable:** The 4ft KryptoFlex cable can be coiled and secured with a Velcro strap (if included) for easy storage when not in use.



Figure 1: A comprehensive view of the Kryptonite KryptoLok Series 2 U-Lock and the 4ft Flex Cable, highlighting the robust U-shackle, locking mechanism, and cable loops.

5. Operating Instructions

To effectively secure your bicycle, follow these guidelines:

1. Locking Your Bike:

- Choose a secure, immovable object (e.g., a bike rack, lamppost) to lock your bike to.
- Position the U-Lock to secure the bicycle frame and at least one wheel to the immovable object. Aim for a tight fit to minimize space for leverage attacks.
- Insert the key into the disc-style cylinder and turn to lock the shackle. Remove the key.
- Use the 4ft KryptoFlex cable to secure the front wheel or other accessories (like a helmet) by looping it through the U-lock and the desired component.

2. Unlocking Your Bike:

- Insert the key into the cylinder. The rotating dustcover should be moved aside first.
- Turn the key to unlock the shackle.
- Remove the U-lock and KryptoFlex cable from your bike and the immovable object.

3. Key Safe Program:

Register your key number with Kryptonite. In case of lost keys, Kryptonite can send you free replacement keys. Visit the Kryptonite website for registration details.

Your browser does not support the video tag.

Video 1: This video demonstrates the features and proper usage of the Kryptonite KryptoLok Series 2 Standard Heavy Duty Bicycle U Lock with 4ft Flex Bike Cable, including how to secure your bike frame and wheels.

Your browser does not support the video tag.

Video 2: An overview of the Kryptonite KryptoLok Series 2 Heavy Duty Bicycle U Lock, detailing its construction and security features.

6. Maintenance

Regular maintenance will extend the life and functionality of your lock:

- **Lubrication:** Periodically apply a small amount of graphite powder or a silicone-based lubricant to the lock cylinder to ensure smooth operation, especially in dusty or wet conditions.
- **Cleaning:** Wipe down the U-lock and cable with a damp cloth to remove dirt and grime. The protective vinyl coating helps prevent scratches and corrosion.
- **Dustcover:** Always ensure the rotating dustcover is closed when the lock is not in use to protect the cylinder from moisture and debris.

7. Troubleshooting

If you encounter issues with your lock, consider the following:

- **Stiff or Sticky Cylinder:** Apply lubricant as described in the Maintenance section. Ensure the key is fully inserted and turned correctly.
- **Shackle Not Engaging:** Check for any obstructions in the locking mechanism or if the shackle is misaligned. Ensure the key is fully turned to the locked position.
- **Lost Keys:** Utilize the Key Safe Program by contacting Kryptonite with your registered key number for replacement keys.

8. Specifications

Brand	Kryptonite
Model Name	Kryptolok Serie 2 Ls + Flex
Model Number	001072
Lock Type	U-lock
Shackle Material	Hardened Performance Steel
Shackle Thickness	13mm
Item Dimensions (L x W x H)	9.02 x 4.02 x 1.18 inches
Item Weight	1.5 Pounds
Cable Length	4 feet
Special Feature	Anti-Drill
Finish Type	Vinyl

9. Warranty and Support

Kryptonite stands behind the quality of its products. The KryptoLok Series 2 Standard U-Lock comes with a Lifetime Warranty. For detailed warranty information, to register your product, or to utilize the Key Safe Program, please visit the official Kryptonite website or contact their customer support.

Legal Disclaimer: Must be at least 18 & over to purchase.