

[Manuals.plus](#) /

› [PetSafe](#) /

› PetSafe Easy Walk Harness Instruction Manual - Medium, Black

PetSafe EW-H-M-BK-45

PetSafe Easy Walk Harness Instruction Manual

Model: EW-H-M-BK-45

INTRODUCTION

The PetSafe Easy Walk Harness is designed to gently discourage your dog from pulling on the leash during walks. Unlike traditional collars, this harness prevents choking and coughing by resting across your dog's sternum, not on the sensitive tracheal area. The unique front-chest leash attachment steers your dog to the side when they pull, redirecting their attention back to you. This manual provides instructions for proper fitting, use, and care of your Easy Walk Harness.



Image: PetSafe Easy Walk Harness - Less pulling, more walking.

PACKAGE CONTENTS

- 1 PetSafe Easy Walk Harness (Size Medium, Black)
- 1 Nylon Leash (1.8 meters / 6 feet)
- Instruction Manual

SIZING AND FITTING

Proper fitting is crucial for the effectiveness and comfort of the Easy Walk Harness. The harness features 4

adjustment points to ensure an optimal fit for your dog. A correctly fitted harness will form a "T" shape across your dog's side when they are standing.

Step 1: Measure Your Dog

Before fitting, measure your dog to select the correct harness size. The current product is size Medium, suitable for chest girths between 51 and 71 cm (20-28 inches) and weights between 11-23 kg (25-50 lbs).

- 1. **Chest Width:** Place a measuring tape across the chest, approximately 2.5 cm (1 inch) behind the front legs.
- 2. **Girth:** Wrap a measuring tape around the deepest part of your dog's rib cage, just behind the front legs.



Image: Measuring instructions for chest width and girth.

Sizing Chart

Size	Chest Width	Girth	Weight
XS	20-23 cm (8-9 in)	30-40 cm (12-16 in)	5-7 kg (11-15 lbs)
S	23-30 cm (9-12 in)	38-51 cm (15-20 in)	7-11 kg (15-25 lbs)

Size	Chest Width	Girth	Weight
S/M	28-33 cm (11-13 in)	48-63 cm (19-25 in)	9-14 kg (20-30 lbs)
M	30-38 cm (12-15 in)	51-71 cm (20-28 in)	11-23 kg (25-50 lbs)
M/L	36-46 cm (14-18 in)	64-89 cm (25-35 in)	18-29 kg (40-65 lbs)
L	41-53 cm (16-21 in)	66-91 cm (26-36 in)	29-43 kg (65-95 lbs)
XL	43-61 cm (17-24 in)	86-117 cm (34-46 in)	Over 41 kg (Over 90 lbs)

Step 2: Put on the Harness


1. Identify the chest strap (often a different color or clearly marked) and the shoulder straps.
2. Place the chest strap across your dog's chest, ensuring the front leash attachment ring is centered.
3. Bring the shoulder straps over your dog's back and fasten the quick-release buckles.
4. The harness should form a "T" shape on your dog's side when they are standing.

Mesures Harnais Easy Walk®

- 1

Largeur Poitrail - Posez le ruban à mesurer sur le poitrail jusqu'à environ 2.5 cm derrière les pattes avant
- 2

Tour de poitrine - Enroulez un ruban à mesurer autour de la partie la plus profonde de la cage thoracique du chien derrière les pattes avant



Taille	Poitrail	Tour de poitrine	Poids
Moyen	30-38 cm	56-81 cm	11-23 kg
Moyen/Large	36-46 cm	61-86 cm	18-30 kg
Grand	41-53 cm	69-102 cm	30-43 kg
Très Grand	43-61 cm	81-124 cm	Plus de 40,8 kg

Image: The harness should form a 'T' on the side when your dog is standing.

Step 3: Adjust the Straps

Adjust all four straps (two shoulder, two girth) to achieve a snug but comfortable fit. You should be able to fit one finger comfortably under the straps. Ensure the harness does not chafe or restrict movement.

- The chest strap should sit low across the sternum, not on the throat.
- The girth strap should be behind the front legs, allowing full range of motion.



Image: Patented front-chest leash attachment for anti-pull action.

OPERATING INSTRUCTIONS

Once the harness is properly fitted, attach the included 1.8-meter (6-foot) nylon leash to the D-ring located on the front of the chest strap. This front attachment point is key to the harness's anti-pull function.

- When your dog attempts to pull forward, the leash attachment gently steers them to the side, redirecting their attention towards you.
- This design avoids pressure on the throat, preventing choking or coughing.
- Use the harness as a training tool to teach your dog to walk politely by your side.



Recommandé par les
vétérinaires et les entraîneurs

Plus de 9 millions vendus

Image: A dog walking comfortably with the Easy Walk Harness and leash.

MAINTENANCE

To ensure the longevity and hygiene of your PetSafe Easy Walk Harness, follow these maintenance guidelines:

- **Cleaning:** The harness is machine washable. Use a mild detergent and cold water. Air dry only; do not tumble dry.
- **Inspection:** Regularly inspect the harness for any signs of wear and tear, such as frayed straps, loose stitching, or damaged buckles. Replace the harness if any components are compromised to ensure your dog's safety.
- **Storage:** Store the harness in a clean, dry place when not in use.

TROUBLESHOOTING

If you encounter issues with your Easy Walk Harness, consider the following common solutions:

- **Dog is still pulling:**
 - **Check the fit:** Ensure the harness is snug and correctly positioned. The chest strap should be

low across the sternum, and the harness should form a "T" shape on the side. A loose harness will not be effective.

- **Leash attachment:** Confirm the leash is attached to the front D-ring, not a back ring (if present on other harnesses).
- **Training consistency:** Consistent training and redirection are necessary. The harness is a tool to aid training, not a substitute for it.

- **Harness is chafing or causing discomfort:**

- **Adjust the straps:** Loosen or tighten straps as needed. Ensure no straps are digging into your dog's skin.
- **Check for proper size:** If the harness is too small or too large, it can cause discomfort. Refer to the sizing chart.
- **Material irritation:** While made of soft nylon, some dogs may have sensitive skin. Monitor for any irritation.

- **Dog is escaping the harness:**

- **Tighten the straps:** The harness is likely too loose. Adjust all four straps to ensure a snug fit where only one finger can fit under the straps.
- **Correct placement:** Ensure the harness is worn as intended, with the chest strap low and the girth strap behind the front legs.

- **Harness edges feel sharp:**

- Inspect the edges of the straps. If any feel rough, you may gently smooth them with a fine-grit sandpaper or nail file.

SPECIFICATIONS

Feature	Detail
Model Number	EW-H-M-BK-45
Size	Medium
Color	Black
Material	Nylon
Chest Girth Range	51-71 cm (20-28 inches)
Weight Range	11-23 kg (25-50 lbs)
Leash Length	1.8 meters (6 feet)
Care Instructions	Machine Washable
Recommended Breeds	Border Collies, Spaniels (for Medium size)
UPC	729849132351

WARRANTY INFORMATION

The PetSafe Easy Walk Harness is covered by a 2-year manufacturer's warranty. This warranty covers

defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please refer to the official PetSafe website or contact customer support.

CUSTOMER SUPPORT

For further assistance, questions, or troubleshooting not covered in this manual, please contact PetSafe Customer Service:

- **Phone:** 00 800 1818 2020 (International Toll-Free)
- **Website:** Visit the official PetSafe website for FAQs and additional resources.