

[Manuals.plus](#) /

› [Hot Wheels](#) /

› Hot Wheels Wall Tracks Mid-Air Madness Booster Trackset User Manual

Hot Wheels W3422

Hot Wheels Wall Tracks Mid-Air Madness Booster Trackset User Manual

Model: W3422

1. INTRODUCTION

This manual provides instructions for the Hot Wheels Wall Tracks Mid-Air Madness Booster Trackset. This trackset is designed for wall-mounted play, featuring a motorized booster for launching cars and track sections for dynamic movement. The set includes one Hot Wheels car, the Wall Tracks set components, 3M Command Strips for secure wall mounting, and a background poster.

2. SAFETY INFORMATION

- Recommended for ages 4 years and up.
- Adult assembly is required.
- Requires batteries (not included) for the motorized booster. Refer to the booster unit for specific battery requirements.
- Not for use with some Hot Wheels vehicles. Test car compatibility before extensive play.
- Ensure all track connections are secure before use to prevent parts from detaching during play.

3. SETUP INSTRUCTIONS

Follow these steps to assemble and mount your Hot Wheels Wall Tracks Mid-Air Madness Booster Trackset:

1. **Unpack Components:** Carefully remove all items from the packaging. Verify that all parts are present by comparing them with the contents list on the box.
2. **Prepare Wall Surface:** Choose a clean, smooth wall surface for mounting. Ensure the surface is free of dust, dirt, and grease for optimal adhesion of the 3M Command Strips.
3. **Use Hanging Template:** Locate the included hanging template. This template guides the precise placement of the mounting brackets. Position the template on the wall at the desired height and location, ensuring it is level. Secure the template temporarily with tape if needed.

4. **Attach Command Strips to Brackets:** Apply the 3M Command Strips to the designated areas on the back of each mounting bracket. Follow the specific instructions provided with the Command Strips for proper application and adhesion.
5. **Mount Brackets:** Align each bracket with its corresponding position on the hanging template. Press each bracket firmly against the wall for 30 seconds to ensure the Command Strip adheres properly. Once all brackets are mounted, carefully remove the hanging template.
6. **Assemble Track Sections:** Connect the various track sections to the mounted brackets. Refer to the assembly diagram provided in the product packaging for the correct sequence and orientation of the track pieces. Ensure all connections click securely into place.
7. **Install Batteries:** Insert the required batteries into the motorized booster unit. Refer to the battery compartment for the correct battery type and polarity. (Batteries are not included).
8. **Attach Poster:** If desired, attach the background poster to the wall behind the trackset using additional 3M Command Strips or other wall-safe adhesive.

For a visual guide on the setup process, please watch the following video:

Your browser does not support the video tag.

Video demonstrating the assembly and wall mounting of Hot Wheels Wall Tracks.




Image: The Hot Wheels Wall Tracks Mid-Air Madness Booster Trackset fully assembled and ready for play.

4. OPERATING INSTRUCTIONS

Once the trackset is securely mounted and batteries are installed in the booster, you can begin play:

1. **Place Car:** Position a compatible Hot Wheels car at the starting point of the track, typically before the motorized booster.
2. **Activate Booster:** Turn on the motorized booster. The booster will begin to propel the car forward.
3. **Launch Car:** The booster is designed to launch cars up the ramp, initiating the track's action sequences, including anti-gravity thrills and mid-air maneuvers.
4. **Continuous Play:** The track is designed to accommodate multiple cars for continuous racing and crashing action.

Experiment with different cars to observe their performance on the track.

5. **Expand Your Track:** Hot Wheels Wall Tracks are fully customizable. You can connect additional Wall Tracks stunt sets (sold separately) to create larger and more complex track layouts on your wall. These sets connect easily to expand the play experience.

Observe the track in action:

Your browser does not support the video tag.

Video showcasing the Hot Wheels Wall Tracks in operation, demonstrating car movement and track features.



Image: A child interacting with the Hot Wheels Wall Tracks set mounted on a wall.

5. MAINTENANCE

- **Cleaning:** Wipe the track sections and booster unit with a dry or slightly damp cloth. Do not immerse any electronic components in water.
- **Battery Replacement:** Replace batteries in the motorized booster when performance diminishes. Always use the recommended battery type and dispose of old batteries responsibly.
- **Storage:** When not in use, the trackset can remain mounted on the wall. If disassembling for storage, carefully remove the track sections and store them in their original packaging or a suitable container to prevent damage.
- **Command Strip Care:** If relocating the trackset, follow 3M Command Strip removal instructions to prevent wall damage. Use new Command Strips for re-mounting.

6. TROUBLESHOOTING

If you encounter issues with your Hot Wheels Wall Tracks Mid-Air Madness Booster Trackset, refer to the following common problems and solutions:

- **Track sections detaching from the wall:**
 - Ensure 3M Command Strips were applied to a clean, dry surface and pressed firmly for the recommended duration.
 - Allow sufficient time for the adhesive to set before placing weight on the brackets.
 - If a specific section, such as a top piece or a high-stress point, repeatedly detaches, consider replacing the Command Strip for that bracket or reinforcing the connection point with a fresh strip.
- **Cars not completing the track or falling off:**
 - Verify all track connections are secure and properly aligned. Misaligned sections can impede car movement.
 - Check the motorized booster for sufficient battery power. Weak batteries may not provide enough propulsion.
 - Ensure the car being used is compatible with the trackset. Some larger or heavier Hot Wheels vehicles may not perform optimally on certain track features.
 - Inspect the track for any obstructions or debris that might be hindering car movement.
- **Motorized booster not functioning:**
 - Check battery installation and ensure batteries are inserted with correct polarity.
 - Replace old batteries with fresh ones.
 - Verify that the power switch on the booster unit is in the 'ON' position.

7. SPECIFICATIONS

Feature	Detail
Brand	Hot Wheels
Model Number	W3422
Manufacturer Minimum Age	48.0 Months
Manufacturer Maximum Age	144.0 Months
Item Dimensions (LxWxH)	20 x 2.75 x 12 inches
Item Weight	1 Pound
Number of Pieces	1 (Trackset components)
Assembly Required	No (Refers to the product being a single unit, but user assembly of track is required)
Remote Included	No

8. WARRANTY AND SUPPORT

This Hot Wheels product is covered by a 1-year manufacturer warranty against defects. For warranty claims or technical support, please refer to the contact information provided in the original product packaging or visit the official Hot Wheels

website for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0060RZK5C>

More documents and user manuals: <https://manuals.plus/>