

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lorell](#) /
- › [Lorell LLR66125 Accord Mid-Back Task Chair User Manual](#)

Lorell LLR 66125

Lorell LLR66125 Accord Mid-Back Task Chair User Manual

Model: LLR 66125

INTRODUCTION

Thank you for choosing the Lorell LLR66125 Accord Mid-Back Task Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.





Figure 1: Lorell LLR66125 Accord Mid-Back Task Chair. This image shows the complete chair from a front-angle view, highlighting its grey fabric, black frame, and adjustable armrests.

SAFETY INFORMATION

For your safety and to prevent damage to the product, please observe the following guidelines:

- **Maximum Weight Capacity:** This chair is designed to support a maximum weight of **275 pounds (124.7 kg)**. Do not exceed this limit.
- **Proper Assembly:** Ensure all components are correctly assembled and tightened according to the instructions before using the chair. Improper assembly can lead to instability and injury.
- **Adjustable Mechanisms:** Exercise caution when operating adjustable mechanisms such as the 360-degree swivel, tilt lock, and asynchronous control. Avoid sudden movements or excessive force.
- **Stable Surface:** Always use the chair on a stable, level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the chair during assembly and adjustment to prevent accidents.

ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please ensure all parts are present before beginning. A detailed assembly guide with diagrams is typically included in the product packaging. If you are missing parts or the assembly guide, please contact Lorell customer support.

General Assembly Steps (Typical for Task Chairs):

1. Unpack all components and verify against the parts list.
2. Attach the casters (wheels) to the chair base.
3. Insert the pneumatic gas lift cylinder into the center of the chair base.
4. Attach the seat plate mechanism to the underside of the seat cushion.
5. Secure the backrest to the seat plate mechanism.
6. Attach the armrests to the seat cushion.
7. Place the assembled seat and back onto the pneumatic gas lift cylinder.
8. Test all functions to ensure proper operation and stability.

Note: Specific steps and hardware may vary. Always refer to the detailed instructions provided with your product.

OPERATING INSTRUCTIONS

The Lorell LLR66125 Accord Mid-Back Task Chair features multiple adjustments to customize your seating experience for optimal comfort and support.

Adjustable Features:

- **Pneumatic Seat Height Adjustment:**

To raise the seat, lift the lever located under the seat on the right side while taking your weight off the seat. To lower the seat, lift the lever while seated. The seat height adjusts from approximately 18.1 inches to 21.7 inches from the floor.

- **Back Height Adjustment:**

To adjust the backrest height, loosen the knob at the back of the chair, slide the backrest up or down to your desired position, and then tighten the knob securely.

- **Armrest Width Adjustment:**

The armrests can be adjusted in width from 18 inches to 19.5 inches. Locate the adjustment mechanism (usually a knob or lever) beneath the armrests and adjust as needed for better positioning.

- **360-Degree Swivel:**

The chair features a full 360-degree swivel for easy movement and access to your workspace.

- **Tilt Tension Control:**

The tilt tension knob, typically located under the seat at the front, controls the amount of force required to recline the chair. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).

- **Tilt Lock:**

To lock the chair in an upright position, push the tilt lever (often combined with the seat height lever) inwards. To unlock and allow reclining, pull the lever outwards.

- **Asynchronous Control:**

This feature allows independent adjustment of the seat and backrest angles. Use the separate levers to adjust the seat tilt and backrest tilt to your preferred ergonomic position.

- **Waterfall Seat Edge:**

The contoured waterfall seat edge is designed to provide under-thigh support and reduce pressure on your legs.

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your Lorell task chair.

- **Cleaning:** The fabric is 100% polyester. For general cleaning, **spot clean** with a mild detergent and a damp cloth. Avoid harsh chemicals or abrasive cleaners.

- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary.
- **Casters:** Keep casters clean and free of debris to ensure smooth movement.
- **Avoid Overloading:** Do not exceed the maximum weight capacity of 275 lbs.

TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common solutions:

- **Chair is unstable/wobbly:**
Ensure all assembly bolts and screws are securely tightened. Check that the chair is on a level surface.
- **Seat height adjustment not working:**
Verify that the pneumatic gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Chair does not recline or recline too easily/stiffly:**
Check the tilt lock lever to ensure it is in the unlocked position. Adjust the tilt tension knob to increase or decrease resistance.
- **Casters not rolling smoothly:**
Inspect casters for hair, dust, or debris and clean as necessary. Ensure they are properly inserted into the chair base.

For issues not covered here, please contact Lorell customer support.

SPECIFICATIONS



Figure 2: Lorell LLR66125 Accord Mid-Back Task Chair with key dimensions. This image illustrates the chair's overall height (39.25 inches), width (26.75 inches), and depth (26 inches).

Feature	Detail
Brand	Lorell

Feature	Detail
Model Number	LLR 66125
Product Dimensions (D x W x H)	26"D x 26.75"W x 39.25"H
Item Weight	50.7 pounds (23 kg)
Maximum Load Capacity	275 pounds (124.7 kg)
Seat Material	100% Polyester Fabric
Seat Color	Grey
Frame Color	Black
Minimum Seat Height	18.1 inches (46 cm)
Maximum Seat Height	21.7 inches (55.1 cm)
Armrest Width Adjustment	18 inches to 19.5 inches
Back Style	Solid Back, Mid-Back
Special Features	Tilt Tension, Tilt Lock, Adjustable Arms, Waterfall Seat Edge, Back Height Adjustment, Seat Height Adjustment, Synchro Tilt, 360-degree Swivel, Asynchronous Control
Assembly Required	Yes
Country of Origin	Taiwan
Certifications & Standards	ANSI/BIFMA

WARRANTY INFORMATION

The Lorell LLR66125 Accord Mid-Back Task Chair comes with a **5-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, please refer to the documentation included with your product or contact Lorell customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to make a warranty claim, please contact Lorell customer support. You can find more information and contact details on the official Lorell website or through your retailer.

Visit the official Lorell Store: [Lorell Store on Amazon](#)



