

LILLIPUT FA1011-NP/C

LILLIPUT FA1011-NP/C 10.1-inch Field HD Monitor User Manual

Model: FA1011-NP/C

- Introduction
- Package Contents
- Parts Diagram
- Setup
- Operating
- Maintenance
- Troubleshooting
- Specifications
- Warranty & Support

1. INTRODUCTION

The LILLIPUT FA1011-NP/C is a 10.1-inch non-touch field HD monitor designed for professional and enthusiast photographers and videographers. It provides a clear and accurate display for on-camera monitoring, featuring multiple input options including HDMI, DVI, VGA, and AV. This manual provides detailed instructions for the proper setup, operation, and maintenance of your monitor to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact your retailer immediately.

- LILLIPUT FA1011-NP/C 10.1-inch Field HD Monitor
- Power Adapter (12V DC)
- HDMI Cable
- Monitor Stand
- Sun Hood
- User Manual

3. PARTS DIAGRAM

3.1 Front View



Figure 3.1: Front view of the LILLIPUT FA1011-NP/C monitor, showing the 10.1-inch display, control buttons (Menu, A/V, Power, navigation arrows), and the LILLIPUT branding. The detachable sun hood is also visible, designed to reduce glare in bright environments.

3.2 Rear View and Connections



Figure 3.2: Rear view of the LILLIPUT FA1011-NP/C monitor, highlighting the various input and power ports. These include the 12V DC power input, HDMI port, DVI port, VGA port, and AV input. A battery plate for portable power solutions and mounting points are also visible.

4. SETUP

4.1 Mounting the Monitor

Attach the provided monitor stand to the bottom of the monitor using the designated screw hole. For on-camera use, secure the monitor to your camera rig or hot shoe mount using a compatible mounting arm (sold separately) via the monitor's mounting points.

4.2 Power Connection

1. Connect the 12V DC power adapter to the monitor's power input port on the rear.
2. Plug the power adapter into a suitable electrical outlet.
3. Alternatively, for portable use, attach a compatible battery to the battery plate on the rear of the monitor.

4.3 Video Input Connection

Connect your video source (e.g., DSLR camera, camcorder, PC) to the monitor using one of the available input ports:

- **HDMI:** Use an HDMI cable to connect your device's HDMI output to the monitor's HDMI input.
- **DVI:** Use a DVI cable to connect your device's DVI output to the monitor's DVI input.
- **VGA (PC):** Use a VGA cable to connect your device's VGA output to the monitor's VGA input.
- **AV1/AV2:** Use an AV cable to connect your device's AV output to either AV1 or AV2 input.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the **Power** button located on the front panel to turn the monitor on or off. The power indicator light will illuminate when the monitor is on.

5.2 Input Selection

Press the **A/V** button on the front panel to cycle through the available video inputs (HDMI, DVI, VGA, AV1, AV2) until your desired source is displayed.

5.3 Menu Navigation

Press the **MENU** button to access the On-Screen Display (OSD) menu. Use the navigation arrow buttons (←, →, ^, v, if applicable, or the A/V button for selection) to navigate through menu options and adjust settings. Press **MENU** again to exit the OSD.

5.4 Picture Adjustments

Within the OSD menu, you can adjust various picture settings:

- **Brightness:** Adjusts the overall luminance of the display.
- **Contrast:** Controls the difference between the brightest and darkest areas of the image.
- **Color/Saturation:** Adjusts the intensity of colors.
- **Hue:** Shifts the color balance (primarily for NTSC video).
- **Aspect Ratio:** Selects the display ratio (e.g., 16:9, 4:3).

6. MAINTENANCE

6.1 Cleaning the Monitor

- Always power off and unplug the monitor before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive screen cleaner to wipe the display surface.
- Do not use harsh chemicals, alcohol, or abrasive materials, as these can damage the screen or casing.
- For the casing, use a dry, soft cloth.

6.2 Storage

- When not in use, store the monitor in a cool, dry place, away from direct sunlight and extreme temperatures.

- If storing for an extended period, it is recommended to place the monitor back in its original packaging or a protective case.

7. TROUBLESHOOTING

If you encounter issues with your monitor, please refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cable disconnected; Power adapter faulty; Battery depleted	Ensure power cable is securely connected. Check power adapter. Recharge or replace battery.
No signal / Black screen	Incorrect input selected; Video cable loose or faulty; Source device not outputting signal	Press A/V button to select correct input. Check video cable connections. Verify source device is on and outputting video.
Poor picture quality (blurry, distorted)	Incorrect resolution; Faulty cable; Picture settings incorrect	Ensure source resolution matches monitor's native resolution (1024x600). Try a different video cable. Adjust brightness, contrast, and sharpness in OSD menu.
Buttons unresponsive	Temporary software glitch	Power off the monitor, wait a few seconds, then power it back on.

8. SPECIFICATIONS

The following are the technical specifications for the LILLIPUT FA1011-NP/C monitor:

Feature	Detail
Model	FA1011-NP/C
Screen Size	10.1 Inches
Screen Resolution	1024x600
Input Signals	AV1, AV2, PC (VGA), HDMI, DVI
Brightness	250cd/
Voltage	12 Volts
Item Weight	1.12 pounds
Product Dimensions (LxWxH)	1.38 x 9.98 x 6.4 inches
Color	Black

9. WARRANTY AND SUPPORT

9.1 Product Warranty

The LILLIPUT FA1011-NP/C monitor comes with a one-year limited warranty. For customers in the USA, warranty service is provided by VIVITEQ, the official USA seller. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions.

9.2 Technical Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact your point of purchase or the official LILLIPUT distributor in your region. For USA customers, contact VIVITEQ for support.

© 2023 LILLIPUT. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0063FJBQ0>

More documents and user manuals: <https://manuals.plus/>