



Manuals.plus /

› Ingersoll /

› Ingersoll IN2803BGR Bison No.12 Stainless Steel Men's Watch User Manual

Ingersoll IN2803BGR

Ingersoll IN2803BGR Bison No.12 Stainless Steel Men's Watch User Manual

Model: IN2803BGR

INTRODUCTION

Welcome to the user manual for your new Ingersoll IN2803BGR Bison No.12 Stainless Steel Men's Watch. This timepiece combines classic design with robust functionality, featuring an automatic movement, day, date, and 24-hour functions. Crafted with a durable stainless steel case and a comfortable black leather strap, this watch is designed for daily wear. Please read this manual carefully to understand the proper setup, operation, and maintenance of your watch.



Image: Front view of the Ingersoll IN2803BGR Bison No.12 watch. It features a black dial with luminous hour markers and hands, three

sub-dials, and a day/date window at the 3 o'clock position. The watch has a black leather strap with green stitching and a stainless steel case.

SETUP AND INITIAL WINDING

Your Ingersoll Bison No.12 watch is equipped with an automatic movement, which means it is powered by the motion of your wrist. For initial setup or if the watch has stopped due to lack of wear, follow these steps:

- Manual Winding:** Gently unscrew the crown (if it's a screw-down crown) and pull it out to position 1. Rotate the crown clockwise approximately 20-30 times. This will provide enough power reserve to start the watch.
- Setting the Date and Day:** Pull the crown out to position 2. Rotate the crown to set the date and day. It is recommended to set the date and day to the previous day/date, then proceed to set the time.
- Setting the Time:** Pull the crown out to position 3 (farthest position). Rotate the crown to advance the hands clockwise until the current date and day change to the correct ones. Continue rotating to set the correct time, ensuring you distinguish between AM and PM for the 24-hour function.
- Secure the Crown:** Once all settings are complete, push the crown back into position 0 (fully in) and screw it down firmly (if applicable) to ensure water resistance.

The watch will continue to operate as long as it is worn regularly. If not worn for an extended period, it may stop and require manual winding again.

OPERATING YOUR WATCH

Your Ingersoll Bison No.12 watch features several functions for precise timekeeping and utility:

- Time Display:** The main hour, minute, and second hands indicate the current time. The luminous coating on the hands and markers ensures readability in low light conditions.
- Day and Date Display:** Located at the 3 o'clock position, the window displays the current day of the week and the numerical date. These functions automatically advance at midnight.
- 24-Hour Sub-dial:** One of the sub-dials indicates the time in a 24-hour format, which is useful for tracking military time or distinguishing between AM and PM at a glance.
- Additional Sub-dials:** The watch features additional sub-dials, which may include a small seconds hand or other indicators depending on the specific movement. Refer to the visual guide for their exact functions.

MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your Ingersoll watch.

- Water Resistance (30m):** Your watch is water resistant to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in and screwed down (if applicable) before any contact with water.
- Cleaning:** Wipe the watch case and crystal with a soft, dry, lint-free cloth. For the leather strap, avoid excessive moisture and harsh chemicals. If the strap gets wet, allow it to air dry naturally away from direct heat.
- Temperature and Magnetic Fields:** Avoid exposing your watch to extreme temperatures (hot or cold) or strong magnetic fields, as these can affect the accuracy of the automatic movement.
- Storage:** When not wearing the watch, store it in a cool, dry place, preferably in its original box or a watch winder to keep the automatic movement running.

TROUBLESHOOTING

If you encounter any issues with your watch, consider the following common solutions:

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Insufficient power reserve (automatic movement).	Manually wind the watch by rotating the crown 20-30 times. Wear the watch regularly to keep it wound.
Date/Day not changing at midnight.	Time is set to AM instead of PM, or vice versa.	Advance the time by 12 hours. Ensure the watch passes midnight to confirm the date/day change.
Condensation under the crystal.	Exposure to extreme temperature changes or moisture ingress.	Avoid extreme temperature changes. If condensation persists, seek professional service immediately to prevent damage.

For issues not listed here or if solutions do not resolve the problem, please contact customer support.

SPECIFICATIONS

- **Model Number:** IN2803BGR
- **Movement:** Automatic
- **Case Material:** Stainless Steel
- **Dial Color:** Black
- **Strap Material:** Black Leather
- **Functions:** Day, Date, 24-Hour Display
- **Water Resistance:** 30 meters (3 ATM)

WARRANTY AND SUPPORT

Your Ingersoll IN2803BGR Bison No.12 watch comes with a **3-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims or technical support, please contact your authorized Ingersoll dealer or the official Ingersoll customer service. Keep your proof of purchase for warranty validation.

Note: Specific contact details for support may vary by region. Please refer to the Ingersoll official website or your purchase documentation for the most accurate support information.

