

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Rev-A-Shelf](#) /
- › [Rev-A-Shelf 11 Inch Tip-Out Front Sink Tray Set Instruction Manual](#)

Rev-A-Shelf 6572-11W-5

Rev-A-Shelf 11 Inch Tip-Out Front Sink Tray Set Instruction Manual

Model: 6572-11W-5 | Brand: Rev-A-Shelf

PRODUCT OVERVIEW

The Rev-A-Shelf 6572 Series Tip-Out Tray Set provides convenient storage solutions for items typically kept around the sink area. Designed to utilize the false front panel of a sink cabinet, this set offers easy access to sponges, brushes, and other small kitchen or bathroom essentials.

Key features include:

- Two white polymer tip-out trays.
- Two sets of self-hold in hinges for secure installation.
- Suitable for both kitchen and bathroom applications.
- Designed to mount to sink front panels.

COMPONENTS INCLUDED

The Rev-A-Shelf 6572-11W-5 Tip-Out Tray Set includes the following components:

- 1 x Conventional Open Tray (White, High-Impact Polystyrene)
- 1 x Accessory Tray with Ring Holder and Soap Dish (White, High-Impact Polystyrene)
- 2 x Pairs of Self-Hold in Hinges

SETUP AND INSTALLATION

Proper installation of the Rev-A-Shelf Tip-Out Tray Set ensures optimal functionality and durability. This product is designed to be installed into the false front panel of a sink cabinet.



Image: Rev-A-Shelf Tip-Out Trays installed under a kitchen sink, demonstrating how the trays pivot out from the cabinet's false front, providing accessible storage for sink-side items like sponges and soap.

Installation Steps:

1. **Prepare the Cabinet:** Ensure the false front panel of your sink cabinet is removable and has sufficient clearance behind it for the trays and hinges.
2. **Attach Hinges to Trays:** Securely attach one hinge to each end of both tip-out trays using appropriate fasteners (not typically included, as they depend on cabinet material). Ensure the hinges are oriented correctly for the desired pivot action.
3. **Mount Hinges to Cabinet Frame:** Position the trays with attached hinges against the inside of the cabinet frame where the false front panel will be. Mark the screw holes for the hinges on the cabinet frame.
4. **Secure Hinges:** Drill pilot holes if necessary, then securely fasten the hinges to the cabinet frame. Ensure the trays can pivot freely without obstruction.
5. **Attach False Front Panel:** Reattach the false front panel to the front of the installed trays. The hinges are designed to hold the panel in place, allowing it to tip out with the trays. Adjust as needed for proper alignment and smooth operation.
6. **Test Operation:** Gently open and close the tip-out trays to ensure they operate smoothly and securely.

For detailed diagrams and specific fastener recommendations, refer to the manufacturer's official installation guide, typically included with the product packaging.

OPERATION

Operating the Rev-A-Shelf Tip-Out Tray Set is straightforward:

- To access the trays, gently pull the top edge of the false front panel forward. The panel will pivot downwards, revealing the trays.
- Place or retrieve items such as sponges, scrub brushes, or small cleaning supplies from the trays.
- To close, simply push the false front panel upwards until it is flush with the cabinet face. The self-hold hinges will keep it securely closed.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your Rev-A-Shelf Tip-Out Tray Set:

- **Cleaning Trays:** The high-impact polystyrene trays can be easily cleaned. Wipe with a dry cloth for light dust. For more thorough cleaning, the trays are dishwasher safe. Remove them from the hinges before placing in a dishwasher.
- **Cleaning Hinges:** Wipe the metal hinges with a dry cloth to remove dust or debris. Avoid using abrasive cleaners or harsh chemicals on the hinges.
- **General Care:** Avoid placing excessively heavy items in the trays, as the maximum weight recommendation is 5 pounds.

TROUBLESHOOTING

If you encounter issues with your tip-out tray set, consider the following:

- **Trays not closing flush:** Check for any obstructions behind the trays or within the cabinet opening. Ensure the hinges are properly aligned and not bent.
- **Trays feel loose or wobbly:** Verify that all screws securing the hinges to the cabinet frame are tightened. Over time, screws may loosen and require re-tightening.
- **Difficulty opening/closing:** Ensure the hinges are clean and free of debris. A small amount of silicone spray (avoiding contact with the trays) can be applied to hinge pivot points if movement is stiff, but this is rarely needed for self-hold hinges.

SPECIFICATIONS






Brand	Rev-A-Shelf
Model Number	6572-11W-5
Color	White
Product Dimensions (L x W x H)	11.6"L x 5.2"W x 2.5"H (Trays)
Item Weight	1.43 pounds
Material	High-Impact Polystyrene (Trays)
Maximum Weight Recommendation	5 Pounds
Dishwasher Safe	Yes (Trays only)
UPC	090713523194

WARRANTY AND SUPPORT

Specific warranty information for the Rev-A-Shelf 11 Inch Tip-Out Front Sink Tray Set (Model 6572-11W-5) is not provided in this manual. For details regarding product warranty, returns, or technical support, please contact Rev-A-Shelf directly through their official website or customer service channels.

You can typically find contact information on the manufacturer's packaging or by visiting the [Rev-A-Shelf Store on Amazon](#) or their corporate website.

Related Documents - 6572-11W-5

	<p>Rev-A-Shelf Tip-Out Tray System Installation Instructions</p> <p>Comprehensive installation guide for the Rev-A-Shelf Tip-Out Tray System, covering hinge types, tray assembly, and mounting for polymer and slim series trays. Includes tools required, helpful hints, and customer support contact.</p>
	<p>Rev-A-Shelf Soft-Close Tip-Out Trays Installation Instructions</p> <p>Step-by-step guide for installing Rev-A-Shelf's soft-close tip-out trays in sink base cabinets. Includes tools required, parts list, and detailed instructions for preparing panels, mounting hinges, and attaching trays.</p>
	<p>Rev-A-Shelf Cutlery Tray Installation Guide</p> <p>Comprehensive installation instructions for the Rev-A-Shelf Cutlery Tray (Model I-CT-0825), detailing measurement, trimming, and care. Enhance your kitchen drawer organization with this guide.</p>
	<p>Rev-A-Shelf Door-Mount Kit Installation Instructions</p> <p>Comprehensive guide for installing the Rev-A-Shelf Door-Mount Kit, detailing parts, tools, and step-by-step assembly for cabinet doors.</p>
	<p>Rev-A-Shelf Heavy-Duty Mixer Lift Installation Instructions</p> <p>Detailed installation guide for the Rev-A-Shelf Heavy-Duty Mixer Lift, including tools required, parts list, preparation steps, and adjustment instructions for optimal performance.</p>

[Rev-A-Shelf Door-Mounting Kit Installation Guide | Model I-5WB-DMKIT-0725](#)

Official installation instructions for the Rev-A-Shelf Door-Mounting Kit (Model I-5WB-DMKIT-0725). Learn how to attach door-mount brackets to cabinet slides and doors for improved organization. Includes parts list, tools required, and step-by-step guidance.