

[Manuals.plus](#) /

› [Rev-A-Shelf](#) /

› Rev-A-Shelf 2-Tier Pull-Out Cabinet Organizer User Manual (Model 59-12C-2-5)

Rev-A-Shelf 59-12C-2-5

Rev-A-Shelf 2-Tier Pull-Out Cabinet Organizer User Manual

Model: 59-12C-2-5

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup &](#)
[Installation](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Rev-A-Shelf 2-Tier Pull-Out Cabinet Organizer. This product is designed to enhance the organization and accessibility of items within your kitchen or pantry cabinets. Its two-tier design maximizes vertical storage space, while the smooth pull-out mechanism provides easy access to contents. Please read this manual thoroughly before installation and use to ensure proper setup and long-term performance.



Image 1.1: The Rev-A-Shelf 2-Tier Pull-Out Cabinet Organizer, Model 59-12C-2-5, shown installed in a base cabinet. This image illustrates the two-tier design and the pull-out functionality, providing a visual representation of the product's appearance and how it fits into a cabinet space.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product and your cabinet:

- **Read all instructions:** Ensure you understand all installation and operation steps before proceeding.
- **Proper tools:** Use appropriate tools for installation. Refer to the "Tools Required" section.
- **Weight capacity:** Do not exceed the maximum weight capacity of the organizer. Overloading can cause damage or instability.
- **Secure installation:** Ensure the organizer is securely fastened to the cabinet base according to the instructions. Loose installation can lead to tipping or detachment.
- **Pinch points:** Keep hands and fingers clear of moving parts, especially during installation and when pulling the organizer in or out.
- **Not for wet use:** This product is not designed for use in wet conditions. Exposure to water can lead to rust and

affect the functionality of the slides.

- **Children and pets:** Keep children and pets away from the installation area. Do not allow them to play with or hang on the organizer.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, please contact customer support.

- (1) 2-Tier Pull-Out Organizer Frame with Baskets
- (1) Pair of Full-Extension Ball-Bearing Slides (pre-attached or separate)
- (1) Mounting Bracket/Base
- (4-8) Mounting Screws (for cabinet base)
- (Optional) Door Mount Brackets and Screws
- (1) Instruction Manual

4. SETUP & INSTALLATION

4.1 Tools Required

- Measuring Tape
- Pencil
- Phillips Head Screwdriver or Power Drill with Phillips Bit
- Level
- (Optional) Awl or Center Punch

4.2 Installation Steps

1. Prepare the Cabinet:

Clear the cabinet of all contents. Ensure the cabinet floor is clean and free of debris. Measure the interior width, depth, and height of your cabinet to confirm it accommodates the organizer's dimensions (refer to specifications).

2. Position the Mounting Bracket:

Place the mounting bracket/base of the organizer inside the cabinet. Position it to allow sufficient clearance for the cabinet door and any hinges. Typically, the front edge of the bracket should be set back slightly from the cabinet opening to prevent interference with the door when closed. Use a measuring tape to ensure it is centered or positioned as desired.

3. Mark Mounting Holes:

Once the bracket is in the desired position, use a pencil to mark the locations of the mounting holes on the cabinet floor. Ensure the bracket is level before marking.

4. Drill Pilot Holes (Optional but Recommended):

For easier installation and to prevent wood splitting, drill small pilot holes at the marked locations. Use a drill bit slightly smaller than the diameter of the mounting screws.

5. Secure the Mounting Bracket:

Align the mounting bracket with the pilot holes (if drilled) and secure it to the cabinet floor using the provided mounting screws. Tighten screws firmly but do not overtighten.

6. Attach the Organizer Frame:

If the slides are separate from the frame, attach them to the frame according to the specific instructions provided

with your unit. Then, align the organizer frame (with slides) onto the secured mounting bracket. The slides should engage smoothly with the bracket's runners.

7. **Test Operation:**

Gently pull the organizer out and push it back in to ensure smooth operation. Check for any binding or resistance. Adjust the mounting bracket slightly if necessary to achieve optimal movement.

8. **(Optional) Door Mounting:**

If your model includes door mounting brackets, follow the separate instructions provided to attach the cabinet door directly to the organizer. This allows the organizer to pull out automatically when the door is opened.

5. **OPERATING INSTRUCTIONS**

Using your Rev-A-Shelf 2-Tier Pull-Out Cabinet Organizer is straightforward:

- **Pulling Out:** Grasp the front of the organizer or the cabinet door (if door-mounted) and gently pull it towards you. The full-extension slides will allow the entire organizer to extend out of the cabinet, providing complete access to both tiers.
- **Pushing In:** To close, simply push the organizer back into the cabinet until it is fully recessed. Ensure no items are obstructing its path.
- **Loading:** Distribute items evenly across both tiers. Place heavier items on the bottom tier for stability. Do not exceed the recommended weight capacity.

6. **MAINTENANCE**

Regular maintenance will ensure the longevity and smooth operation of your organizer:

- **Cleaning:** Wipe down the baskets and frame with a soft, damp cloth and mild soap as needed. Avoid abrasive cleaners or harsh chemicals, which can damage the finish. Dry thoroughly.
- **Slide Lubrication:** Periodically check the ball-bearing slides. If they begin to feel stiff or noisy, apply a small amount of silicone-based lubricant to the slide mechanisms. Do not use oil-based lubricants, as they can attract dust and debris.
- **Fastener Check:** Every few months, check all mounting screws to ensure they are still tight. Retighten if necessary.
- **Avoid Wet Conditions:** As noted in safety, avoid exposing the organizer to wet conditions to prevent rust and damage to the slides.

7. **TROUBLESHOOTING**

Problem	Possible Cause	Solution
Organizer does not slide smoothly.	◦ Slides are dirty or dry. ◦ Mounting screws are loose. ◦ Organizer is overloaded or unevenly loaded. ◦ Misalignment during installation.	◦ Clean slides and apply silicone lubricant. ◦ Check and tighten all mounting screws. ◦ Reduce weight or redistribute items. ◦ Re-check alignment and adjust mounting bracket if necessary.

Problem	Possible Cause	Solution
Organizer rubs against cabinet door/frame.	◦ Improper positioning during installation. ◦ Cabinet door hinges are misaligned.	◦ Adjust the mounting bracket to provide adequate clearance. ◦ Check and adjust cabinet door hinges.
Rust spots appear on the organizer.	◦ Exposure to moisture or wet conditions.	◦ Ensure the cabinet environment is dry. Avoid storing wet items directly on the organizer.

8. SPECIFICATIONS

Feature	Detail
Model Number	59-12C-2-5
Product Dimensions	0.75 x 0.75 x 0.75 inches <i>(Note: These dimensions appear to be packaging or partial dimensions. Actual installed dimensions will vary based on cabinet size and specific model variant. Please measure your cabinet carefully.)</i>
Item Weight	17.16 pounds
Tiers	2
Slide Type	Full-Extension Ball-Bearing
Material	Typically heavy-gauge wire construction <i>(Specific material not provided, but common for Rev-A-Shelf organizers)</i>

Note: Product specifications are subject to change without notice. Always refer to the packaging or manufacturer's website for the most current information. The provided product dimensions (0.75 x 0.75 x 0.75 inches) seem unusually small for a cabinet organizer and may represent packaging or a component dimension. Users should verify actual product dimensions for their specific cabinet.

9. WARRANTY & SUPPORT

Rev-A-Shelf products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Rev-A-Shelf website. In most cases, a limited lifetime warranty covers manufacturing defects.

For technical assistance, missing parts, or warranty claims, please contact Rev-A-Shelf customer support directly. Contact information can typically be found on their official website or on the product packaging.

Online Support: www.rev-a-shelf.com/support

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question