

Manuals.plus /

> [Alessi](#) /

> Alessi MW05/15 Dressed Bottle Coaster User Manual

Alessi MW05/15

Alessi MW05/15 Dressed Bottle Coaster User Manual

Model: MW05/15 | Brand: Alessi

INTRODUCTION

This manual provides essential information for the proper use and care of your Alessi MW05/15 Dressed Bottle Coaster. Designed by Marcel Wanders, this mirror-polished 18/10 stainless steel coaster features a unique embossed decoration, intended to subtly enhance your table setting while protecting surfaces from condensation and spills.

PRODUCT OVERVIEW

Figure 1: Alessi MW05/15 Dressed Bottle Coaster (Top View)

This image displays the Alessi MW05/15 Dressed Bottle Coaster from a top-down perspective, highlighting its circular shape, polished stainless steel finish, and the detailed embossed pattern that covers its surface. The pattern features flowing, organic lines with a central, stylized face design.

Figure 2: Alessi MW05/15 Dressed Bottle Coaster (Side View)

This image shows the Alessi MW05/15 Dressed Bottle Coaster from a slight side angle, emphasizing its slim profile and the smooth, polished rim. The embossed pattern on the top surface is still visible, providing texture to the design.

The Alessi MW05/15 Dressed Bottle Coaster is crafted from high-quality 18/10 stainless steel, ensuring durability and a brilliant finish. Its design is both functional and aesthetically pleasing, making it a suitable addition to various table settings.

SETUP

The Alessi MW05/15 Dressed Bottle Coaster requires no assembly or complex setup. It is ready for immediate use upon unboxing.

- Unpack:** Carefully remove the coaster from its packaging.
- Inspect:** Check the coaster for any signs of damage during transit. If damaged, contact customer support.
- Clean:** Before first use, wash the coaster according to the "Maintenance" instructions to remove any manufacturing residues.
- Placement:** Place the coaster on a flat, stable surface where you intend to serve beverages.

OPERATING INSTRUCTIONS

The Alessi MW05/15 Dressed Bottle Coaster is designed for straightforward use.

- **Purpose:** Use the coaster to protect table surfaces from condensation rings, spills, and heat marks from bottles, carafes, or other beverage containers.
- **Placement of Bottle:** Gently place the bottle or container directly onto the center of the coaster. Ensure the base of the bottle fits within the coaster's diameter (14.5 cm).
- **Stability:** The coaster provides a stable base for bottles. Avoid placing excessively heavy or unstable items on it.



Figure 3: Coaster in Hand for Scale

This image shows the Alessi MW05/15 Dressed Bottle Coaster being held by a hand, providing a clear sense of its size and how easily it can be handled and placed on a surface.



Figure 4: Size Comparison (MW05/15 vs. MW05/12)

This image presents a side-by-side comparison of two Alessi Dressed coasters. The larger one on the left is the MW05/15 bottle coaster, and the smaller one on the right is the MW05/12 glass coaster, illustrating their distinct sizes for different uses.

MAINTENANCE

Proper care will ensure the longevity and pristine appearance of your Alessi Dressed Bottle Coaster.

- **Cleaning:** It is recommended to **hand wash only** the coaster. Use warm water with a mild dish soap and a soft cloth or sponge.
- **Drying:** Immediately after washing, dry the coaster thoroughly with a soft, lint-free cloth to prevent water spots and maintain its polished finish.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch the stainless steel surface and damage the finish.
- **Storage:** Store the coaster in a dry place when not in use.

TROUBLESHOOTING

Most issues with the Alessi MW05/15 Dressed Bottle Coaster can be resolved with simple steps.

Problem	Possible Cause	Solution
Water spots or streaks on surface.	Improper drying after washing; hard water residue.	Ensure thorough drying with a soft, lint-free cloth immediately after washing. For stubborn spots, use a stainless steel cleaner or a mixture of vinegar and water, then rinse and dry.
Scratches on surface.	Use of abrasive cleaning materials or contact with sharp objects.	Avoid abrasive cleaners and materials. Handle with care. Minor scratches may be polished out with specialized stainless steel polish, but deep scratches are permanent.
Dull finish.	Accumulation of oils or residues; lack of proper polishing.	Clean regularly as per maintenance instructions. Use a soft cloth to buff the surface after drying to restore its shine.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	MW05/15
Material	18/10 Stainless Steel
Finish	Mirror Polished with Embossed Decoration
Diameter	14.5 cm (5.7 inches)
Height	Approximately 1.02 cm (0.4 inches)
Weight	160 grams (0.35 lbs)
Care Instructions	Hand wash only

WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the official Alessi website or contact Alessi customer service directly. Keep your proof of purchase for any warranty claims.

- **Alessi Official Website:** www.alessi.com
- **Customer Service:** Refer to the "Contact Us" section on the official website for regional contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0067KB9QQ>

More documents and user manuals: <https://manuals.plus/>