Homestyle4u HOMESTYLE4U_539

Homestyle4u Solid Pine Bunk Bed with Pink/Red Curtain Instruction Manual

Model: HOMESTYLE4U_539 | Brand: Homestyle4u

Introduction

This manual provides detailed instructions for the assembly, safe operation, and maintenance of your Homestyle4u Solid Pine Bunk Bed with Pink/Red Curtain. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Homestyle4u Solid Pine Bunk Bed with Pink/Red Curtain, featuring a slide and play tunnel, set up in a child's room.

Safety Information

- Always ensure all bolts and screws are securely tightened. Check periodically and re-tighten as necessary.
- The top bunk is not suitable for children under 6 years of age.
- Ensure the bed is placed on a level surface.
- Do not allow children to jump on the bed or slide.
- Regularly inspect the bed for any signs of wear or damage. Discontinue use if damage is found.
- Maximum recommended weight for the bed is 70 kg (154.3 lbs).
- The bed includes fall protection; ensure it is always properly installed.

Setup and Assembly

Assembly requires two adults. Please lay out all components and hardware before beginning. Refer to the included assembly diagram for specific part identification.

Required Tools:

- Screwdriver (Phillips head)
- Allen wrench (usually included)
- Hammer (optional, for dowels)

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list.
2. **Assemble Bed Frame:** Connect the side rails to the headboard and footboard using the provided hardware. Ensure all connections are secure.
3. **Install Slatted Base:** Place the wooden slats onto the bed frame supports. Ensure they are evenly spaced and secured if applicable.
4. **Attach Ladder:** Securely attach the ladder to the designated side of the bed frame.
5. **Attach Slide:** Mount the slide to the bed frame according to the diagram. Ensure all connection points are firm and stable.
6. **Install Curtain and Tunnel:** Drape and secure the pink/red curtain and tunnel fabric components as shown in the product images.
7. **Final Check:** Double-check all screws, bolts, and connections to ensure the bed is stable and safe for use.



Image: Detailed view of the bed frame connections and assembly points, showing secure bolt and dowel placements.




Image: Technical diagram illustrating the overall dimensions of the bunk bed, including height, length, width, and slide measurements.

Operating Instructions

This bunk bed is designed for sleeping and recreational play.

- **Sleeping:** Ensure a mattress of compatible size (90 x 200 cm / 35.4 x 78.7 inches) is used. The top bunk is intended for children aged 6 and above.
- **Ladder Use:** Always use the ladder to access the top bunk. Do not climb on the bed frame directly.
- **Slide Use:** The slide is for single-person use only. Ensure the area around the slide exit is clear before use. Supervise children during slide use.
- **Curtain and Tunnel:** The fabric curtain and tunnel provide a play area. Ensure they are securely attached and do not obstruct movement or ventilation.



Image: Close-up view of the slide securely attached to the bunk bed frame, highlighting the connection points.

Maintenance and Care

- **Cleaning the Wood:** Wipe wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning the Fabric:** The pink/red curtain and tunnel can be spot cleaned with a mild detergent and water. Refer to any specific care labels on the fabric.
- **Hardware Check:** Periodically check all screws, bolts, and connections for tightness. Re-tighten as needed to maintain structural integrity.
- **Inspection:** Regularly inspect the bed for any splinters, cracks, or loose parts. Address any issues immediately to prevent injury.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware.	Check and tighten all screws and bolts. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections or friction between wood parts.	Re-tighten all hardware. Apply a small amount of wax or lubricant to friction points if necessary.
Slide or ladder feels loose.	Improper attachment or loose fasteners.	Verify that the slide and ladder are correctly installed and all mounting hardware is fully tightened.
Missing parts during assembly.	Packaging error.	Contact Homestyle4u customer support with your model number and a list of missing parts.

Product Specifications

Feature	Detail
Brand	Homestyle4u
Model Number	HOMESTYLE4U_539
Color	Red (with Pink/Red curtain)
Material	Solid Pine Wood
Product Dimensions (L x W x H)	208 x 97 x 110 cm (81.9 x 38.2 x 43.3 inches)
Item Weight	25 Kilograms (55.1 lbs)
Maximum Weight Recommendation	70 Kilograms (154.3 lbs)
Compatible Mattress Size	90 x 200 cm (35.4 x 78.7 inches)
Special Features	Removable curtain, Solid construction, Fall protection, Rounded edges and posts
Included Components	Bed frame, Slide, Curtain, Tunnel



Image: A close-up view of the wooden slatted bed base, showing individual slats and their connecting straps.

Warranty Information

Specific warranty details for the Homestyle4u Solid Pine Bunk Bed are not provided in the product data. For information regarding warranty coverage, please contact the manufacturer directly using the support contact details provided below or refer to the documentation included with your purchase.

Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Homestyle4u customer support.

- **Manufacturer:** HOMESTYLE4U
- **Contact Information:** Please refer to the contact details provided on the product packaging or the official Homestyle4u website.
- **When contacting support, please provide:**
  - Your purchase date
  - The product model number: HOMESTYLE4U_539
  - A detailed description of your issue

© 2026 Homestyle4u. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question