

Sevylor Adventure

Sevylor Adventure Inflatable Kayak User Manual

Model: Adventure (2000009547)

INTRODUCTION

Thank you for choosing the Sevylor Adventure Inflatable Kayak. This manual provides important information for the safe and effective use of your kayak. Please read all instructions carefully before assembly and use. Retain this manual for future reference.

The Sevylor Adventure is a robust 2-person inflatable kayak designed for use in lakes, calm seas, and general recreational paddling. Its wide shape ensures stability and comfort on the water.

SETUP AND INFLATION

Before inflation, ensure the kayak is placed on a clean, flat surface free of sharp objects.

1. **Unfold the Kayak:** Carefully unroll the kayak and lay it flat.
2. **Identify Air Chambers:** The kayak features multiple air chambers for safety and stability. These include two side chambers and an I-beam structured floor chamber.
3. **Inflate Chambers:** Use a suitable pump (not included) to inflate the chambers. The kayak is equipped with Boston valves for easy inflation and rapid deflation.
 - Open the outer cap of the Boston valve.
 - Insert the pump nozzle into the valve.
 - Inflate the chamber until it is firm to the touch but not overinflated. Use the included manometer to check the pressure. Recommended pressure for side chambers is 1.5 PSI and for the floor chamber is 0.9 PSI.
 - Quickly remove the pump and close the inner cap, then screw on the outer cap tightly to prevent air leakage.
4. **Install Seats:** The two inflatable seats are adjustable and removable. Position them inside the kayak and secure them according to your preference for comfort and paddling position.
5. **Attach Fin:** Locate the directional fin (skeg) and attach it to the designated slot on the underside of the kayak. This improves tracking and maneuverability.



Figure 1: Interior view of the Sevylor Adventure Kayak showing the two adjustable inflatable seats and the I-beam floor structure.



Figure 2: Cutaway illustration demonstrating the multi-chamber design and I-beam floor construction for enhanced stability and safety.

OPERATING INSTRUCTIONS

The Sevylor Adventure Kayak is designed for two occupants with a maximum load capacity of 165 kg (363 lbs). Always ensure the total weight of occupants and gear does not exceed this limit.

- **Entry and Exit:** Enter and exit the kayak carefully to maintain balance. Distribute weight evenly.
- **Paddling:** Use appropriate paddles (not included) for propulsion. The kayak's wide design provides excellent stability, making it suitable for various water conditions, including calm lakes and coastal waters.
- **Safety:** Always wear a personal flotation device (PFD) when using the kayak. Be aware of weather conditions and water currents. Do not use in rough waters or during storms.
- **Gear Storage:** Utilize the elastic cords at the bow and stern for securing small items and gear.



Figure 3: The Sevylor Adventure Kayak in use with two paddlers, demonstrating its stability and maneuverability on the water.

CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your Sevylor Adventure Kayak.

- **Cleaning:** After each use, especially in saltwater, rinse the kayak thoroughly with fresh water. Use mild soap if necessary. Ensure all sand and debris are removed.
- **Drying:** It is crucial to dry the kayak completely before storage to prevent mold and mildew. Deflate the kayak and wipe down all surfaces. If possible, allow it to air dry in a shaded area. Pay special attention to drying the interior and underneath the inflatable floor.
- **Storage:** Once completely dry, deflate the kayak and fold it compactly. Store it in the provided transport bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Repair Kit:** A repair kit is included for minor punctures. Follow the instructions provided with the repair kit for effective patching. For larger damage, professional repair may be required.



Figure 4: The Sevylor Adventure Kayak being carried by two individuals on a beach, highlighting its portability for transport and storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kayak loses air quickly.	Valve not properly closed, small puncture, or leak in a seam.	Ensure all Boston valves are securely closed. Check for punctures using soapy water and repair with the included kit. Inspect seams for damage.
Kayak feels unstable or difficult to steer.	Insufficient inflation, fin not attached, or uneven weight distribution.	Check and adjust air pressure in all chambers using the manometer. Ensure the directional fin is correctly installed. Distribute weight evenly among occupants.
Difficulty inflating.	Valve obstruction or pump malfunction.	Check valves for debris. Ensure pump nozzle fits securely into the Boston valve. Verify pump is functioning correctly.

SPECIFICATIONS

- **Model Name:** Adventure
- **Model Number:** 2000009547
- **Brand:** Sevylor
- **Inflated Dimensions (L x W):** 314 cm x 88 cm (approximately 123.6 in x 34.6 in)
- **Weight:** 11.5 kg (approximately 25.3 lbs)
- **Maximum Load Capacity:** 165 kg (approximately 363 lbs)

- **Number of Seats:** 2
- **Material:** PVC (Polyvinyl Chloride) and strong polyester hull
- **Features:** Boston valves, I-beam floor construction, 2 adjustable/removable inflatable seats, directional fin, manometer, transport bag, repair kit.

WARRANTY INFORMATION

For detailed information regarding the product warranty, please refer to the "Legal Warranty" section on the retailer's or manufacturer's support pages. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact Sevylor customer support or your product retailer. Have your model number (2000009547) and proof of purchase ready when contacting support.

© 2024 Sevylor. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question