

[Manuals.plus](#) /

› [MINKA-AIRE](#) /

› MINKA-AIRE F659-FB Classica 54" 5-Blade Ceiling Fan Instruction Manual

MINKA-AIRE F659-FB

MINKA-AIRE F659-FB Classica 54" 5-Blade Ceiling Fan Instruction Manual

Model: F659-FB

1. IMPORTANT SAFETY INFORMATION

Read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- **Electrical Safety:** All electrical wiring must be performed by a qualified electrician and conform to all local and national electrical codes. Disconnect power at the circuit breaker before installation or servicing.
- **Mounting:** Ensure the mounting structure can support the weight of the fan (approximately 23.2 pounds) and its operational forces.
- **Blade Clearance:** Maintain a minimum clearance of 7 feet from the floor to the bottom of the fan blades.
- **Proposition 65 Warning:** This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

2. PRODUCT OVERVIEW

The MINKA-AIRE Classica F659-FB is a 54-inch, 5-blade ceiling fan designed for indoor use. It features a French Beige finish with Medium Maple blades, offering a traditional aesthetic.

- **Design:** Traditional European and Old World design with a French Beige finish and Five Medium Maple Blades.
- **Motor:** Quiet, 3-speed reversible AC motor for year-round air circulation.
- **Downrod:** Includes a 6-inch downrod.
- **Light Kit:** No bulb included. Compatible with optional Universal Light Kit or Custom Light Kit K9659 (sold separately).



Image 2.1: The MINKA-AIRE Classica F659-FB ceiling fan with French Beige finish and Medium Maple blades.

3. SETUP AND INSTALLATION

Professional installation is required for this ceiling fan. Ensure all components are present before beginning installation.

3.1 Unpacking and Inspection

- Carefully remove all contents from the packaging.
- Inspect all parts for any damage. Do not proceed with installation if any parts are damaged.
- Verify all components listed in the packing list are present.

3.2 Mounting the Fan

The fan must be securely mounted to a ceiling joist or a fan-rated outlet box capable of supporting the fan's weight.

1. Turn off power at the circuit breaker.
2. Install the mounting bracket to the ceiling outlet box.
3. Assemble the downrod and canopy. The included downrod is 6 inches. Other lengths are available separately.
4. Carefully lift the fan assembly and hang it from the mounting bracket.



Image 3.1: Various downrod lengths available for ceiling fan installation, including the standard 6-inch downrod.

3.3 Electrical Connections

Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the full installation manual (not included here). Ensure all connections are secure and insulated.

3.4 Attaching Blades

Attach the five Medium Maple blades to the motor housing using the provided screws and washers. Ensure all blades are securely fastened.

4. OPERATING INSTRUCTIONS

The MINKA-AIRE Classica F659-FB ceiling fan can be operated using the integrated pull chain, or optionally with a remote control or voice control if a compatible smart control system is installed.

4.1 Pull Chain Operation

- **Fan Speed:** Pull the chain repeatedly to cycle through fan speeds: High, Medium, Low, Off.
- **Light (if installed):** If an optional light kit is installed, a separate pull chain will control the light.

4.2 Reversible Motor Function

A slide switch on the motor housing controls the direction of blade rotation.

- **Summer Mode (Downward Airflow):** Set the switch to move air downward, creating a cooling effect.
- **Winter Mode (Upward Airflow):** Set the switch to move air upward, circulating warm air trapped near the ceiling.

4.3 Remote and Voice Control (Optional)

This fan is compatible with remote control and voice control systems (e.g., Bond Enabled Smart WiFi Ceiling Fan Control). These accessories are sold separately and require their own installation and setup.



Image 4.1: Example of a remote control for operating the ceiling fan's functions.



Image 4.2: The Bond Compatible icon, indicating compatibility with smart home control systems.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** Clean the fan housing and blades periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Balance:** Check blade screws for tightness annually. Loose blades can cause wobbling and noise.
- **Electrical Connections:** Periodically check all electrical connections for tightness.

6. TROUBLESHOOTING

Before attempting any repairs, ensure power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Motor switch in OFF position.	Check circuit breaker; Verify all wire connections; Ensure pull chain is not in OFF position.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (sold separately) if needed; Ensure mounting bracket is secure.

Problem	Possible Cause	Solution
Noisy operation	Loose screws; Motor not seated properly; Blades rubbing.	Check and tighten all screws; Re-seat motor; Inspect for blade obstruction.

7. SPECIFICATIONS

Detailed technical specifications for the MINKA-AIRE Classica F659-FB ceiling fan.

Feature	Detail
Brand	MINKA-AIRE
Model Number	F659-FB
Color	French Beige
Blade Material	Maple
Number of Blades	5
Blade Length	54 inches
Product Dimensions (D x W x H)	54"D x 54"W x 16.75"H
Item Weight	23.2 pounds
Motor Type	AC
Number of Speeds	3
Control Method	Pull Chain Control, Remote Control, Voice Control (with optional accessories)
Voltage	120 volts
Wattage	60 watts
Air Flow Capacity	6313 cfm
Downrod Length (Included)	6 inches
Indoor/Outdoor Usage	Indoor
Energy Star Certified	Yes



8. WARRANTY AND SUPPORT

This MINKA-AIRE product is covered by a manufacturer's warranty.

- **Replacement Parts Policy:** All products purchased have a 30-day replacement parts policy to ensure a fully working item.
- **Warranty Period:** All products are covered under a 1-Year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped.
- **Coverage:** The warranty covers all items and conditions identified in the original manufacturer's warranty.
- **Exclusions:** The warranty specifically does not cover loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.
- **Manufacturer:** Minka Lighting LLC.

For support or warranty claims, please contact Minka Lighting LLC.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question