

Philips LRH1070/00

Philips LRH1070/00 SENSR Surface Box Instruction Manual

Model: LRH1070/00

[Contents](#) [Setup](#) [Introduction](#) [Safety Information](#) [Package](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and proper installation, operation, and maintenance of the Philips LRH1070/00 SENSR Surface Box. Please read this manual thoroughly before installation and retain it for future reference.

The Philips LRH1070/00 SENSR Surface Box is designed to provide a secure and aesthetically pleasing mounting solution for compatible Philips flat screen accessories, specifically the LRM1070 and LRM1080 models. It is intended for indoor use only.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the product:

- Ensure all electrical connections are made by a qualified electrician if wiring is involved.
- Do not install the surface box in damp or wet locations.
- Verify that the mounting surface is structurally sound and can support the weight of the surface box and any attached devices.
- Use appropriate tools for installation.
- Keep packaging materials away from children.
- Do not modify the product in any way. Unauthorized modifications may void the warranty and create safety hazards.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and undamaged. If any items are missing or damaged, contact your retailer immediately.

- 1 x Philips LRH1070/00 SENSR Surface Box (White)
- Mounting hardware (screws, anchors - typically included, but not explicitly listed in product data)
- Instruction Manual (this document)



Image: The Philips LRH1070/00 SENSR Surface Box. This white, square-shaped enclosure is designed for surface mounting and provides a housing for compatible Philips flat screen accessories.

4. SETUP AND INSTALLATION

The Philips LRH1070/00 SENSR Surface Box is designed for surface mounting and is compatible with Philips LRM1070 and LRM1080 accessories. Follow these steps for proper installation:

1. **Choose Location:** Select a suitable, flat, and stable surface for mounting. Ensure there is sufficient space and that the location meets any specific requirements for the LRM1070 or LRM1080 accessory.
2. **Mark Mounting Points:** Hold the surface box against the desired mounting location. Use a pencil to mark the positions for the mounting screws. Ensure the box is level before marking.
3. **Drill Pilot Holes:** Using an appropriate drill bit for your wall material (e.g., wood, drywall, masonry), drill pilot holes at the marked positions. If installing into drywall, insert wall anchors (not supplied, but typically required for secure mounting).
4. **Secure the Box:** Align the surface box with the pilot holes/anchors. Insert the mounting screws (supplied with the box or appropriate for your anchors) and tighten them until the box is firmly secured to the surface. Do not overtighten.
5. **Install Compatible Accessory:** Once the surface box is securely mounted, proceed with installing your Philips LRM1070 or LRM1080 accessory according to its specific instruction manual. The

surface box provides the necessary housing and connection points for these compatible devices.

Note: This surface box is a housing component. Refer to the specific manual of your Philips LRM1070 or LRM1080 accessory for its operational details.

5. MAINTENANCE

The Philips LRH1070/00 SENSR Surface Box requires minimal maintenance.

- **Cleaning:** To clean the surface box, wipe it gently with a soft, dry cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying thoroughly.
- **Do Not Use:** Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically check the mounting screws to ensure they remain tight and secure.

6. TROUBLESHOOTING

If you encounter issues during installation or use, refer to the following common solutions:

Problem	Possible Cause	Solution
Surface box is not level after mounting.	Mounting points were not marked accurately, or screws were tightened unevenly.	Loosen screws slightly, adjust the box to be level, then retighten evenly. If necessary, remove and re-mark mounting points.
Surface box feels loose after installation.	Screws are not fully tightened, or wall anchors are insufficient for the wall material.	Ensure screws are tightened securely. If using wall anchors, verify they are appropriate for your wall type and installed correctly. Consider using stronger anchors if needed.
Compatible accessory (LRM1070/LRM1080) does not fit into the surface box.	Incorrect accessory model or improper alignment.	Double-check that your accessory is indeed a Philips LRM1070 or LRM1080. Ensure correct orientation and alignment when attempting to fit it into the surface box. Do not force it.

7. SPECIFICATIONS

Feature	Detail
Model Number	LRH1070/00
Product Color	White
Dimensions (L x W x H)	95 x 95 x 51.5 mm (3.74 x 3.74 x 2.03 inches)
Weight	100 g (3.53 ounces)
Compatibility	Philips LRM1070, Philips LRM1080
International Protection (IP) Rating	IP00
Quantity per pack	1 pc(s)

Feature	Detail
Manufacturer	Philips
ASIN	B006D7UA0E
Item Model Number	871155973143899
GTIN (UPC/EAN)	08711559731438

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Philips website or contact Philips customer service in your region. Keep your proof of purchase for warranty claims.

Philips Official Website: www.philips.com

For technical assistance or inquiries regarding the Philips LRH1070/00 SENSR Surface Box, please contact Philips support directly.