

[manuals.plus](#) /› [PanDigital](#) /› [Pandigital PANSCN08 8.5x14 HandHeld Wand Scanner User Manual](#)

## PanDigital PANSCN08

# Pandigital PANSCN08 Handheld Wand Scanner User Manual

Model: PANSCN08

## 1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Pandigital PANSCN08 Handheld Wand Scanner. This device is designed to digitize documents and photos up to 8.5 x 14 inches with resolutions up to 600 dpi, offering both color and grayscale scanning capabilities. It operates independently, saving scans directly to a microSD card.

## 2. SAFETY INFORMATION

- Do not expose the scanner to water or excessive moisture.
- Avoid dropping the device or subjecting it to strong impacts.
- Keep the scanner away from direct sunlight and heat sources.
- Use only the specified battery type and ensure correct polarity during installation.
- Do not attempt to disassemble or repair the scanner yourself. Contact qualified service personnel.
- Keep out of reach of children.

## 3. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Pandigital PANSCN08 Handheld Wand Scanner
- USB Cable
- 2GB microSD Card
- Cleaning Cloth
- User Manual (this document)

## 4. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your scanner:



Image 1: The Pandigital PANSCN08 handheld wand scanner, showcasing its compact design and control panel.

- **Scan Button:** Initiates and stops scanning.
- **Mode Button:** Toggles between different scanning modes (e.g., DPI, Color/Grayscale, File Format).
- **LCD Display:** Shows current settings and status.
- **MicroSD Card Slot:** For inserting the memory card.
- **USB Port:** For connecting to a computer to transfer files.
- **Battery Compartment:** Houses the batteries.
- **Scanning Head:** The optical sensor that captures the image.
- **Rollers:** Guide the scanner smoothly over the document.

## 5. SETUP

---

### 5.1. Battery Installation

1. Locate the battery compartment cover on the scanner.
2. Slide or unclip the cover to open it.
3. Insert the required batteries (e.g., 2x AA batteries, not included) according to the polarity markings (+/-).
4. Close the battery compartment cover securely.

### 5.2. MicroSD Card Installation

1. Locate the microSD card slot on the side of the scanner.
2. Insert the included 2GB microSD card into the slot with the gold contacts facing down, until it clicks into place.
3. To remove, gently push the card inward until it springs out.

### 5.3. Powering On/Off

- **To Power On:** Press and hold the Scan button for approximately 2 seconds. The LCD display will illuminate.
- **To Power Off:** Press and hold the Scan button again for approximately 2 seconds. The display will turn off.

## 6. OPERATING THE SCANNER

---

### 6.1. Adjusting Settings

Before scanning, you can adjust the following settings using the Mode button and the Scan button for selection:

- **DPI (Dots Per Inch):** Select between 300 dpi (standard) or 600 dpi (high resolution). Higher DPI results in larger file sizes and more detail.
- **Color Mode:** Choose between Color or Grayscale scanning.
- **File Format:** Select JPEG (for images) or PDF (for multi-page documents).

## 6.2. Scanning a Document or Photo



**Image 2:** A user demonstrating the handheld scanning process with the Pandigital PANSCN08 scanner over a document.

1. Place the document or photo on a flat, stable surface.
2. Ensure the scanner is powered on and desired settings are selected.
3. Position the scanner at the top edge of the document, ensuring the scanning head is fully over the content.
4. Press the Scan button once to begin scanning. The scan indicator light will illuminate.
5. Slowly and steadily glide the scanner downwards over the document. Maintain even pressure and a straight path. The dual rollers assist in keeping the scan straight.
6. Once you reach the end of the document, press the Scan button again to stop scanning. The scan indicator light will turn off.
7. The scanned image will be automatically saved to the microSD card.

## 6.3. Transferring Files to a Computer

1. Ensure the scanner is powered off.
2. Connect the scanner to your computer using the provided USB cable.
3. The scanner will appear as a removable storage device (like a USB drive) on your computer.
4. Navigate to the scanner's drive and locate the scanned files (typically in a folder named 'DCIM' or 'SCAN').
5. Copy the desired files to your computer.
6. Safely eject the removable storage device from your computer before disconnecting the USB cable.

## 7. MAINTENANCE

### 7.1. Cleaning the Scanner

- **Scanning Head:** Use the included cleaning cloth or a soft, lint-free cloth to gently wipe the scanning head. Do not use abrasive cleaners or solvents.
- **Exterior:** Wipe the exterior of the scanner with a soft, dry cloth.
- Ensure the scanner is powered off before cleaning.

## 7.2. Battery Care

- Remove batteries if the scanner will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

## 8. TROUBLESHOOTING

- **Scanner not powering on:** Check battery installation and ensure batteries have sufficient charge.
- **Poor scan quality (blurry/streaky):** Ensure the scanning head is clean. Scan slowly and steadily. Check DPI settings.
- **Scanner not recognized by computer:** Ensure the USB cable is securely connected and the scanner is powered off before connecting. Try a different USB port or cable.
- **MicroSD card error:** Ensure the card is inserted correctly. Try reformatting the card (this will erase all data).
- **Scanner stops mid-scan:** Ensure batteries are not low.

## 9. SPECIFICATIONS

<b>Model Number</b>	PANSCN08
<b>Scanner Type</b>	Handheld Wand Scanner
<b>Maximum Document Size</b>	8.5 x 14 inches (Legal)
<b>Resolution</b>	Up to 600 dpi
<b>Color Depth</b>	Color, Grayscale
<b>File Formats</b>	JPEG, PDF
<b>Storage</b>	MicroSD card (2GB included)
<b>Connectivity</b>	USB
<b>Power Source</b>	Batteries (not included)
<b>Minimum System Requirements</b>	Windows 7
<b>Item Weight</b>	1.4 pounds

## 10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official PanDigital website. Keep your proof of purchase for warranty claims.

## Related Documents - PANSCN08

 Handheld Wand Scanner User Guide V1.6	<p><a href="#">Pandigital Handheld Wand Scanner User Guide V1.6</a> Comprehensive user guide for the Pandigital Handheld Wand Scanner (V1.6), detailing setup, operation, software, maintenance, and troubleshooting for efficient document and photo scanning.</p>
 Digital Photo Frame User Guide PI8004W01	<p><a href="#">Pandigital PI8004W01 Digital Photo Frame User Guide</a> Comprehensive user guide for the Pandigital PI8004W01 Digital Photo Frame, detailing setup, photo display, music playback, video viewing, Wi-Fi connectivity, PC transfer, and Bluetooth features.</p>
 Digital Photo Frame User Guide	<p><a href="#">Pandigital Digital Photo Frame User Guide</a> Comprehensive user guide for the Pandigital Digital Photo Frame, covering setup, operation, features like slideshows, music playback, video viewing, clock/alarm functions, file management, troubleshooting, warranty, and FCC compliance.</p>
 Handheld Wand Scanner User Guide V1.6	<p><a href="#">Pandigital Handheld Wand Scanner User Guide V1.6</a> Comprehensive user guide for the Pandigital Handheld Wand Scanner (V1.6), detailing setup, operation, software, maintenance, and troubleshooting for efficient document and photo scanning.</p>
 Digital Photo Frame User Guide PI8004W01	<p><a href="#">Pandigital PI8004W01 Digital Photo Frame User Guide</a> Comprehensive user guide for the Pandigital PI8004W01 Digital Photo Frame, detailing setup, photo display, music playback, video viewing, Wi-Fi connectivity, PC transfer, and Bluetooth features.</p>
 Digital Photo Frame User Guide	<p><a href="#">Pandigital Digital Photo Frame User Guide</a> Comprehensive user guide for the Pandigital Digital Photo Frame, covering setup, operation, features like slideshows, music playback, video viewing, clock/alarm functions, file management, troubleshooting, warranty, and FCC compliance.</p>

PANDIGITAL®

Handheld Wand Scanner



User Guide

V1.1

[\[pdf\]](#) Guide Declaration of Conformity

Microsoft Word UG E PANSCN08 v1 1 IN PROGRESS doc ksmalley E167092 user guide qvc 80 footers

|||

Handheld Wand Scanner User Guide V1.1 Table of Contents Read This First

..... nt..... 21 UG-

E\_PANSCN08\_v1.1\_01-11 2 Read This First Please read the following important safety instructions care...

lang:en **score:35** filesize: 2.81 M page\_count: 22 document date: 2011-05-16

PANDIGITAL®

Handheld Wand Scanner



User Guide

V1.6

[Pandigital Handheld Wand Scanner User Guide V1.6](#)

Comprehensive user guide for the Pandigital Handheld Wand Scanner (V1.6), detailing setup, operation, software, maintenance, and troubleshooting for efficient document and photo scanning.

lang:en **score:33** filesize: 2.29 M page\_count: 27 document date: 2011-06-16